

13-MAY-2000 14:39 FROM IDT-HK LTD PDD / TEL

TO

27411693 P.01

Frequency Table

40CH	10CH	Hand TX	Base TX
1		925.30	902.80
2	1	925.35	902.85
3		925.40	902.90
4		925.45	902.95
5		925.50	903.00
6	2	925.55	903.05
7		925.60	903.10
8		925.65	903.15
9		925.70	903.20
10	3	925.75	903.25
11		925.80	903.30
12		925.85	903.35
13		925.90	903.40
14	4	925.95	903.45
15		926.00	903.50
16		926.05	903.55
17		926.10	903.60
18	5	926.15	903.65
19		926.20	903.70
20		926.25	903.75
21		926.30	903.80
22	6	926.35	903.85
23		926.40	903.90
24		926.45	903.95
25		926.50	904.00
26	7	926.55	904.05
27		926.60	904.10
28		926.65	904.15
29		926.70	904.20
30	8	926.75	904.25
31		926.80	904.30
32		926.85	904.35
33		926.90	904.40
34	9	926.95	904.45
35		927.00	904.50
36		927.05	904.55
37		927.10	904.60
38	10	927.15	904.65
39		927.20	904.70
40		927.25	904.75

To: Angela Tang.

From: Blandine - CT 7/16

Frequency Table for

RS 918. (10CH)

Tommy Leung ITS/LAB-HKG

From: Blanche Wong [pdd.tel@idthk.com]
Sent: Tuesday, June 27, 2000 5:52 PM
To: Tommy Leung (E-mail)
Subject: 900Mhz RF Description

Antenna is used for both RF transmission and RF reception (same for both Base and H/S).

For the transmission, audio signal is sent to the RF Module. The RF Module can convert it to RF frequency. The RF frequency goes out from the Module Antenna pin, through PCB layout pattern, antenna fixing screw and then radiated out from Antenna.

For the reception, RF signal is pick up by the Antenna and goes through antenna fixing screw, and then goes through PCB layout pattern, and sent to Module Antenna pin. The RF Module can convert it to audio signal and output through the Audio output pin.

Please note that the RF module for 43-3504 is Samsung (RU0926H18HKC - H/S, RU0902B18HKB - B/U), for 43-3505 is Sambo (SBM-3020A-HIW - H/S, SBM-3020A-BIW- B/U)

Best Regards