

Dosmono Scanning pen

C505H

Instruction Manual

Summary Description: the scanning pen is an artificial intelligence product that integrate many technologies such as picture splicing, OCR, translation, intelligent voice, ext. The efficiency of solving problems is greatly improved in the scenes of re-study, overseas tourism, business office, etc.

Power button:

1. Power On / Off: Long press the power button for more than 3 seconds to select on/ off or restart the product.
2. Standby: short press the power button to unlock the screen or standby.

Volume button (shared with the voice button): press the red / blue button to adjust the sound volume.

Return button: (common AI function key): short press the "round button" of the device or short press the power button twice to return.

Touch screen: it supports clicking, sliding, and tapping the screen to select the required functions.

Red / blue voice button: it is the voice input button of voice translation function. Long press the blue button to speak Chinese which automatically translate it into English; Long press the red button to speak English which automatically translate it into Chinese.

Quick Guide:

First of all, thank you very much for using our AI products!

Preparations before using:

1. Power charging: please check whether the power of the device is sufficient before use it.

If the device cannot be started or shows lake of battery, please use the equipped charging line to charge the device. It is best to charge for 1 hour or wait until the battery is sufficient before turn on the device.

When the device is powered off, the screen will display the charging indication and the percentage of power in about 8-10 seconds.

Charge the device when it is powered on, the battery logo in the upper right corner of the screen

will show with "lightning" mark.

2. Network connection: after the device is turned on, connect the network in the setting - "WLAN" interface. It can be connected to WiFi or mobile hotspot which make the device more effective during online mode.

3. Scan Operation

(1) Due to the technical requirements of this product, during the scanning process, the advice shall be inclined at 70-90 degrees with the plane, and the collimation shall be aligned with the text center line;

(2) Press the pen head, when it starts to light up, drag the scanning to the right and keep the pen head light on constantly during the scanning process;

(3) Align the aim point with the blank space in front of the first text and start scanning. After scanned the last text, raise the pen head;

(4) View the results and click the screen for corresponding operations;

4. Offline Use


This device supports normal scanning dictionary and other functions without connecting with the network; It is recommended to connect the network first for better using experience

5. The top of the device screen displays some status information about the device, such as WiFi connection status, power percentage, charging status, etc.

Main functions: (in the main interface, if you directly press the pen head to scan, the scanning dictionary function is automatically used by default)

Scan dictionary

It supports Chinese and English vocabulary scanning and has a large amount of vocabulary contents. If you need to connect with multi-line scanning, please turn on the multi-line function.

(1) After scanning, the screen will automatically displays the results. Tap the word / sentence to view the details, tap  to add to the new thesaurus for easy review in the future.

(2) It has the functions of text interpretation, word explanation, sentence making, synonym, antonym and other functions.

Voice translation (online use)

Support online language translation in Chinese and English (with our software upgrade, the supported languages will increase)

In the voice translation interface, long press the blue button to speak Chinese and automatically translate it into English; Long press the red button to speak English and automatically translate it into Chinese; The screen will automatically displays the results and read them out.

Basic learning (English, Chinese, Mathematics)

It includes multi-disciplinary synchronous and basic knowledge to help children quickly master basic knowledge and improve learning efficiency

Synchronous learning

Conduct relevant explanation, knowledge induction, expand learning and increase the width of knowledge for multiple disciplines.

AI voice

Equipped with intelligent voice system, after long press AI function button, the encyclopedia system will solve the question what you have asked.

Vocabulary Notebook

Words are not mastered during scanning can be collected in the vocabulary notebook for review and learning again.

Tools: including music, video, recorder, etc.

System settings

1. WLAN: connect WiFi for the device which make the device functioning more effective.
2. Bluetooth: Connect to Bluetooth headset, Bluetooth speaker and other audio devices.
3. Volume: Sounds up/down.
4. Brightness: Adjust the brightness of the screen.
5. Date time: View date time and set time zone.
6. System update: Able to check whether there is any updated software version and start to update it.

7. About the device: view the current equipment model, SN number, software version and other information.

8. Pen holding direction: you can choose left / right hand pen holding according to your habits.

Cautions

1. When upgrading the device, do not perform any operations during program download or automatic program installation.

2. Please connect to WIFI for better using experience; Some functions require networking.

3. During scanning, keep the equipment inclined at 70-90 degrees, align the aim point with the text center line, and drag at a constantly speed; If the identification is not correct, try again.

4. Align the aim point with the space before the initial letter and start scanning. After the aim point has scanned the last letter, raise the pen head.

5. During voice translation, the distance between the mouth and the MIC of the device is within 30cm, which is the best distance for voice recognition.

6. Please speak with normal speed and coherence and do not pause many times during the talk. The above situation is easy to cause inaccurate translation.

7. Please try to pronounce words as standard as possible, and don't use phrases or slang.

8. The recognition results can be verified through the text displayed on the screen. If there is any error, it can be manually input and edited.

9. If your words are correctly recognized, but the translation is not accurate, please change your expression.

Exception handling

Forced shutdown: when the device fails to shut down normally or crashes, press and hold the power key for more than 10 seconds to force shutdown.

Device Name	Scanning Dictionary Pen	Model	
Body Size	155*43*14mm	Weight	92g
Specification	5V/1A	Standby Time	7-10 days
Wire	Type-c	Screen Size	3.5 inches
Battery Volume	1500mah	Materials	ABS

Product Parameters

Warning

1. Do not use this device in gas stations, fuel depots and other places where electronic equipment is prohibited, otherwise it may cause explosion or fire.
2. Please do not use unapproved or incompatible power supplies and chargers, which may cause fire, explosion or other hazards.
3. When charging is completed or not, please disconnect the charger from the device and unplug the charger from the power socket.
4. It is strictly prohibited to prevent and control the device in an environment with too high or too low temperature to avoid fire, explosion or product failure; It is strictly prohibited to put the device close to heat sources, such as ovens, electric heaters, etc., and do not put it into the fire; Lithium batteries shall not be exposed to such conditions as sunlight, fire or similar overheating situation.
5. It is strictly prohibited for children or pets to swallow or bite the device to avoid unnecessary injury.

Exception clauses

1. Please read the product manual carefully before use and operate in strict accordance with the instruction.
2. This product is not responsible for the translation results.
3. This product is not waterproof. The user shall be responsible for the damage of the machine caused by water inflow.

Warranty regulations

1. The free warranty period of this product is 12 months.
2. During the warranty period, the faults caused by using according to the instructions (determined by the after-sales personnel of our company or the authorized service personnel of our company) shall be repaired free of charge.
3. During the warranty period, the following situations do not belong to the area of free warranty:

(1) Unable to provide warranty certificate and valid purchase certificate.

(2) Unauthorized maintenance, misuse, collision, negligence, abuse, accident, incorrect use of this product, etc.

(3) Long-term exposure to strong light, fire or similar overheated environment.

(4) Machine damage or performance failure caused by human factors such as water inflow.

(5) Using unqualified power supply above 5V / 2A.

The company shall not be liable for any special, incidental or indirect loss and damage.

Warranty certificate

Vendor name:

Place of purchase:

Customer Name:

Contact number:

Contact address:

Product SN:

[illegible]

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.