


掌上云台相机2使用说明书 使用本产品前请仔细阅读本说明书

PALM 2 Gimbal Camera User Manual

Please read this manual carefully before use



1.Product Introduction



2. Charging

To charge PALM2, please use the included USB cable to connect it with the USB-C port in maximum charging current of 5V2A. While charging, the status LED is always on. When the battery is fully charged, the status LED is off.



3. The equipment of external MIC

Please equip the MIC as shown.



4. Inserting the MicroSD Card

Please insert the MicroSD Card as shown, It is recommended to use a microSD card with or over a UHS-III Speed Grade 3 rating. The PALM 2 supports atmost SD card with 256C(not included), and you can format the SD card on PALM 2.





Status	Instruction
Long press	Turn on or turn off the PALM
Short press	Take a capture according to current shooting mode
Double dick	To recenter the gimbal

2. Direction joystick

Direction joystick



Status	Instruction	Remarks
Move up	To control the gimbal camera move up	Mode 1
Move down	To control the gimbal camera move down	Mode 1
Move left	To control the gimbal camera move left	Mode 1
Move right	To control the gimbal camera move right	Mode 1
Move up	ZOOM+	Mode 2
Move down	ZOOM -	Mode 2
Move left	EV-	Mode 2
Move right	EV+	Mode 2


P.S. Click the " + on the top right of screen to switch mode 1 and mode 2.

3. Touch Screen





Status	Instruction
Swipe right/left	To switch shooting mode
Swipe down	To enter setting mode
Swipe up	To enter media library
Double dick	Turn on / turn off Face Tracking
Double click the selfie button	To switch selfie mode
Long dick the selfie button	To center the gimbal



6. Downloading APP

Please scan the QR code or search for downloading the FIMI PLAY APP in APP Store or Google Play



7. Maintenance and Calibration

- 1. The PALM 2 enters the self-check when it is powering.
- Gimbal camera is a high-precision control device. Please do not drop it or have it hit by external force. And please ensure that the gimbal doesn't be blocked by outside forces when it is moving. Otherwise, the machine might be damaaed and be led to a hormal operations.
- Do not place the battery near heat. Lithium battery's capacity reduces significantly in low temperature conditions. Please do not use the PALM 2 if the temperature is below 0 celsius degree.

9. Basic Specification

Name: PALM 2 Gimbal Camera Model: YTAUGRFM Dismensions: 32.5'35.5'132.5mm Net Weight: 145g (accessories are not included) Precision Control ± 0.005' PITCH: ±00' Battery Capacity: 2600 mAh Rated Povers: 982 W Rated Voitage: 3.7V Operating Temperature: 0C-40°C Wrieless Connectivity: WFFIEEE 802.11b/g/n Product standard: QBJ/FMK0005-2017 Check more detailed information in setting This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the Imits for a Class B digital device, pursuant to part 15 of the FCC Rules. These Imits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordinate with the instructors, may cause harmful interference to hard out motion and the state of the state o

- -Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Manufacturer: Sherzhen Fini Robot Technology Co., Ltd. (a Mi Ecosystem company) Address: 2nd Floor, East Block, Tianliao Bullding, 1133 Xueyuan Avenue, Xil Town, Nanshan District, Shenzhen City, China Official website: www.fimi.com Online service: support@fimi.com TEL: 400-661-9098

FCC statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This model product has been tested and meets the FCC RF exposure guidelines with the test distance 20mm for body worn