Owner's Manual

Retain this owner's manual for future reference Read and follow all instructions in this owner's manual

THANK YOU

Thanks for purchasing this product. The product will help you keep fitter, healthier and better in a very easy way. Read and follow all warnings and instructions. For consumer fitness equipment, ensure that proper instructions are obtained prior to use.

IMPORTANT SAFETY INSTRUCTION

• Care should be taken in mounting or dismounting the treadmill. Before mounting or dismounting, bring the machine to a complete stop.

Read all instructions before using the treadmill For HOUSEHOLD USE ONLY. SAVE THESE INSTRUCTIONS.

- When using an electrical appliance, basic precautions should always be followed, including the following: Read all instructions before using (this appliance).
- This treadmill is designed for home use for jogging, running workout purpose; Don't use the treadmill for other exercises which has not relation to treadmill.
- Place the treadmill indoors to avoid any water and no heavy stuff.
- The treadmill shall be installed on a stable and levelled base.
- When using the fitness device, wear comfortable clothing and preferably sports or aerobic shoes.
- Keep Children away from the treadmill to avoid any accident.
- Prior to use, inspect the treadmill to ensure there is no incorrect, worn, or loose components and all components are in good condition and tighten properly. Refer to treadmill maintenance in last chapter for more information.
- Refer to treadmill maintenance keep the top side of the moving surface clean and dry.
- Refer to treadmill maintenance to replace defective components immediately and/or keep the equipment out of use until repair and pay special attention to components most susceptible to wear.
- Refer to treadmill maintenance for method of adjusting the tension and the lateral position of the running surface.
- The safety and integrity designed into the machine can only be maintained when the treadmill is regularly examined for damage and repaired. It is the sole responsibility of the user/owner or facility operator to ensure that regular maintenance is performed. Worn or damaged components shall be replaced immediately, or the

treadmill removed from service until the repair is made. Only manufacturer-supplied or-approved components shall be used to maintain and repair the treadmill.

- The safety level of the equipment can be maintained only if it is examined regularly for damage and wear.
- No overload to give damages to motor, controller, roller and running belt . Make routine maintenance to the treadmill.
- Keep less dust indoors and keep a certain extent of humidity to avoid interference of console and controller.
- For home use treadmill, keep the treadmill continuous running no more than 2 hours. Indoor use, class HC.
- Keep good air circulation when running.
- The recommended minimum clearance required around each treadmill for access to and passage around shall be 500 mm (19.7 in.) on each side of the treadmill. There shall be 2000x1000mm safe space at the treadmill end when running.
- The minimum clearance area behind the treadmill shall be: 2.0 m (78.7 in.). This clearance shall encompass the entire width of the treadmill or the entire length of a row of treadmills. This clearance zone shall be free of all obstructions.
- Read, understand, and test the emergency stop procedures before use. Refer to how to use emergency key chapter for more information.
- Do not exceed maximum user weight 130KG.
- Stop running if any discomfort and consult the doctor.
- "WARNING! Heart rate monitoring systems may be inaccurate. Over exercising may result in serious injury or death. If you feel faint stop exercising immediately";
- Keep the silicone oil bottle out of reach from children and avoid eating by mistake.
- After workout, don't jump out of the treadmill directly, so to prevent accident.
- Pull out of the power plug gently from the socket.
- Correct biomechanical positioning of the user on treadmill is important for healthy workout. For correct workout suggestions, please refer to HOW TO USE THE PRODUCT chapter. Injuries to health may result from incorrect or excessive training.
- During workout, stop use the machine if anything wrong and cut the power immediately.

- The value of the A-weighted emission sound pressure level at the trainer's ear: 68.4dB.
- Noise emission under load is higher than without load.
- Ask local distributor to handle any issue or provide service. It's not allowed to dismantle the components personally. if any of the adjustment devices are left projecting, they could interfere with the user's movement.
- This treadmill is 120KGS.
- DANGER To reduce the risk of electric shock: Always unplug this appliance from the electrical outlet immediately after using and before cleaning.
- WARNING To reduce the risk of burns, fire, electric shock, or injury to persons:
- 1) An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
- 2) Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- 3) This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Keep children under the age of 13 away from this machine.
- 4) Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- 5) Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- 6) Do not carry this appliance by supply cord or use cord as a handle.
- 7) Keep the cord away from heated surfaces.
- 8) Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair, and the like.
- 9) Never drop or insert any object into any opening.
- 10) Do not use outdoors.
- 11) Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

- 12) To disconnect, turn all controls to the off position, then remove plug from outlet.
- CAUTION To Reduce The Risk Of Injury From Moving Parts Unplug Before Servicing.
- WARNING To Reduce the Risk of Electric Shock Unplug Before Cleaning or Servicing
- CAUTION Risk of Injury to Persons To Avoid Injury, use extreme caution when stepping onto or off of a moving belt. Read Instruction Manual Before Using.
- For household use only.
- Connect this appliance to a properly grounded outlet only. See Grounding Instructions.
- SAVE THESE INSTRUCTION

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.


USE GUIDE

- Always connect the appliance to a socket with a grounded circuit and no other appliances connected to it. It is recommended not to use any extension cords.
- Ensure the treadmill stable on the ground before use.
- Check if its function normal or not before running.
- Stand on two side rails when the treadmill starts.
- Attach the safety key to your clothes when running to control any emergency.
- Press "start" button to get the treadmill started.
- Follow the running belt with left leg to do pre-running. Only when you feel it right, then to run with two legs on the treadmill with proper running posture.
- ONLY FOR ONE PERSON. Overload not allowed.
- Adjust speed if necessary.
- After running, pull out the safety key or press "stop" button to get it stopped.
- After running, remember to turn off the power and pull out the plug.
- When you are running on the treadmill, if you feel discomfortable, please stop to run immediately and consult doctors.
- When you are assembling or running the machine, please ensure no person or pets around it.

GROUNDING INSTRUCTIONS


 This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

- DANGER- Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product if it will not fit the outlet, have a proper outlet installed by a qualified electrician.
- This product is for use on nominal 120-V circuit, and has a grounding plug that looks like the plug illustrated in sketch A in below picture. The adaptor is not allowed for use.



DANGER !

To reduce accidents or do harm to any others, check following rule.



- Don't wear the clothes, which is easily hooked.
- Keep power cord away from hot objects.
- Keep children away from the treadmill.

- If anything goes wrong, you can make push-up on the handlebar, leave both leg from the running belt, and jump from outside the treadmill.
- Cut off the power before moving the treadmill.
- Don't open motor and roller cover unless professional technician.
- This machine is used under 10A circuit.
- ◆ Make sure that only one person at a time uses the fitness device.
- The treadmill HRC devices is not professional medical devices, and may not be as exact as medical devices, its results are for reference only.

Stop exercising immediately, should you feel unwell or if you feel pain in your joints or muscles. In particular, keep an eye on how your body is responding to the exercise program. Dizziness is a sign that you are exercising too intensively with the device. At the first signs of dizziness, lay down on the ground until you feel better.

INAPPROPRIATE USER

Following patients under treatment need to get use of the treadmill after approval of professional doctor.

- The person with backache or used to get hurt in the leg, waist, neck.
- The patient with arthritis deformans, rheumatism or gout.
- The patient with osteoporosis.
- The patient with a bad circulatory system like heart disease, vascular disorders and vascular hypertension.
- The patient with respiratory disturbance.
- The patient with Artificial heart rhythm problem.
- The patient with malignant tumors.

- The patient with thrombosis.
- The patient with diabetes-caused perceptual disturbance.
- The person with skin injury.
- ◆ The patient with a high fever above 38° C.
- The person with bent back bone.
- The person with pregnancy or in (menstrual) period.
- The person feels discomfortable.
- The person sleeps badly.

PROHIBITION

Don't use treadmill in following cases, or it will lead to fire or get damaged.

- ◆ Do not use the machine when some cover or inner component is not complete
- ◆Do not jump on or jump off the treadmill
- ◆ Do not use or place it outdoors or rainy or humid environment.
- ◆ Do not use or place it under strong sunlight or high-temperature environment.
- ◆Do not use when there is damage or loose to the power cord or socket
- ◆Do not twist or damage the power cord or put something heavy on it .
- ◆Do not use by two persons at the same time. Keep other people far away from it.
- \blacklozenge Do not let the disabled or somebody who cannot operate the machine to use .
- ◆Do not dismantle the machine personally.

Attention!

- \blacklozenge Do not take strong exercise if you a lazy fitter on common days .
- ◆ Do not work out just after meal or when you feel tired ,flaccid or discomfortable.
- ◆Do not use it when you are drunk .
- Do not use when your pocket is full of hard things.
- Do not have any dust, waste, and water on the power plug.

- Do not use with damp hands.
- Do not pull out or plug in the power cord, otherwise you can be hurt or get an electric shock.

PLUG OUT TIPS

In following cases, please pull out the power cord from the socket, otherwise can lead to fire as dust and humidity will get the power cord insulation worse OR you can be hurt or get an electric shock.

- The treadmill is not used
- When the treadmill is under maintenance
- ◆Can not start or appear abnormal
- Have the power failure.
- When you are plugging out, don't hold the power cord only. You should hold the power cord head and then plug out.
- The treadmill shall be grounded to get less electric shock as grounding provide narrowest channel to the resistance. Please follow local rule to assemble the socket and plug in a proper way. Or you can consult a professional technician. Adaptor socket is not allowed.

Warning labels

echelon RIDE-SO-RCX

Echelon Fitness Multimodia, LLC Street, Suite 700, Chattanologa, TN 37450 1413-917-2453 / 1-423-402-9010

Model / Models / Models STRDE-RCR FCE EF 2AMD4-ECHL7747 Made In China / Fabriquel en Chine / Hecho on China Max User Weight / Polds max, utilisation? Max. peso del usuario: 285 lbs / 130 kg

Motor / Moteyar 2 DCHP, 3.0PHP input / Ermier / Ermadie 120V-60Hz Power / Alimentation / Pritencia: 1300W Current / Courant / Energial 13A Class / Classe / Class: HC

This device complian with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) the device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause underived operation of the device.

Cet appareil est conturne à la partie 15 des règles de la FCC. Son fonctionnement est souvris aux deux conditions sulvarites (1) cet appareil peut provoquer disinterferences nocives, et (2) cet appareil cuit accepter les interférences reçues, y compru culles qui peuverit causer un dysfonctionnement.

Este dispositivo comple con la Parte 15 de las Reglas de la FCC. El funcionamiento está warto a las dos constituines siguientes (1) Este dispositivo no pueda causar interferencias darivnas y (2) este dispositivo debe aceptar cualquier anterferencia recibita, incluida las interferencias que prudan causar un funcionamiento no desnado del dispositio

SERIAL FRANCODE SERIAL #

'WWW Continents UL STD 1947, Centrel to CSA STD C232 ND 48

Declarity errort deptind é unier usager préve Solo pare inst tiel concentrates Configme #18, 370, 1647 Centre #CSA 370, C32,2 ND 88 Cumple con UL \$10, 1647 Centhurds segun CSA 510, C22,2140, 68



ort Rais monitoring lipides may be

inscorute. Over-overcheing may result in

entrops toppy of dealth. If you feel band,

en cline of all residing parts.

part the appigment before use and the

stop searcitizing immediately-

New look, chilling, and Threes

WARNING AVERTISSEMENT ADVERTENC TRAVELAS DIVERSITS A MANYTENELA A LUIS FERIOS ALEJADIOS DE LA MAQUINA HEF-CHLININ WARF

Name & Internet Constraint. Fair the Internet's repair enforcement profess Responses contract of fair and response of resources.

Care in contrast of incident lines are

INCAS MACHINE th of traces to feesare. To their http://www.ethentec.institute registragional control of a reserving had metacher Menal Below Using al and follow all exertings contactions, Tar internet prior to use duce the edit of inputs from my parts, anytig before the extent of experime ¢ ALC: UNIT id of personal loping them likeline scalar the age of 15 may Tone displace. cips wigh for the baselinul come to a complete stop ig of and

Prochostor la risgon de Uniconstituire ana plécie de resonancese, "Désarchest anal de réalizar l'articularie; Pour limiter in trainer de cher electroque l'édicacione de como de technique de trainer formation ATTENTION Report do Manual, Salarias nations de mans de 13 anis à deserve de la registre. Alternées fanginais la lagris Cardine compiléerment au de reportedes carde fanisies um gebier verst grand aller de de terminari

a sign today in advertised as alternatives (a, eff of the data de fact di consumer, addressign hat successed attenued at artest Avantificationettes der fass im ansettenserent all diesettes etc. misse aus der Polyagenerent gesehl publik misse aus aus der Beschlichtungsgerigentes 4..... ette oprozente Propie mentanza et ette opporten innonente post gatanza monorika. Operanzi hude gentan de respecte Parta makach ei mengen die derana selectet a disconschaft antes de Bergelat in digestes HELAUCON. Nonspo de la comercia paramentales. Napolaregia a las telefos mentenes de 15 años lagos de la malagona

Nergel & Announces of An operation and the interfactory, through interface included of an An object of the second control of the definition of the second control of the second definition of the second second

.....

Especta simmarie a la corsa da comer detanerse por Longités actas de contonual to increasingly and presidents

WARNING AVERTISSEMENT Δ ADVERTENC

Danne eventue ill you fine faint or skop. Arthur Dearths at and true tarthe falle

La spatierten die kunnenfilierten bit für Heispennen santiague pur Per Instanto. Ils services assentat peut estistine des blassens proves, voire la rent 3 vous reus antes folia, archer lonsablatantest pe fore de l'assentes.

Gardier with carps, we obtained at ourse forms physique aucentaires disposit de today pintas


tub use if the machine appears thereaged ent a set i dification of lights ne pai allifar te la martira sardià antierinagia na mattania

Deputy has an experiment in production of the residual

down in ferrantia or El anterio de v ser incommuni. El operativa sanandan quante provenien income prover a la matrix. Il la sacrice delle they in france chartering in such distances in

Maritongo el lossegio, la repara la forma linitat animportus Meno de Italas inspinopor minitas.

ter of highly print the starts of a No utilizer to be maintime powere defaults. a imperatori



DANGER | AVERTISSEMENT | PELIGRO

To avoid risk of electric shock, connect this appliance to a property grounded outlet. DO NOT modify the plug provided with the treadmill. If the plug does not fit the outlet, get a proper outlet installed by a qualified technician.

Pour éviter tout risque de choc électrique, branchez cet appareil eur une prise de courant relide à la terre. NE MODIFIEZ PAS la fiche fournie avec le tapis routant. Si la fiche ne rentre pas dans la prise, faltes installer unen prise adaptée per un éléctricien qualifié.

Para evitar el riengo de descarga eléctrica, conecta este aparato a una toma de corriente adecuadamente conectada a Sens. NO MODIFIQUE el enchule que viene con la camindadora. Si el enchute no encaja en el tomacorriente, comunicate con un electricista calificado






Belt Drifting Left or Right Turn Left or Right Adjusting Bolt 1/4 turn clockwise with Allen Wrench until centered.

Courrole dérivant à gauche ou à droite Tournez le boulon de réglage à gauche ou à droite d'un quart de tour dans le sens des alguilles d'une montre avec la clé Allen jusqu'à ce qu'il soit centré.

La correa se desplaza hacia la izquierda o hacia la derecha Gire el perno de ajuste hacia la izquierda o hacia la derecha 1/4 de vuelta en el sentido de las agujas del reloj con una llave Allen hasta que esté centrado.



EXPLODED DRAWING



EXPLODED DRAWING CHART


NO.	Description	Specification	QTY
1	Bottom frame		1
2	Main frame		1
3	Left upright		1
4	Right upright		1
5	Incline frame		1
6	Console neck frame		1
7	Handlebar frame		1
9	Ezfit linking parts		1
10	Handle grip		1
11	Allen truss head half thread bolt half thread	M8×50×20	2
12	Hex lock nut	M8	12
13	Allen half thread bolt	M12×Φ14×35×19	2
14	Allen truss head half thread bolt	M8×35×20	4
15	Allen socket head full thread bolt	M8×75	2
16	Allen socket head full thread bolt	M8×60	1
17	Allen flat head full thread bolt	M6×25	10
18	Phillips truss head full thread bolt	M5×10	4
19	Phillips truss head full thread bolt	M4×10	10
20	Phillips flat head self-tapping screw	ST4×15	18
21	Phillips truss head self-tapping screw	ST4×16	10
22	Phillips flat head self-tapping screw	ST3×10	2
23	Allen truss head half thread bolt	M8×40×20	2
24	Hex lock nut	M10	3
25	Allen truss head half thread bolt	M10×65×20	1
26	Allen truss head full thread bolt	M8×25	4
27	Allen socket head full thread bolt	M8×35	8
28	Phillips truss head self-tapping screw	ST4×10	14
29	Phillips truss head self-tapping screw	ST4×12	24
30	Allen pan head full thread bolt	M6×25	4
31	Allen socket head full thread bolt	M8×45	2
32	Allen flat head full thread bolt	M8×25	8
34	Allen truss head half thread bolt	M10×35×20	3
35	Flat washer	Ф8	14
36	Flat washer	Ф10	4
37	Foot pad		4
38	Front wheel		2
39	Powder metallurgy sleeve		2
41	Controller		1
42	Choke		1
43	Filter		1
44	Power adaptor		1
45	Front roller		1
46	Rear roller		1
47	Running deck		1
48	Running belt		1
49	Motor cover		1
50	Front motor cover		1
51	Rear cover		1
52	Foot rail		2

53 Side cover 2 54 LED strip bousing 2 55 LED strip 2 56 Choke/filter bracket 1 57 Rear wheel 2 68 Motor bett 1 59 Cushion 1 4 60 Brushiess motor 1 61 Incline motor 1 63 Reset Switch 1 64 Power switch 1 65 Left PU handlebar 1 66 Right PU handlebar cover 1 67 Left outer handlebar cover 1 68 Right outer handlebar cover 1 70 Right inner handlebar cover 1 71 Upper dashboard cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 77 Lower tray cover 1					
55 LED strip 2 56 Choke/filter bracket 1 57 Rear wheel 2 58 Motor belt 1 59 Cushion 1 4 60 Brushless motor 1 61 Incline motor 1 62 Power switch 1 63 Reset Switch 1 64 Power cable buckle 1 67 Left PU handlebar 1 68 Left IPU handlebar cover 1 68 Left ulter handlebar cover 1 69 Right uner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 80 Seed handle pulse 1 81 Incline handle pulse 1 80 Gosee handle pulse 1	53	Side cover		2	
26 Choke/filter bracket 1 57 Rear wheel 2 58 Motor belt 1 59 Cushion 1 4 60 Brushless motor 1 61 Incline motor 1 62 Power switch 1 63 Reset Switch 1 64 Power cable buckle 1 65 Left PU handlebar 1 66 Right PU handlebar cover 1 67 Left outer handlebar cover 1 68 Left inner handlebar cover 1 71 Upper dashboard cover 1 72 Lower dashboard cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 84 Speed handle pulse 1 85 Main communication wire 1 86 Power communication wire	54	LED strip housing		2	
57 Rear wheel 2 58 Motor bett 1 59 Cushion 1 4 60 Brushless motor 1 61 Incline motor 1 62 Power switch 1 63 Reset Switch 1 64 Power cable buckle 1 65 Left PU handlebar 1 66 Right PU handlebar cover 1 67 Left outer handlebar cover 1 68 Left inner handlebar cover 1 70 Right inner handlebar cover 1 71 Upper dashboard cover 1 72 Lower tray cover 1 73 Lower tay cover 1 74 Upper dashboard cover 1 75 Lower tay cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 83 Bower communication wire 1 <	55	LED strip		2	
58 Motor belt 1 59 Cushion 1 4 60 Brushless motor 1 61 Incidine motor 1 62 Power switch 1 63 Reset Switch 1 64 Power cable buckle 1 65 Left PU handlebar 1 66 Right PU handlebar cover 1 67 Left outer handlebar cover 1 68 Left inner handlebar cover 1 70 Right inner handlebar cover 1 71 Upper dashboard cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power comm	56	Choke/filter bracket		1	
59 Cushion 1 4 60 Brushless motor 1 61 Incline motor 1 62 Power switch 1 63 Reset Switch 1 64 Power cable buckle 1 65 Left PU handlebar 1 66 Right PU handlebar cover 1 67 Left outer handlebar cover 1 68 Right nuer handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower dashboard cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 87 Power communication wire 1 88 Power communication wire 1 90 Side rail guider<	57	Rear wheel		2	
Bushless motor 1 60 Bushless motor 1 61 Incline motor 1 62 Power switch 1 63 Reset Switch 1 64 Power cable buckle 1 65 Left PU handlebar 1 66 Right PU handlebar cover 1 67 Left outer handlebar cover 1 68 Right nuer handlebar cover 1 69 Right outer handlebar cover 1 70 Right nuer handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 73 Lower tashboard cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 86 Safety key so	58	Motor belt		1	
01 Incline motor 1 02 Power switch 1 03 Reset Switch 1 04 Power cable buckle 1 05 Left PU handlebar 1 06 Right PU handlebar cover 1 07 Left outer handlebar cover 1 08 Left inner handlebar cover 1 07 Right outer handlebar cover 1 170 Right inner handlebar cover 1 171 Upper tray cover 1 172 Lower tray cover 1 173 Lower dashboard cover 1 174 Upper tray cover 1 175 Lower dashboard cover 1 181 Incline handle pulse 1 82 Vper communication wire (main frame+upright) 1 88 Power communication wire 1 91 Power communication wire 1 92 Plastic flat pad 8 93 Safety key socket 1	59	Cushion 1		4	
62 Power switch 1 63 Reset Switch 1 64 Power cable buckle 1 65 Left PU handlebar 1 66 Right PU handlebar 1 67 Left outer handlebar cover 1 68 Right outer handlebar cover 1 70 Right outer handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Speed handle pulse 1 83 Speed handle pulse 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 90 Power communication wire 1 91 Power communication wire 1 1	60	Brushless motor		1	
63 Reset Switch 1 63 Power cable buckle 1 65 Left PU handlebar 1 66 Right PU handlebar 1 67 Left outer handlebar cover 1 68 Right PU handlebar cover 1 69 Right outer handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 87 Power communication wire 1 88 Power communication wire 1 90 Side rail guider 166 91 Power cable buckle 3 92 Plastic flat pad 8 93	61	Incline motor		1	
64 Power cable buckle 1 65 Left PU handlebar 1 66 Right PU handlebar 1 67 Left outer handlebar cover 1 68 Left inner handlebar cover 1 69 Right outer handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 73 Lower dashboard cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire 1 86 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 1 93 Safety key 1 94	62	Power switch		1	
65 Left PU handlebar 1 66 Right PU handlebar cover 1 67 Left inner handlebar cover 1 68 Left inner handlebar cover 1 69 Right outer handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 1 93 Safety key 1 94 Safety key 1 95 LED display 1 96	63	Reset Switch		1	
66 Right PU handlebar 1 67 Left outer handlebar cover 1 68 Left inner handlebar cover 1 69 Right outer handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 9	64	Power cable buckle		1	
67 Left outer handlebar cover 1 68 Left inner handlebar cover 1 69 Right inner handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 98 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 1 93 Safety key 1 94 Safety key socket 1 95 LED display 1 94 Safety key socket 1	65	Left PU handlebar		1	
68 Left inner handlebar cover 1 69 Right outer handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 87 Power communication wire (main frame+upright) 1 88 Power communication wire 1 89 Power communication wire 1 91 Power communication wire 1 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED communication wire 1 96 Outer expansion pipe 1 97 Inner expansion pipe 1	66	Right PU handlebar		1	
69 Right outer handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 1 90 Side rail guider 1 91 Power communication wire 1 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 96	67	Left outer handlebar cover		1	
To Right inner handlebar cover 1 70 Right inner handlebar cover 1 71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 96 Outer expansion pipe 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99	68	Left inner handlebar cover		1	
71 Upper tray cover 1 72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 1 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED communication wire (main frame+upright) 1 100 Power cord 1 1101 Main communication wire (console) 1	69	Right outer handlebar cover		1	
72 Lower tray cover 1 74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 90 Side rail guider 166 91 Power communication wire 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 97 Inner expansion pipe 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (console) 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1	70	Right inner handlebar cover		1	
74 Upper dashboard cover 1 75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 96 LED communication wire (main frame+upright) 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (console) 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1 103 Cushion1 2 2	71	Upper tray cover		1	
75 Lower dashboard cover 1 76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 89 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (console) 1 100 Power cord 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1	72	Lower tray cover		1	
76 Console neck cover 1 81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 89 Power communication wire 1 90 Side rail guider 16 91 Power communication wire 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (console) 1 100 Power cord 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1 103 Cushion1 2 2	74	Upper dashboard cover		1	
81 Incline handle pulse 1 82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 90 Side rail guider 1 90 Side rail guider 16 91 Power cable buckle 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (main frame+upright) 1 100 Power cord 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1 103 Cushion1 2 2 104 Cushion1 3 2 1	75	Lower dashboard cover		1	
82 Cylinder 1 84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 89 Power communication wire 1 90 Side rail guider 1 90 Side rail guider 3 91 Power colle buckle 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (main frame+upright) 1 100 Power cord 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1 103 Cushion1 2 2 104 Cushion1 3 2 <t< td=""><td>76</td><td>Console neck cover</td><td></td><td>1</td></t<>	76	Console neck cover		1	
84 Speed handle pulse 1 85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 89 Power communication wire 1 90 Side rail guider 16 91 Power cable buckle 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 96 Uter expansion pipe 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (console) 1 100 Power cord 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1 103 Cushion1 3 2 104 Cushion1 3 2 107 Power connection wire 1	81	Incline handle pulse		1	
85 Main communication wire (main frame+upright) 1 87 Power communication wire 1 88 Power communication wire 1 89 Power communication wire 1 90 Side rail guider 16 91 Power cable buckle 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (console) 1 100 Power cord 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1 103 Cushion1 2 2 104 Cushion1 3 2 107 Power connection wire 1 108 Handle pulse wire 1 111 Display bracket 1 112 Allen truss head bolt M8×40 2 <td< td=""><td>82</td><td>Cylinder</td><td></td><td>1</td></td<>	82	Cylinder		1	
87Power communication wire188Power communication wire190Side rail guider1691Power cable buckle392Plastic flat pad893Safety key194Safety key socket195LED display197Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1110Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15	84	Speed handle pulse		1	
Bit Power communication wire 1 88 Power communication wire 1 90 Side rail guider 16 91 Power cable buckle 3 92 Plastic flat pad 8 93 Safety key 1 94 Safety key socket 1 95 LED display 1 97 Inner expansion pipe 1 98 Outer expansion pipe 1 99 LED communication wire (main frame+upright) 1 100 Power cord 1 101 Main communication wire (console) 1 102 LED communication wire (console) 1 103 Cushion1 2 2 104 Cushion1 3 2 107 Power connection wire 1 109 Handle pulse wire 1 111 Display bracket 1 112 Allen truss head bolt M8×40 2 113 Allen truss head full thread bolt M8×15 <td>85</td> <td>Main communication wire (main frame+upright)</td> <td></td> <td>1</td>	85	Main communication wire (main frame+upright)		1	
89Power communication wire190Side rail guider1691Power cable buckle392Plastic flat pad893Safety key194Safety key socket195LED display197Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15	87	Power communication wire		1	
00Side rail guider1691Power cable buckle392Plastic flat pad893Safety key194Safety key socket195LED display197Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15	88	Power communication wire		1	
91Power cable buckle392Plastic flat pad893Safety key194Safety key socket195LED display197Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15	89	Power communication wire			
92Plastic flat pad893Safety key194Safety key socket195LED display197Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×402113Allen truss head full thread boltM8×154	90	Side rail guider		16	
93Safety key194Safety key socket195LED display197Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×4013Allen truss head full thread boltM8×15	91	Power cable buckle		3	
94Safety key socket195LED display197Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15	92	Plastic flat pad		8	
95LED display197Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15	93	Safety key		1	
97Inner expansion pipe198Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15	94	Safety key socket		1	
98Outer expansion pipe199LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×402113Allen truss head full thread boltM8×154	95	LED display		1	
99LED communication wire (main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15	97	Inner expansion pipe		1	
99(main frame+upright)1100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×402113Allen truss head full thread boltM8×154	98	Outer expansion pipe		1	
Image (main frame+upright)Image (main frame+upright)100Power cord1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×402113Allen truss head full thread boltM8×154	99			1	
100Main communication wire (console)1101Main communication wire (console)1102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×402113Allen truss head full thread boltM8×154					
102LED communication wire (console)1103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×402113Allen truss head full thread boltM8×154					
103Cushion1 22104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15					
104Cushion1 32107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15					
107Power connection wire1109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15					
109Handle pulse wire1111Display bracket1112Allen truss head boltM8×40113Allen truss head full thread boltM8×15					
111Display bracket1112Allen truss head boltM8×402113Allen truss head full thread boltM8×154					
112Allen truss head boltM8×402113Allen truss head full thread boltM8×154					
113 Allen truss head full thread bolt M8×15 4			M9×40		
	114			· ·	

115	main communication wire (dashboard)	1
116	LED communication wire (dashboard)	1
117	Pedal lever	1
118	Wireless charging pad	1
119	Motor fixed plate A	1
120	Motor fixed plate B	1


NOTE: We reserve the right to amend the product without prior notice.

TREADMILL STRUCTURE




NOTE: WE RESERVE THE RIGHT TO AMEND THE PRODUCT WITHOUT PRIOR NOTICE.


Packing parts




Main frame



Tray and handlebar





LED display




Silicone oil bottle








Handgrip dashboard




Hardware kit








L-shaped wrench 5×30×80




T-shaped wrench 6×80 Cross open wrench 14 x 17 x 75



Allen socket head full thread bolt


M8×35 6PCS

Allen socket head full thread bolt M8×45 2PCS



Allen flat head full thread bolt M8×25 8PCS

Main parts









Incline motor

Front roller


Rear cover

ASSEMBLY INSTRUCTION


Note: Do not plug in power socket before installation completes; Do not remove bands securing running deck to main frame until treadmill is in desired assembly location. Doing so could result in injury.



Step 1: Take out the main frame and display from box and put it on the flat floor (As shown). The uprights are attached to the main frame already, only lift both uprights up and lock 6 M8x35 Allen socket head full thread bolt, but don't tighten them.



Step 2: Connect the two communication wires between console frame and upright, then put the console frame onto the upright by 8 M8 x 25 Allen flat head full thread bolt, but don't tighten them.



Step3: the LED display is pre-assembled with dashboard. Connect the communication wire, insert the handgrip dashboard into the console frame with 2ea M8 x 45 Allen

GENERAL FITNESS TIPS

Warm-Up

Do some warm-up for at least 5 to 10 minutes before every exercise.

Breathe

Make sure you breathe regularly, properly and calmly when exercising.

Exercise Frequency

It should have 48 hours of rest for the same muscles.

Load

Do exercise as per your own condition, can enhance

exercise force step by step .In the beginning ,it's normal

to get aching pain of muscles. This pain can be removed

in the late phase.

Relax

Remember to have some relax at least 5 minutes to do some stretch after running.

Drink and Meal


Start running on the treadmill after 1 hour of your meal.

And you can start your meal after half an hour of

finishing exercise. Drink less water and no large drink when running.

Stretching Exercises

A successful exercise session begins with warming up exercises and ends with exercises for cooling down and relaxing. These warming up exercises prepare your body for the subsequent demands made upon it. The cooling down / relaxation period after the exercise session ensures that you do not experience any muscular



problems. In the following you will find stretching exercise instructions for warming up and cooling down. Please pay attention to the following points:

1. TOUCH TOES

Bend your trunk slowly forwards and try to touch your feet with your hands. Reach down as far as possible to your toes. Maintain this position for 10-15 seconds if possible and relax. Repeat three times. See pic.1

2. EXERCISES FOR THE KNEES

Sit on the floor and place your feet in such a way that your knees are facing outwards. Pull you 10-15 seconds if possible. Repeat three times for each leg . See pic.2

3. EXERCISES FOR THE CALVES/ACHILLES TENDON

Place both hands on the wall and support your full body weight. Then move your left leg backwards and alternate it with your right leg. This stretches the back of the leg. Maintain this position for 10-15 seconds if possible. Repeat this exercise 2 times for each leg. See pic.3

4. EXERCISES FOR THE UPPER THIGH

Support yourself by placing your hand on the wall, then reach down behind you and lift up your right or left foot as close to your buttocks as possible. Feel a comfortable tension in your front upper thigh. Maintain this position for 10-15 seconds if possible and repeat this exercise 2 times for each leg. See pic.4

5. INSIDE UPPER THIGH

Sit on the floor and stretch out your right leg. Bend your left leg and place your foot on your right upper thigh. Now try to reach your right foot with your right arm. Maintain this position for 10-15 seconds if possible. Repeat this exercise 3 times for each leg. See pic.5

CONSOLE KEYPRESS INSTRUCTION



LED panel display



Incline fast key

Speed fast key

Metrics Incline: 0-15 TIME: 0:00-99.59 PULSE: 0-999 CALORIES: 0-999 SPEED: 0.6-12.5MPH (1.0-20.00 KMH) DISTANCE: 0-99.9 Incline fast key: level 2/4/6/8 Speed fast key: 2/4/6/8 mph (equals 3.2/6.4/9.6/12.8kmh)

Dashboard keypress

Mode

Program

Stop/ Pause Start



When not connected to Echelon APPs, the LED treadmill can be operated by itself

with built-in program and mode: **Program**:P1-P10 built-in programs for selection by press this button; **Mode**: Press mode key to switch among time, distance and calories to input the target.

Start key: At standby mode without pressing Program or Mode key, Press start key to start to run;


Stop key: when the treadmill runs, press this key to pause the treadmill; press and hold this key to stop the treadmill; at standby, press this key to reset.

Change mph and kmh: unplug the safety key, press and hold program and mode key at the same time for 3 seconds, the program switches its unit and then reboot, the speed window will show its current unit for 1 seconds. E= metric (kmh), I= imperial (mph)

Note: when connected to Echelon APPs by iPad/mobile by Bluetooth, it can select the Echelon run class to operate the treadmill, instead of using the built-in program and mode on treadmill.

Handgrip keypress

incline



Keypress Button instruction with either LED panel, or connected Echelon APPs by Bluetooth:

Power on treadmill, the LED panel light up, you can either workout under LED panel alone, or log-in Echelon APPs, select your desired classes, click Play, the treadmill will start automatically, enjoy the running joy; when the class end, the treadmill will stop automatically. If you wanna start/pause/stop the treadmill, below manual setting will help:

- 1. **Start key**: Press start key, there is 3 beeping for countdown, the treadmill starts with the running belt and Red LED on side rail;
- 2. **Stop key**: Press Stop key, the treadmill pauses, the belt does not run with flash red

and green LED on side rail; Press Start key to restart the treadmill; At pause status, press and hold Stop key, the treadmill stops, the belt does not run with Green LED on foot rail.

- 3. **Incline key:** click ▲, the incline is adding; click ▼, the incline is decreasing (incline range: 0-15), and it will also display in Echelon APPs;
- 4. **Speed key:** click + to add the speed; click to decrease the speed (speed range: 0.6-12.5mph), and it will also display in Echelon APPs.
- 5. **Safety key**: when the safety key is pulled out, the treadmill stops with flash Red LED; when the safety key is inserted, press Start key or click the blue icon resume workout in APPs to restart the treadmill.
- 6. **Hand pulse:** when power on, put both hands on the hand pulse, the heart rate will be displayed on PULSE window in LED; If connected to Echelon APPs, it will show in APPS, and LED on side rail will change color following heart rate zone (Note: This value is not used as medical data, only for workout reference.)
- 7. LED on side rail off: the treadmill goes to sleep mode.
- 8. **Speakers:** It has a pair of speakers over Bluetooth. Connect your player or phone over Bluetooth to the treadmill and play the music.

Below works on Keypress Button instruction by LED treadmill itself, without connecting Echelon APPs:

Target mode

At standby mode, Press Mode key to input training target. The target will count down after the start. Press Mode key to switch among time, distance and calories. Then press UP/DOWN keys of speed or incline to adjust the targets. Once any of the targets, time, distance and calories reach zero, the treadmill will end the work session and stop the motor. Then the treadmill will recover to standby mode. At target mode, anytime press Program key, the treadmill will enter the Program function.

Program

In standby mode, Press Program key to select programs from 1 to 10. The selected program will show at the CALORIES window, the startup incline of the selected program will show at the INCLINE window, and the startup speed of the selected program will show at the SPEED window.

Progr	Segment am	1	2	3	4	5	6	7	8	9	10
P1	SPEED	1.0	3.0	5.0	5.0	5.0	7.0	7.0	7.0	3.0	2.0
	INCLINE	2	2	8	6	6	5	5	6	2	2
P2	SPEED	1.0	3.0	5.0	8.0	5.0	5.0	6.0	8.0	4.0	3.0
ΓZ	INCLINE	3	3	2	2	8	8	4	4	4	4
P3	SPEED	2.0	3.0	7.0	8.0	5.0	5.0	5.0	8.0	4.0	3.0
	INCLINE	1	2	5	7	7	4	4	6	2	2
P4	SPEED	2.0	2.0	5.0	8.0	8.0	8.0	8.0	5.0	3.0	2.0
1 4	INCLINE	3	3	9	9	9	9	9	6	2	2
P5	SPEED	3.0	4.0	8.0	9.0	10.0	10.0	10.0	7.0	4.0	3.0
	INCLINE	2	2	8	6	6	6	6	6	1	1
P6	SPEED	3.0	4.0	6.0	7.0	7.0	7.0	9.0	10.0	5.0	3.0
10	INCLINE	1	8	8	7	7	7	7	5	3	1
P7	SPEED	3.0	4.0	4.0	10.0	4.0	9.0	4.0	11.0	3.0	2.0
	INCLINE	1	1	6	6	6	8	8	10	6	2

Below are the profiles for each program:

P10 -	SPEED INCLINE	3.0 2	5.0 7	9.0 5	10.0 5	6.0 8	6.0 8	9.0 8	6.0 8	11.0 4	3.0 4
	SPEED	3.0	5.0	9.0	10.0	6.0	6.0	9.0	6.0	11.0	3.0
F9	INCLINE	3	6	7	3	8	8	3	8	4	4
P9 -	SPEED	3.0	7.0	10.0	4.0	7.0	11.0	5.0	4.0	12.0	6.0
	INCLINE	3	3	3	7	7	3	3	3	5	5
P8 -	SPEED	3.0	5.0	7.0	9.0	3.0	5.0	7.0	5.0	11.0	5.0

The Program has a 30-minute default countdown time. You may adjust the time by pressing UP and DOWN keys.

If you want to quit Program, press STOP to go back to Quick Start. At Program mode, anytime press Mode key, the treadmill will enter the Target function.

HOW TO USE THE PRODUCT

1, Turn the power on, keep the treadmill at its lowest position without incline and check if normal function.

- 2, Attach the safety key to your clothes by clips.
- 3, Check and ensure proper function and stability before use.
- Don't stand on the running belt to get it started.
- The correct way to start is standing on both side rails with hands on the handle bar.
- After pressing Start key or click Play in the APPs Class, the treadmill is running at the initial speed of 0.6mph (1km/h)
- Press Speed + key to add speed. (1.6-2.2mph which equals 2.5km/h-3.5km/h, is comfortable speed). With both hands on handlebar, step onto the running belt with both feet one after another, and you will soon keep up with the speed of the running belt.

4, After some minutes, the treadmill can speed up by pressing Speed + key, or speed down by pressing speed - key, while holding the hand bar(speed range: 0.6-12.5mph, which equals, 1-20kmh) It can also incline by pressing Incline \blacktriangle key, or decline by pressing incline \blacktriangledown key (incline range: 0-15 level).

5, Press Stop key to stop the treadmill immediately, or wait the class ends and the treadmill stops automatically. Press stop key the 1st time for pause; at Pause status, hold and press the key again to stop.

6, Heart rate testing: After the treadmill is powered on, hold your hands on the hand pulse, then you can see HRC value on the display window. (Note: This value is not used as medical data, only for workout reference.)

HOW TO USE SAFTEY KEY

Put on the safety key; When the safety key connected to treadmill is pulled out, the treadmill will stop and LED shows AA error code. Only when push back the safety key to the treadmill, and press Start key on console again, or click the blue icon Resume

Workout in APPs, the treadmill will run again.



Trouble shooting and maintenance

Treadmill

Item	Reason	Maintenance
	a no power	Plug into socket
Treadmill doesn't	b safety key isn't in the right position	Insert the safety key back to the safety key socket
work	c Open circuit signal system	Check the controller input and signal wire
	d switch off	Place the power switch in the "ON" position.
The running belt	a no enough lubrication	Use the Silicone oil
does not run smoothly.	b running belt too tight	Adjust the running belt tension
Running belt slips	a running belt too loose	Adjust the running belt tension


Console

Item	Reason	Maintenance
	•	Plug into socket, place the power switch in the "ON" position.
	position	Insert the safety key back to the safety key socket
	right, or transformer is defected	Check and connect the transformer correctly, or replace the transformer
	D、Open circuit	Check the system input and output terminal and the communication lines
Stop suddenly	A、Safety key fall off	Insert the safety key back into safety key socket

in a normal state	B、abnormal system	Contact the after-sales team for service
	A、Some buttons are damaged or invalid	Replace the buttons
work	B、All buttons are invalid	1、Replace button board, wires of buttons 2, main board 3 or console
No heart rate data is shown	A、Handle pulse wire isn't assembled well, or handle pulse wire is defected.	Check and connect it well, or replace the handle pulse wire
	B、Console line fault	Replace the console
AA (at all window)	Safety key lost	Plug the safety key back
A1		 Check if good connection between lower con- troller and console, and each pin is properly in serted.
(at TIME window)	lower control board connection fails.	2. Check if any damage cables between lower controller and console, change the cables
		3. Change lower controller or console if above cannot solve
A2		 Use volt meter to check whether the power supply voltage is lower than 50% of the norma voltage
(at TIME Window)	explosion-proof protection	 Check if connecting motor, and reconnect the motor cable. Check if odor from controller, and change the
		controller.
A3		1. Check if speed sensor correct installation
(at TIME window)	Abnormal speed sensor	 Check if speed sensor in good contact, if wire in good condition
		3. Change the speed sensor
A4 (at TIME window)	Abnormal incline motor	 Run the incline motor calibration: Unplug the safety key, then hold the STOP key for 3sec- onds to enter incline calibration. Plug the safe key again, the incline will return to zero after calibration completes.
		 If still error code, check if the wire is proper connection Change the incline motor
A5 (at TIME window)	Over current	 Power off for 20seconds, then power on If still error code, check if roller proper function check if the running belt and deck good lubri- cated Change the controller

Using instruction:

Treadmill folding and moving:



1、Folding

2、Unfolding

1. When unfolding the treadmill, you should choose one place where around 1m away from the power socket, and the ground is flat without any barriers.

3, moving

First you need be sure following things before moving:

- 1: the power is off;
- 2: the plug has been pulled out from the socket;
- 3: the treadmill has been folded;

Then you can catch the end of treadmill with one hand, and catch the handlebar at the same side with another hand, tilt 30~40° up to chest to move the treadmill slowly.

TREADMILL MAINTENANCE

Proper maintenance is very important to ensure a faultless and operational condition of the treadmill. Improper maintenance can cause damage to the treadmill or shorten the life of the product. All parts of the treadmill shall be checked and tightened regularly. Worn out parts must be replaced immediately.

Lubrication

After the running belt has been used for a period of time, it must be lubricated with the configured methyl silicone oil. Suggestion:

Using time less than 3 hours every week Using time equal to 4-7 hours every week

Using time more than 7 hours every week proper lubrication.

How to check if the running belt need lubrication: You can lift up the running belt and touch the middle of back of running belt. If your hands are stained with silicone oil (something damp), it means no need more silicone oil .

lubrication once every 5 months

- lubrication once every 2 months
- lubrication once every month
- No excessive lubrication. Note: the important factor of increase the lifetime for treadmill is

How to lubricate the belt:

Step 1: Stop the running belt, and fold the treadmill. Step 2: Lift up the running belt from the back of main frame and put the silicone oil bottle as far as to middle of the belt, spray silicone oil starting from the middle of running belt then to two sides.

Step 3: Unfold the treadmill and run the treadmill at a speed of 1km/h to apply silicone evenly, tread lightly on the running belt from left to right for several minutes to let belt absorb the silicon spray.

Cleaning

Regular cleaning of the running belt ensures a long product life. Warning: The treadmill shall be turned off to avoid electrical shocks. The power cord shall be pulled out of the socket, before starting the cleaning or maintenance.

• After training: Wipe the console and other surfaces with a clean soft and damp cloth to remove sweat residues.


Caution: Do not use any abrasives or solvents. To avoid damage to the console, keep any liquids away. Do not expose the console to direct sunlight.


 Weekly: To make the cleaning easier it is recommended to use a mat for the treadmill. mat under the treadmill once a week. the power cord is unplugged from the electric socket.

Running belt tension adjustment

All running belts are properly set at the factory and after assembly. However, after a period of use, loose belt may occur, and the user might feel pause or slipping belt. Adjust the running belt tension by turning left and right adjusting bolt 1/4 turn clockwise with Allen Wrench until proper tension.


Proper running belt tension is important, if loose belt, the running belt and the roller will slip in turn. But too tight, it increase the load of the motor and damage the motor, running belt and roller, etc.






Shoes can leave dirt on the running belt that can fall beneath the treadmill. Clean the

Storage: Store your treadmill in a clean and dry environment. Ensure power off and



Running belt deviation adjustment:

All running belts are properly set at the factory and after assembly. However, after a period of use, belt deviation might occur. The reasons might be as follows. ① The treadmill is not placed in level surface. 2 The user don't run in the center of the running belt. ③ The user don't apply even force on both feet. When this deviation occurs, the running belt can run several minutes without load, to return to normal. But if not, turning left or right adjusting bolt 1/4 turn clockwise with Allen Wrench until centered.



for left deviation,


Adjust the left bolt clockwise or the right bolt anti-clockwise.

KEY POINT:

-Clockwise means tighten. -Anti-clockwise means loosen. -Running belt will shift to the loose side.

①If the running belt shifts to the left, that means the left side is too loose. Adjust the left bolt clockwise to make the left tighter. Or adjust the right screw anti-clockwise to make the right looser. 2 If the running belt shifts to the right, that means the right side is too loose.

Adjust the right bolt clockwise to make the right tighter Or adjust the left screw anti-clockwise to make the left looser.



For right deviation. adjust the right bolt clockwise or the left bolt anti-clockwise.

Attention:

-You need to start the treadmill (let the belt run) at a low speed before you adjust the running belt.

-When you adjust the bolt, don't rotate it too much. -After each adjustment you need to look for the changes in the running belt. Running belt deviation is not covered by the warranty, and is mainly maintained by users according to the instructions. Running deviation can seriously damage the running belt. It must be found and corrected in time.

Customer Service

Echelon Fitness Multimedia 605 Chestnut St. | Suite 700 | Chattanooga TN 37450

Questions or Concerns

Our members are our priority! If you require assistance or have concerns, please contact our customer service team.

(423) 455-8989

cs@echelonfit.com

Submit a Request:

