



P.O.Box 303

Joensuunkatu 7

FIN-24101 SALO, FINLAND

Tel. +358 71 800 8000

Fax. +358 71 80 44122

# Test Setup photos for RM-1104 **SAR Compliance Test Report**

SAR\_Photo\_RM-1104\_06 2015-09-10 Test report no.: Date of report: **Template version:** 20.0 Number of pages: 7 Microsoft

TCC Microsoft Salo Laboratory **Testing laboratory:** Client:

P.O.Box 303 Joensuunkatu 7E

FIN-24101 SALO, FINLAND Tel. +358 71 800 8000 Fax. +358 71 80 44122

Juha-Matti Varjonen

Jari Rontu **Product contact** person:

Responsible test engineer:

**Measurements made** by:

J-P Karppanen, Marko Laaksonen, Eva Lehtinen, Jesse Louhola, Teuvo Miettinen, Sami Savela, Jani Tuomela, J-M Varjonen

**Tested device:** 

RM-1104, HW: 2012. RM-1118, HW: 2060

FCC ID: **PYASTT** IC: 661X-STT

**Supplement reports:** FCC\_RM-1104\_05

Testing has been carried out in accordance with:

47CFR §2.1093

Radiofrequency Radiation Exposure Evaluation: Portable Devices

FCC published RF exposure KDB procedures

RSS-102, Issue 5

Evaluation Procedure for Mobile and Portable Radio Transmitters with Respect to Health Canada's Safety Code 6 for Exposure of Humans to Radio Frequency Fields

IEEE 1528 - 2013

IEEE Recommended Practice for Determining the Peak Spatial-Average Specific Absorption Rate (SAR) in the Human Head from Wireless Communications Devices:

Measurement Technique

**Documentation:** The documentation of the testing performed on the tested devices is archived for 15 years

at TCC Microsoft.

**Test results:** The tested device complies with the requirements in respect of all parameters

subject to the test. The test results and statements relate only to the items tested. The test report shall not be reproduced except in full, without written approval of the

laboratory.

**Date and signatures:** 

For the contents:





# CONTENTS

1.	PICT	URE OF THE DEVICE	3
2.	TEST	POSITIONS	4
	2.1	AGAINST PHANTOM HEAD	4
	2.2	BODY-WORN 15 MM CONFIGURATION	4
	2.3	Wireless Router 10 mm Configuration	5
3.	DESC	CRIPTION OF THE ANTENNA	7





## 1. PICTURE OF THE DEVICE







#### 2. TEST POSITIONS

## 2.1 Against Phantom Head

Measurements were made in "cheek" and "tilt" positions on both the left hand and right hand sides of the phantom.

The positions used in the measurements were according to IEEE 1528 "IEEE Recommended Practice for Determining the Peak Spatial-Average Specific Absorption Rate (SAR) in the Human Head from Wireless Communications Devices: Measurement Techniques".



Photo of the Device in "Cheek" position



Photo of the Device in "Tilt" position

## 2.2 Body-worn 15 mm Configuration

The device was placed in the SPEAG holder using the Microsoft spacer and placed below the flat phantom. The distance between the device and the phantom was kept at the separation distance indicated in the photo below using a separate flat spacer that was removed before the start of the measurements. The device was oriented with both sides facing the phantom to find the highest results.



Photo of the device positioned for Body SAR measurement.

The spacer was removed for the tests.

Microsoft Body-worn accessories are commonly available for the separation distance used in this testing.





### 2.3 Wireless Router 10 mm Configuration

The device was placed in the SPEAG holder using the Microsoft spacer and, in sequence, the back, display and each of the 4 edges was positioned 10 mm away from the flat phantom. The spacer was removed before the start of the measurements.



Photo of the device positioned for WR mode measurement –back facing phantom.

The spacer was removed before the start of the measurements.



Photo of the device positioned for WR mode measurement – display facing phantom.

The spacer was removed before the start of the measurements.



Photo of the device positioned for WR mode measurement – top edge facing phantom. The spacer was removed before the start of the measurements.







Photo of the device positioned for WR mode measurement – bottom edge facing phantom.

The spacer was removed before the start of the measurements.



Photo of the device positioned for WR mode measurement – left edge facing phantom.

The spacer was removed before the start of the measurements.



Photo of the device positioned for WR mode measurement – right edge facing phantom.

The spacer was removed before the start of the measurements





#### 3. DESCRIPTION OF THE ANTENNA

The device has 2 separate internal antennas for cellular, AWS and PCS use. The cellular antennas are located at left bottom and at right bottom underneath the back cover. Additionally, the device has 2 separate internal antennas for WLAN use. The main WLAN antenna for 2.4 and 5 GHz is located at right top of the device. The secondary WLAN antenna for 2.4GHz is located at left bottom edge, and the secondary WLAN antenna for 5 GHz is located at top edge beside the WLAN main antenna.

# Phone outside dimensions and distance between radiators for Main antennas, BT/Wifi

