

# 说明书

## 工艺:装订

## 材质:80克哑粉

## 尺寸:129\*129mm

## 颜色:单黑印刷



Hereby, TECNO MOBILE LIMITED Declares that this Smart Watch is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.

**CAUTION:**  
 1. Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions.  
 - disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;  
 - leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;  
 - a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.  
 2. EUT Temperature: -20°C ~ +60°C (Standalone), 5°C ~ +45°C (with adapter).  
**Frequency Range(RF):**  
 BT: 2402 ~ 2480MHz(TX/RX)  
**Max. Of Transmit power:**  
 BT(EDR): 7.27dBm  
 BLE: 5.37 dBm  
 The full text of the EU declaration of conformity is available at the following internet address:  
<https://www.tecno-mobile.com/declaration/#/>

**FCC Caution:**  
**Labeling requirements.**  
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 (1) This device may not cause harmful interference.  
 (2) This device must accept any interference received, including interference that may cause undesired operation.  
**Information to user.**  
 Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
**Information to the user.**  
 Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
 - Reorient or relocate the receiving antenna.  
 - Increase the separation between the equipment and receiver.  
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 - Consult the dealer or an experienced radio/TV technician for help.  
 Note: This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.  
**RF Exposure Statement**  
 The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Welcome to use the smart watch, high-performance wrist strap smart watch to create a caring fitness experience for you.  
**Equipment maintenance**  
 When taking care of your watch, keep the following tips in mind:  
 1. Clean the watch regularly, especially the inside of the watch, to keep it dry. Adjust the strap tightness to ensure air circulation.  
 2. The wrist worn on the watch should not use excessive skin care products.  
 3. If skin allergies or discomfort occur, please stop wearing.  
**Diagram mainframe of the watch**  
  
**Boot up**  
 Press and hold the side button for 3 seconds or plug in the charging cable to charge.

Download and install the APP:  
 (1) Use mobile phone to scan the QR code and download the APP.  
 (2) The iOS system selects the App store, searches for and downloads My Health, or scans the QR code to download.  
 The Android systems can choose Google Play to download and install My Health, or scan the QR code to download.  
  
 Note: The phone must support Android 8.0 or iOS 11.0 system or above, Bluetooth version 4.0 or above.

**2.APP bound the watch**  
 THERE ARE TWO METHODS

A. Method: Add Device  
 B. Method: Scanning the watch QR code

A. Method: Click on your device in the list of scanned devices  
 B. Method: Bind by scanning the watch QR code

Binding successful

**Phone Call Binding**  
 ① For Android Phones  
 After the APP is successfully bound, the phone will automatically pop up the select the Bluetooth "Watch Pro 2" pairing window, select "Pair" option, as shown below.  
 ② For iOS Mobile Phones  
 After the APP is successfully bound, the phone will automatically pop up the pairing window, select "Pair" option, as shown below.

Android		iOS	
Pop up the select	Binding successful	Pop up the select	Binding successful

Note: Before Phone Call Binding, the CALL BT switch of the watch needs to be on, as shown below:

BT icon and status:  
  
 BT icon means not connected, BT icon with a checkmark means have connected

**Watch function introduction power on status:**  
 Main screen menu interface switching, as shown below the interface, etc.:

**Unbind**  
 1. Android  
 Android phones can be disconnected from the phone by simply tapping Remove Device.  
 2. iOS  
 After the App is unbound, you also need to option the Bluetooth and click the symbol on the right, Select ignore this device in the settings, As shown in the following figure:

**Common problems**  
 1.1 Make sure that the phone Bluetooth is turned on, and the watch is turned on;  
 1.2 When searching for Bluetooth, make sure that the watch has not been bound by other accounts;  
 1.3 When searching for Bluetooth, the watch and the phone should be as close as possible.  
 2. If the user has installed other software such as mobile phone housekeeper in the mobile phone, in order to ensure the normal operation of the background APP, please open the message push and allow the background running permission on the mobile phone, otherwise the message cannot be pushed.  
 3. Charging requirements:  
 Use a charger with a specification of 5V 0.5-1A to charge. If you do not use it for a long time, please be sure to turn off the system and keep the power supply once every month.  
**Disclaimer**  
 Warning: This product is not a medical device, watch and its application should not be used to diagnose, treat or prevent diseases. If you want to change your exercise, sleep and other habits, please be sure to consult a qualified medical professional first to avoid serious casualties. The Company reserves the right to modify and improve any of the functions described in this manual without prior notice, and the Company reserves the right to continuously update the product content, and all content shall be subject to physical objects.

**EU DECLARATION OF CONFORMITY**  
 in accordance with Annex VI of Directive 2014/53/EU of the European Parliament and of the Council  
 1. For the following Radio equipment:  
 Model: WP02  
 Product: Smart Watch  
 Trade name or Brand: TECNO  
 Software / Hardware number: BDCAE0AA/ MA0021.01  
 2. Name and address of the manufacturer or his authorized representative:  
 Manufacturer: TECNO MOBILE LIMITED  
 Address: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19-25 SHAN MEI STREET FOTAN NT HONGKONG  
 3. This declaration of conformity is issued under the sole responsibility of the Manufacturer.  
 4. Object of the declaration (identification of the radio equipment allowing traceability; it may include a colour image of sufficient clarity where necessary for the identification of the radio equipment).  
 5. The object of the declaration described above is in conformity with the relevant Union harmonization legislation: Directive 2014/53/EU (RED)  
 6. References to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared.  
 Article 3.1a Health: EN 62479:2010  
 Article 3.1b Electrical Safety: EN 62368-1:2014(A1):2017  
 EN IEC 62368-1:2020+A11:2020  
 Article 3.1b: ETSI EN 301 489-1 V2.2.3 (2019-11)  
 ETSI EN 301 489-17 V3.2.4 (2020-09)  
 Article 3.2: ETSI EN 300 328 V2.2.2 (2019-07)

7. Notified Body Name: Eurofins Electrical and Electronic Testing NA, Inc.  
 Notified Body Number: 0980  
 Notified Body Assessment Performed: Module B/C on Article 5.1a, 5.1b, 5.2  
 Technical File Identification Number: N/A  
 8. Where applicable, description of accessories and components, including software, which allow the radio equipment to operate as intended and covered by the EU declaration of conformity. User instructions are provided in the User Manual. The Software and Hardware versions are specified above.  
 9. Additional information:  
 Referring to Article 10.2 of the Directive, this equipment is so constructed that it can be operated in all Member States, without infringing applicable requirements on the use of radio spectrum.  
 Referring to Article 10.10 of the Directive, there are no restrictions on putting this equipment into service or of requirements for authorisation of use. Please refer to the User Manual for details.  
 On behalf of:  
 Manufacturer: TECNO MOBILE LIMITED  
 Address: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19-25 SHAN MEI STREET FOTAN NT HONGKONG  
 (Place and date of issue): Shenzhen, 2023-12-12  
 (Name, function): Daozhuang Yang / Manager  
 (signature): Daozhuang Yang  
 (Name and signature of person responsible)

**CUSTOMER SERVICE**  
  

Name:	
Address:	
Tel No:	
Date of purchase: ( dd/mm/aa)	
S/N:	

**TECNO MOBILE LIMITED**  
 TM and ©2019 TECNO Corporation. All rights reserved. Other product and company names mentioned herein may be trademarks or trade names of their respective owners. Specifications are subject to change without notice. Model names and the availability of particular products may vary by region.

**مرحبا بك في دليل استخدام الساعة الذكية، الساعة الذكية بسوار عالي الأداء لتوفير تجربة حياة صحية لا مثيل لها.**  
**ملاحظة:** يرجى قراءة التعليمات بعناية قبل استخدام الساعة الذكية. يرجى قراءة التعليمات بعناية قبل استخدام الساعة الذكية. يرجى قراءة التعليمات بعناية قبل استخدام الساعة الذكية.  
 1. تم اختبار الساعة بدقة عالية من قبل فريقنا المختص. يرجى قراءة التعليمات بعناية قبل استخدامها.  
 2. يجب عدم لمس السوار على المعصم أثناء استخدام مستشعرات الساعة بالسرعة بشكل متكرر.  
 3. في حال حدوث حساسية الجلد أو عدم الراحة يرجى التوقف عن ارتداؤها.  
**رسم توضيحي للهيكل الرئيسي للساعة.**  
**تنظيف الساعة**  
 لمسح الساعة مسطحة على الزر الجانبية لمدة 3 ثوانٍ أو قم بتوصيل كابل الشحن.

تحميل وتثبيت التطبيق:  
 (1) استخدم الهاتف... مسح رمز الاصلحة المرمزة (QR code) وقم بتحميل التطبيق.  
 (2) نظام iOS: قم بإختيار متجر التطبيقات (App Store) البحث وقم بتحميل تطبيق My Health, أو قم مسح رمز الاصلحة المرمزة للتحميل.  
 يمكن لانشطة Android اختيار متجر Google Play لتحميل وتثبيت تطبيق My Health, أو مسح رمز الاصلحة المرمزة للتحميل.  
  
 ملاحظة: يجب أن يكون الهاتف متوافقًا مع نظام Android 8.0 أو iOS 11.0 أو أنظمة أحدث، وإصدار Bluetooth 4.0 أو أحدث.

**2. ربط التطبيق بالساعة**  
 هناك طريقتان

A. الطريقة المباشرة  
 B. الطريقة المباشرة  
 C. الطريقة المباشرة  
 D. الطريقة المباشرة

A. الطريقة المباشرة  
 B. الطريقة المباشرة  
 C. الطريقة المباشرة  
 D. الطريقة المباشرة

**ربط المعلومات الهاتفية**  
 ① بالنسبة لهواتف Android: بعد أن يتم ربط الهاتف بنجاح، سيتم فتح نافذة اختيار الجهاز، حدد خيار "Watch Pro 2".  
 ② بالنسبة لهواتف iOS: بعد أن يتم ربط الهاتف بنجاح، سيتم فتح نافذة اختيار الجهاز، حدد خيار "Pair".  
 هو موضح أدناه:

Android		iOS	
ظهور نافذة الاختيار	تم الربط بنجاح	تم الربط بنجاح	تم الربط بنجاح

**مقدمة وقلق الساعة عند التشغيل:**  
 تبتدل واجهة القلعة الرئيسية على الشاشة الرئيسية، كما هو موضح في الواجهة أدناه، إلخ.

ملاحظة: قبل ربط المعلومات الهاتفية، يجب أن يكون مفتاح CALL BT الخاص في الساعة قيد التشغيل، كما هو موضح أدناه:

**1. نظام Android**  
 يمكن فصل هواتف Android عن الهاتف ببساطة عن طريق النقر فقط على أيقونة الجهاز.

**2. نظام iOS**  
 بعد إلغاء ربط الساعة يجب أيضًا تعطيل البلوتوث والنقر على الرمز على اليمين ثم اختيار التعامل هنا الجانبي في الإعدادات كما هو موضح في الشكل التالي.

**Добро пожаловать к использованию смарт-часов, высокопроизводительных смарт-часов с ремешком на запястье, обеспечивающих для заботы о физическом состоянии для вас.**  
**Техническое обслуживание оборудования**  
 При работе с вашим часам, имейте в виду следующие советы:  
 1. Регулярно чистите часы, особенно внутреннюю часть, чтобы они оставались сухими. Регулируйте тугомота ремешка, чтобы обеспечить циркуляцию воздуха.  
 2. На носке подтягивайте ремешок часов, не следует использовать избыточные средства по уходу за кожей.  
 3. При возникновении аллергии или дискомфорта на коже прекратите ношение.  
**Схема корпуса умных часов**  
  
**Загрузка**  
 Нажмите и удерживайте боковую кнопку в течение 3 секунд или подключите кабель для зарядки.

**Отвязать**  
 1. Android  
 Телефоны Android можно отключить от телефона простым нажатием Удалить устройство.  
 2. iOS  
 После того, как приложение будет отключено, вам также нужно включить Bluetooth и нажать на символ справа, выбрать Игнорировать это устройство в настройках, как показано на следующем рисунке.

**Загрузите и установите приложение:**  
 (1) С помощью мобильного телефона отсканируйте код QR и загрузите приложение.  
 (2) Система iOS выберает App Store, выполните поиск и загрузку My Health или сканируйте код QR для загрузки.  
 Система Android может выбрать Google Play для загрузки и установку My Health или отсканируйте QR-код для загрузки.  
  
 Примечание: Телефон должен поддерживать систему Android 11.0 или iOS 9.0 или выше, Bluetooth версии 4.0 или выше.

**2.APP привязал часы**  
 СУЩЕСТВУЕТ ДВА МЕТОДА

Способ 1: Добавить устройство в список обнаруженных устройств  
 Способ 2: Отсканируйте QR-код на экране часов

Способ 1: Выберите свое устройство в списке обнаруженных устройств  
 Способ 2: Сравните устройство с устройством сопряжения QR-кода на первом экране часов

Сравнение успешно завершено

**Привязка к телефонному номеру**  
 ① Для смартфонов с Android после успешного сопряжения приложения на телефоне автоматически откроется окно выбора сопряжения Bluetooth "Watch Pro 2", выберите опцию "Сопрежение", как показано ниже:  
 ② Для смартфонов с iOS после успешного сопряжения приложения на телефоне автоматически откроется окно сопряжения, выберите опцию "Сопрежение", как показано ниже:

Android		iOS	
Выполнение окна выбора	Сопрежение успешно завершено	Выполнение окна выбора	Сопрежение успешно завершено

**Введение функции просмотра состояния включения питания:**  
 Переключение интерфейса главного экранного меню, как показано ниже интерфейса, и т.д.:

**Примечание:** Перед привязкой телефона вам необходимо включить переключатель вывода BT на часах, как показано на рисунке ниже:

**Значок и статус BT:**  
  
 Указывает, что не подключен, Указывает на подключенный

**2. iOS**  
 После того, как приложение будет отключено, вам также нужно включить Bluetooth и нажать на символ справа, выбрать Игнорировать это устройство в настройках, как показано на следующем рисунке.

**Аккуратный уход за часами.**  
**Экран**  
**Состояние экрана**  
 1. Состояние экрана: для очистки экрана используйте мягкую ткань.  
 2. Состояние экрана: для очистки экрана используйте мягкую ткань.  
 3. Чистка экрана: для очистки экрана используйте мягкую ткань.  
**Состояние экрана**  
  
**Обновление**  
 Нажмите и удерживайте боковую кнопку 3 секунды или подключите кабель для зарядки.

Установите и загрузите:  
 (1) VEYA кодированный тарамак и установку индексом для cep телефону каллан.  
 (2) iOS системы için App Store'da, My Health'i uygulamasını indirin veya QR kodunu taratın.  
 Android sistemleri için Google Play Store üzerinden My Health uygulamasını yükleyebilir veya QR kodunu taratabilirsiniz.  
  
 Not: Telefonun Android 8.0 ve iOS 11.0 sistemi veya üstünü, Bluetooth sürüm 4.0 veya üstünü desteklemesi gerekir.

**2.APP saat bağlantısı**  
 İKİ YÖNTEM VAR

A. Yöntem: Çihaz Ekle  
 B. Yöntem: Çihaz Ekle

A. Yöntem: Tarama  
 B. Yöntem: Tarama

B. Yöntem: Saat VEYA kodunu taramaya başlıyorum

Binding successful

**Telefon Görüşmesi Bağlama**  
 ① Android Telefonlar için Uygulama başarıyla bağlandıktan sonra, telefon otomatik olarak Bluetooth "Watch Pro 2" eşleştirme penceresini seçin, aşağıda gösterildiği gibi "Eşleştir" seçeneğini seçin.  
 ② iOS Cep Telefonları için Uygulama başarıyla bağlandıktan sonra, telefon otomatik olarak eşleştirme penceresini açacaktır, aşağıda gösterildiği gibi "Eşleştir" seçeneğini seçin.

Android		iOS	
Seçimi yap	Bağlama başlandı	Bağlama başlandı	Bağlama başlandı

Not: Telefon Görüşmesi Bağlandıktan önce saatini CALL BT anahtarını aşağıda gösterildiği gibi açık olmalıdır.  
  
 BT simgesi ve durumu:  
  
 Bağlı olmadığı anlamına gelir, Bağlandı anlamına gelir  
**İşlev tanıtımının güç açık durumunu izleyin:**  
 Ana ekran menü arayüzünün değiştirilmesi, aşağıda gösterildiği gibi arayüz vb. Ana ekran menü arayüzünün değiştirilmesi, aşağıda gösterildiği gibi arayüz vb.:

**Bağlantıyı kaldır**  
 1. Android  
 Android telefonları telefona bağlantı yalnızca Çihazı Kaldır'a dokunarak kesilebilir.  
  
 2. iOS  
 Uygulamanın bağlantısını kesildikten sonra, Bluetooth seçeneğini de seçmenize ve sağdaki simgeye tıklayarak gerekir. Ayarlarda Bluetooth'u yok sayı seçeneğini seçin. Aşağıdaki şekilde gösterildiği gibi

www.tecno-mobile.com