
Model.URTM018

# Spacewalk 1 Walking Treadmill

**USER MANUAL** 





IMPORTANT: Read all instructions carefully before using this product. Retain this owner's manual for future reference. The specifications of this product may vary from this photo, subject to change without notice.

#### Manufacturer: Shenzhen Yile Dynamic Technology Co., LTD.

Address: 131, Shahe Xili, 2-2 Xili North Road, Licheng Community, Xili Street, Nanshan District, Shenzhen City, China

Version: 1.0









MADE IN CHINA

# **TABLE OF**CONTENTS

01CUSTOMER SERVICE

02 IMPORTANT SAFETY INSTRUCTIONS

03 SAFETY NOTICE

04 SPECIFICATION

05 PRODUCT AND ACCESSORIES

06 PRODUCT INTRODUCTION

07 INSTALLATION AND STORAGE

08 STATEMENT AND ERROR CODE

09 CARE AND MAINTENANCE

10 WARRANTY

## 1 / CUSTOMER SERVICE

#### IMPORTANT: FOR UREVO ONLY

For damaged or defective product, questions, replacement parts or any other service support, please contact our customer service department by the below methods:

### services@urevosports.com

Response Time: 24-48 hours

Emailing us with the Order ID will be the best method to receive a response during peak business hours.

### Website: www.urevosports.com

PLEASE DO NOT RETURN THIS PRODUCT WITHOUT ASKING OUR CUSTOMER SERVICE.

## 2 / IMPORTANT SAFETY INSTRUCTIONS

#### DANGER - To reduce the risk of electric shock:

1. Always unplug this appliance from the electrical outlet immediately after using and before cleaning.

## WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1. An appliance should never be left unattended plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
- 2.Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- 4. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- 5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- 6. Do not carry this appliance by supply cord or use cord as a handle.

- 7. Keep the cord away from heated surfaces.
- Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair, and the like.
- 9. Never drop or insert any object into any opening.
- 10. Do not use outdoors.
- 11. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 12. Caution To reduce the risk of injury from moving parts Unplug before servicing.
- 13. Warning To reduce the risk of Electric shock Unplug before cleaning or servicing.
- 14. Warning Risk of personal injury Keep children under the age of 13 away from machine.
- 15. To disconnect, turn all controls to the position, then remove plug form outlet.
- 16. Connect this appliance to a properly outlet only. See grounding instructions.
- 17. This appliance is not intended for use by persons with reduces physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning

use of the appliance by a person responsible for their safety. Keep children under the age of 13 away from this machine.

18. The maximum weight capacity for this product is 264.5lbs/120kg. DO NOT EXCEED MAXIMUM WEIGHT CAPACITY.

#### **SAVE THESE INSTRUCTIONS**

#### **GROUNDING INSTRUCTIONS:**

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

DANGER - Improper connection of the equipmentgrounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

#### FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- (3) This device has been evaluated to meet general RF exposure requirement. This device should be installed and operated with minimum distance 20cm between the radiator & your body.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## 3 / SAFETY NOTICE




 ↑ Please keep a rear distance of 100 cm or more.



↑ Please keep a distance of 0.6 meters or more for both sides.



(X) Trampling the treadmill lid is prohibited.




Make sure the treadmill is folded up completely before use.



(X) Using on uneven ground is prohibited.




It is strictly forbidden to walk up and down the walking device while walking. 05







On't fold down when working.



On not storage as stand up.




Be carefully of elderly and pregnant woman use .




Single person walking only.




Do no walking with pets.



Take care clothing or others debris drawn into appliance when working



Please unplug power cord when not in use.



Do not storage as side stand.



On not transverse motion.



Children use MUST be under supervised.




Oo not backward motion.

## 4/SPECIFICATION

Performance indictors	Detailed parameters	Performance indictors	Detailed parameters
Product dimension	1425 × 560 × 1110 mm	Minimum speed	0.6 mph
	56.1×22.1× 43.7 inch		
Walking Area	1200 x 420 mm	Maximum speed	4 mph
	47.24 x 16.54 inch		
Gross weight	35 KG	Rate voltage	110 - 120V ~
	77.2 Lbs		
Net weight	30 KG	Screen size	180 x 62 mm
	66.14 Lbs		7.09 x 2.44 inch
Maximum load	120 KG	Rated power	625W
	264.5 Lbs	Suggested age	14-60 years old


## 5/PRODUCT AND ACCESSORIES

Please carefully check whether the contents of the package are complete and intact. If there is any missing and damage, please contact the seller.



#### Accessories

Hex Tool × 1







User Manual x 1

Quick Start Guide x 1


## 6/PRODUCT INTRODUCTION






## 7 / INSTALLATION AND STORAGE

• Take out appliance from packages.




1. Unbox and take out accessory box.




2. Lift out appliance and place at flat surface.

Attention: 2-3 persons assist is necessary.



Its normal that visible welding marks residual on walking belt.

### • Transportation




1. If transportation needs, unplug power cord and lifting the terminal of appliance.



2. Easy to transport appliance with bottom transportation wheel assists . like as wheelbarrow.


### Fold up appliance



1. Hold handrail and boost up till upright is locked, "Click" sound appear.



2. Take out tablet mount from accessory box and insert it at top rear of upright.




 Plug in power cord and switch on power rock button, you can hear a Bi sound from buzzer, its means the circuit of appliance has connected with power electricity.
Warning: MUST use power cord with comes of package.


## Fold down appliance



1. Power off appliance and unplug power cord before storage process.



 Pull latch to release and folding down upright gradually.
Tips: Push handrail a bit before release latch.





## 8/STATEMENT AND ERROR CODE

### **Standby Mode**

In ready mode, it will switch to "**Standby mode**" automatically in case non-activated console longer than 10 minutes, you're able to weak up console by press any of touch buttons.



### Remote upgrade treadmill

OTA firmware upgrade: you would get upgrade news in Urevo APP, please follow steps to process OTA firmware upgrade.



#### **Error Code**

14

Error Code	Fault Analysis		
E01	Power supply to control module dysfunction	<b>N</b>	
E02	Over current protection		
E04	Motor dysfunction	1,	
E05	Internal communication disconnected or error	•	(E)
E06	Power tube or relay dysfunction		

Not only error code appeared but also built in buzzer alarm, Once error code and alarm happened, you MUST stop workout immediately, Please contact with after sale service if problem CAN NOT be solved after restart.

## 9/CARE AND MAINTENANCE

### A. Symptom: walk belt off centered or slips.




#### Centering walk belt process as follow:

- 1. Make sure App connected.
- 2. Enter "belt centering mode" in App.
- 3. Active this mode in App and power on appliance, the walking belt centering process work at 4km/h speed automatically.
- 4. Observe belt centering progress every 2 minutes.
- 5. Manual as alternative in case Auto belt centering mode is failed:
  - If the walk belt has shifted to the left, use the hex key to turn the left idler roller screw clockwise 1/4 of a turn( refer to figure 2).
  - if the walking belt has shifted to the right, turn the left idler roller screw counterclockwise 1/4 of a turn.( refer to figure 3).
- 6. Appliance MUST work 1-2 minutes Per. each manual centering.
- 7. Exit "belt centering mode" in App if belt is centred or Waiting the whole program completely finished.



#### Belt slip correcting process as follow:

- 1. Power off appliance before operation.
- 2. Using the hex key, turn both idler roller screws clockwise, 1/2 of a turn.
- 3. After corrected, please attempts to walking 1-2 minutes under 1Km/h speed setting, Repeat until the walking belt is properly tightened.



#### **Attentions**

- To prevent any injury, don't place any debris around appliance before maintenance process.
- 2. MUST use associated hex tool.
- 3. Take care at maintenance process. Do not pinch fingers.



### B. Belt lubrication process, follow instruction below to lubricate belt.



1. Power off appliance and unplug cord.

2. Using the hex tool, turn both idler roller screws clockwise till belt loosen and lifting easily.

Tips: please markdown Hex tool rotating cycles when loosen belt, which use for adapting belt tension after lubrication process.

- 3. Lifting edges of belt and spraying lubrication silicone at center of walk platform evenly. Not necessary to apply spray silicone on entire walk platform.
- 4. Lubrication silicone volume Per time of maintenance: 5-10mL Attention: it would causes of belt slip if spray too much.
- 5. Power on appliance and workout few minutes, in order to spread lubrication silicone to whole belt surface evenly.

Attention: please hold handrail when workout at 1km/h setting Lubrication frequency: High recommend 200Km Per time.

## C: Appliance cleaning.



- 1. Power off appliance and unplug power cord before cleaning.
- 2. Wipe and clean with damp cloth, Do not cleaning with acidic or caustic detergents.
- 3. Do not clean opposite of walk belt.
- 4. Its normal few black powders residual under appliance after long working.

# 10/WARRANTY

#### MANUFACTURER'S LIMITED WARRANTY

UREVO warrants to the original purchaser that this product is free from defects in material and workmanship when used for the purpose intended, under the conditions that it has been installed and operated in accordance with UREVO Owner's Manual. UREVO's obligation under this warranty applies to the following:

#### COMPONENT LENGTH OF WARRANTY

Structural Frame 1 year For Home Use Only All Other Components 90 days For Home Use Only

### **Exclusions from Warranty Coverage:**

UREVO does not warrant against and is not responsible for, and no implied warranty shall be deemed to cover, any product failure, product malfunction, or damages attributable to:

- 1.Improper installation and/or failure to abide by UREVO's installation guidelines;
- 2. Use of this product beyond normal home use, or in an application for which it was not designed;
- Cosmetic items such as scratches, dents or discolorations;
- Damage caused by normal wear and tear, vandalism, accidental or by animals;

- 5. Any act of Nature (such as fire, flooding, snow, ice, hurricanes, earthquakes, lightnings or other natural disasters), environmental condition (such as air pollution, mold, mildew, etc.), or staining from foreign substances (such as dirt, grease, oil, etc.);
- Normal weathering due to exposure to sunlight, weather and atmosphere which can cause colored surfaces to among other things, flake, chalk, accumulate dirt or stains.
- 7. Improper operation, alteration, handling, storage, abuse or neglect of the products.

UREVO, using its sole discretion, will either repair or replace free of charge any part(s) proven to be defective under normal home use. Any repair or replacement shall provide no new warranty coverage, but shall retain only the remaining portion of the original product's warranty. This warranty is offered only to the original purchaser and is not transferable. Proof of original purchase is required.

When ordering replacement parts please have the following information ready:

- 1. Order Number
- 2. Description of Parts (Adding photos or videos would be helpful)
- 3. Part Number
- 4. Date of Purchase