

文件名称: Keypad Touch-SMS-EN-2204设计师:WQY完成时间:2022/04/01版本号: V1.0-2204成品尺寸:60*93mm材质和工艺:
128g铜版纸 风琴折更改内容:



备注:红色线框不印刷



Please read this user manual carefully before your device.





List of Components

 Light Sensor
 Status Bar (Unlock Icon, Incicator Light, Lock Icon, Low Battery Icon) NFC Sensor (NFC sensing is valid within



You will need:

A smartphone or tablet using Bluetooth 4.2 or later.

The latest version of our app, downloadable with the App Store or Google Play Store.

A SwitchBot account, you can register via our app or sign in to your account directly if you already have one.

Mease note: if you want to set unjock passcode remotely or receive notifications on your phone, you will need a SwitchBot Hub Mini (sold separately).



1. Remove the battery cover and install the batteries. Make sure the batteries are installed in the right direction. Then put the sure the put the sure the put the sure that the sure

Keep your device away from heat and humidity, and make sure it does not come into contact with fire or water.
 Do not touch or operate this product with week handle.

Do not touch or operate this product with wet hands.
 This product is a precision-based electronic product, please avoid physical damage.
 Do not attempt to disassemble, repair, or modify the product.
 Do not use the product where wireless devices are not allowed.

Installation

Method 1: Install with Screws Before installation you will need:



F Rubber Hammer Screwdriver

Step 2: Determine Drill Bit Size and Drill Holes

Step 1: Confirm Installation Position a mistake were is meler-steed from jour Lock.
Add Keypad Touch following the instructions on the app. After adding successfully, find a suitable position on the well, attach switchBot Keypad Touch to the chosen position with your hands, then check if you can lock and unlock SwitchBot Lock smoothly when using Keypad Touch.

If everything works correctly, place the alignment sticker to the position chosen at mark holes for screws using a pencil.

tonsulting a professional.

Prepare a suitably sized electric drill bit before drilling.

① When installing on more rugged surfaces like concrete or brick:
Use an electric drill with the 6 mm (15/64") sized drill bit to drill holes at the marked positions, then use the rubber hammer to hammer the expansion bolts into the wall.

② When installing on surfaces like wood or

Use an electric drill with the 2.8 mm (7/64") sized drill bit to drill holes at the marked

Step 3: Attach Mounting Plate to the Wall

Affix mounting plate to the wall using screws. Make sure the mounting plate is firmly attached, there should be no exces movement when you press either side.



Step 4: Attach Keypad Touch to Mounting Plate Align the two metal round buttons at the back of Keypad Touch with the two round localing Tolles at the button of mounted plate. Then slide Keypad Touch downward and the step of the step of the step of the own further. Press pe Keypad Touch from different angles using your hands to make sure it is sailed.



Method 2: Install with Adhesive Tape

Step 1: Confirm Installation Position To avoid repeatedly changing positions after installation and causing damage to your wall, we suggest that you add likepad Touch on our app first to see whether you can control the Lock kis Keypad Touch it is installed wi

-Smuor Step 2: Attach Mounting Plate to the Wall

so presert your separal Touch being removed.)
Add your Keypad Touch following the
instructions on our app. After adding
successfully, find a suitable position on the
wall, attach your Keypad Touch to the position
with your hands, then check if you can lock
and unlock SwitchBot Lock smoothly using
Keypad Touch, if so, use pencil to mark
the position.

wall at the marked position. Press the mounting plate against the wall for 2 minutes to ensure it is firm.



Step 3: Attach Keypad Touch to Mounting Plate

Tips: Make sure the mounting plate has been firmly attached to the wall before continuing.

attoried to the will believe contriving.

Align the two metal round buttons at the back of Keypad Touch with the two round locating holes at the bottom of mounting plate. Then slide Keypad Touch downwards along the mounting plate until it can not go any further. Press the Keypad Touch from different angles using your hands to make sure it is stable.





www.switch-bot.com V1.0-2204

Keypad Touch Removal Illustration

Poke the ejection pin into the removal hole with pressure, then pull the Keypad Touch upwards to remove it.



Keypad Touch Removal Alerts

Keypad Touch Removal Alvers

Removal alers will be activated once
Keypad Touch is added to your SwittBot
account. Removal alerts will be triggered
every time your Keypad Touch is removed
from the mounting plate.

Users can remove alerts by entering the
correct passcode, verifying fingerprints or
NFC cards.

Precautions

This product cannot contral your Lock when it runs out the battery. Please check remaining battery via our app or the indicator on the device panel periodically, and makes sure your epiace the battery in time. Remember to bring a key out with you withen the battery is low to prevent being locked outside. Refrain from using this product if an error occurs and contract SwitchBot Customer Service.

Indicator light flashes green reprofit ledicator I gift flashes green stawy then goes off Red battery ton lights up and desice begs toke Green unlock con lights up with a betty with a betty ledicator light thanks red twice and disince begs toked twice and disince begs toked. twice and device beopt vide indicator light flashes red once and welock lock bon flashes once with 2 becas indicator light flashes red twice and panel haddlight flashes brice with 2 beeps Indicator light flashes red and panel baddlight flashes rapitly with continuous beeps Unable to connect to Lock Removal alert

Please visit support switch-bot.com for detailed information.

Device Status Description

Device Status Description

cator light flashes green by to set up Lock successful Wrong passcode encered 5 times

When your device battery is low, a red battery icon will appear and your device will emit a sound prompt indicating low battery every time you wake it up. You will also the Keypad Touch to your SwitchBot Lock again if you find your lost device.

Lost Device

every time you wake it up. You will also receive a notification via our app. Should this happen, please replace batteries as soon as possible.

How to replace batteries: Remove the Keypad Touch from the mounting plate, open the battery cover and insert 2 new CR123A batteries, then attach the keypad Touch back to the mounting plate.

Battery Replacement

Unpairing

If you are not using Keypad Touch, please novigate to the Settings page of the Keypad Touch to unpair it. Once Keypad Touch to unpair it, the the to control our pair wit, the the not have to control our SwitchBot Lock. Please operate with caution.

Should you lose your device, please navigate to the Settings page of the Keypad Touch in question and remove pairing. You can pair

Firmware Upgrades

In order to improve user experience, we will regularly release firmware updates to introduce new functions and solve any software defects that may occur during a solve any experience of effects that may occur during usuable, we will be used an upgrade no explication to your account via our app. When upgrading belose makes user your product has sufficient battery and make sure your smartphone is within range to prevent interference.

Troubleshooting

Specifications Model: W2500020 Color: Black Material: PC + ABS

Size: 112 × 38 × 36 mm (4.4 × 1.5 × 1.4 in.)
Weight: 130 g (4.6 oz.) (with battery)
Battery: 2 CR 1234 batteries
Battery: Life: Approx. 2 years
Usage Environment: Outdoor and Indoor
System Requirements:
US 11+, Android OS 5.0+
Network Connectivity: Bluetooth Low Energy
Consolidor. To promote the second of the control of

Network Connectivity: Bluetooth Loi Operating Temperature: -25 °C to 66 °C (-13 °F to 150 °F) Operating Humidity: 10 % to 90 % RH (noncondensing) IP Ratings: IP65

Disclaimer

Please visit our website or scan the QR code below for more information.

Size: 112 × 38 × 36 mm (4.4 × 1.5 × 1.4 in.)

This product has a one-year warranty which begins from date of purchase. Should the following situations occur, your warranty and/oryour eligibility for a return or refund may not be valid.

Return & Refund Policy

- Intervention to evalue.

 Intended damage or abuse.

 Inappropriate storage (including dropping or soaking in water).

 Unauthorized modifying or repair of product.

 Natural wear of product.

 Natural wassters.

Contact & Support

Setup and Troubleshooting:

This product is not a security device and cannot prevent instances of theft from taking place. SwitchBot is not liable for any theft or similar accidents that may occur when using our products. Support@wondertechlabs.com
Feedback: If you have any concerns or
problems when using our products, please
send feedback via our app through the
Profile > Feedback page.

CE Warning

Importer Name: Amazon Services Europe Importer Address: 38 Avenue John F Kennedy, L-1855 Luxembourg, Art4-EURep@amazon.com

Support Email: support@wondertechlabs.com

EU Regulatory Conformance

Manufacturer's Name: Woan Technology (Shenzhen) Co., Ltd.This device Use only the supplied or an approved antenna. This device in complance with the essential requirements and other relevant provisions of directive 2014/53/EU. All essential radio test suites RF exposure information: The EIRP power of the device at maximal case is below the exempt condition, 20mW specified in EN62479: 2010. RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation(1999/519/EC). have been carried out.

Recommendation (TED DOC CE DOC Hereby, Woan Technology (Shenzheri) Co., Ltd., dedares that the radio equipment type 201, 453/FLJ. The full text of the EU declaration of conformity is available at the following internet address: support.switch-bot.com

Internal addirects support adult-host com UNICA DOC Hereds, Wasn Technology (Sheruther) (C., Ltd. desibers that the made equipment type W2500070 desibers in the following the washelde at the following internet address: The following internet address: Round 1101, Glandreng Commercial, Maderials (Round 101), Glandreng Commercials (Round 101), Glandreng (Round

Operation frequency BLE: 2402MHz-2480MHz Operation temperature: -25-66°C NFC13.56MHz

This device complies with Part 15 of the PCC Rules. Operation is subject to the following two

tions used Comparison with 1 of the ECL.

The Committee of the Committee o NOTE: The manufacturer is not responsible for any radio or TV interference caused by modifications to this equipment. Such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure

condition without restriction.

which can be determined by turning the equipment of and on, the user is encouraged to ty to correct the interference by one or more to ty to correct the interference by one or more than the control of the interference by one or more than the control of the interference and inte