

IT-3000M54E Operational Description

Test report No. RFI/MPTB1/RP45177JD07A

System configuration and connection

- 1 IrDA link between EUA and the cradle
- 2 Wireless communication by Bluetooth wireless technology
- 3 Printer
- 4 Buzzer Unit

Operation: switch-on, operation, power-off

- ☐ Press the reset button behind the EUA with a slim point article.

2 Double click to open the folder.

My Computer – Storage Card

3 Double click “File APO”

AUTO POWER OFF Release

4 Double click diag FEED

5 Wait for “DIAG Rev.0.17 for PX-780” and tap it.

6 Tap twice “NEXT”

7 Tap “3 Load Run”

8 Tap “Load Run2”

Start of the operation