

# **Smart Watch** User Manual

Product Name: SMART WATCH Product model: TF-H01 Battery parameters: 420mAh

Input parameters: 5V-500mAh FCC-ID: 2BAQF-TF-H01

enzhen Qishun Innovation Technology Development Co., Ltd

Basic introduction to the product







# APP download, installation and use


## 1. Scan the following OR code or enter each major application market

to download and install "GloryFit"

Equipment requirements; jos 9.0 and above; Android 5.0 and above



2. After the download is completed, start the new user registration or third-party login. And improve personal basic information



# 4. After the binding is successful, start to set the functions of the watch

3.Start binding watch

**★ IMPORTANT NOTICE ★** 

## How to make music and social media playing? WATCH "SETTING"ICON



in the APP according to your habits

IN"SETTING"---"SOUND AND VIBRATION TURN ON / OFF THE "MEDIAL AUDION TO SWITCH THE MUSIC PLAYING

## Basic product functions Sort regardless

1.Motion Real time recording of current steps, distance and calories

## 2.Call The watch can dial directly



4.Blood oxygen Real time automatic measurement of blood oxygen saturation, can also be actively measured, and vibration prompts indicate measurement completion.

## store 100 phone numbers. and has recent call records



13.Bluetooth photography the anniclick on the watch to control the phone to take

5.Blood pressure

Timely measure the high

and synchronize it with the

7.Weather forecast

connecting to the app, the

watch can view the weather

conditions of the day and

9.100+Sport mode

Enter the selected sports

mode and start, swipe to

the right to pause, stop, or

11.Music control

music from the phone, car

pause/play, previous, next.

Watch Bluetooth plays

volume adjustment

continue

After successfully

the past few days

and low voltage at that time


15.Breathing exercise Set the time and frequency in the watch, follow the practice, and achieve the purpose of breathing training.

## Other functions of the watch: Do Not Disturb Mode/Stopwatch/Countdown/Flashlight/Calculator/

Female Physiological Cycle/Call Reminder/Alarm clock reminder/ long sitting reminder/Find phone /goal achievement reminder

## Matters needing attention 1. Please avoid strong impact, high temperature and exposure to

- 2. Do not disassemble, repair or modify the machine by yourself. 3, This machine can be charged with 5V 500MA -- 5V 2A charger.
- It is strictly prohibited to use the over-voltage load power supply for charging.
- 4, It is prohibited to charge when there is water stain. 5. This product is an electronic consumption monitoring product



6.Sleep monitoring

Wenn Sie eine Uhr in den

Schlaftragen, überwacht

wie Tiefschlaf, leichter

Augenbewegung

die Uhr automatisch Daten

Schlaf, Wachzustand und

8 Information reminder

message prompts. Click to view the content, or click to

10.Voice Assistant

watch, and control the

12.SOS

to make a call.

14.Game

Built in multiple

decompression games

entertainment

Click on voice, speak to the

phone to achieve the goal

Synchronize the emergency

number to the watch end in

the app. and click on SOS

Watch saves the last 8

clear the message

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may

cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment

Note: This equipment has been tested and found to comply with the limits for

pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication:

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver

is connected

Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The company reserves the right to modify the contents of this manual without

However, there is no quarantee that interference will not occur in a particular installation.

any notice. It is normal that some functions are different in specific software versions.