无线收音麦克风	产品介绍 康敏志导教育的产品。 本产品为智能无能差发成,可整件专业级科协高差输出,即 勤新用,无限APP,多种指法:包定我和的信盖,现象的少考生合分形。		使用方法 ^{第一步:把她收留的一头输入手机输口。}	第二步:长披走克风的开机器,指示灯夹绿灯,即开机成功。	第二步: 法收益红灯常完, 手机打开相机, 直接组成物APP的 可使用素充成收益。	特别说明: 第90时接用方法加下: 接收減量面设有带电池,直播时不需 要凭电、或果真期时,手机电量不足的情况下,直接递过接 收减的接口给予手机免电。	UI功能 変死以及射線 ³²⁽²⁴⁾ 単作 741 世紀15 生気(156) 741 世紀15 日平 単金が 毛知15 日平	28. 一座二度大风的空港水一一一面均称于高速。可关机高级出动 的发展的。利益的时候,然后先和称考到的发展及从,用的 可能是不可能。如果的现在分词,和显示的发展,就是在一次关系 无效不可。// 包装清单
说明书	无线像直要无从由两部分构成,意克风发射线,接收3%。 (如下图所示)						センズムカ	日表演員介容 日表演員介容 注意均定影響 注意均定影響 注意均定影響 注意均衡 注意均衡 注意均衡 注意均衡 注意均衡 注意均衡 注意均衡 注意均衡 注意 注 注意 注意 注
C C F F C 2 2 2 2 2		© лод © лода © воланот © велонот © велонот деятна, © велонот деятна, © велонот © велонот о велонот © велонот	E CPPOVVO/00/2018-10-00 日前日子長春前日東京西 IEを CPTO-17HOTOR(和) 7年正常使用。				また。 日本 118 日本 118	(金) 検验员 桜 市島市の 桜 市島市の 桜 市島市の 低市の ● ● ● ● ● ● ● ● ● ● ● ● ●

	Introduction	ID Diagram	How to use				About UI	
Wireless Microphone User Manual	Thirds for choosing our product. This product as most twelves increasing output Plug and the provides ago reguined. Model weight Can obtain Plug ago reguined. Model weight Can obtain Plug ago reguined. Model weight Can obtain Plug the control of the control of the for control of the the control of the control of the for control of the Can obtained of the control of the for control of the Can obtained of the control of the for control of the Can obtained of the control of the control of the control of the control of the control of the plug of the control of the control of the control of the plug of the control of the control of the control of the plug of the control of the control of the control of the plug of the control of the control of the control of the control of the plug of the control of the control of the control of the control of the plug of the control	Windowskiel Weither headstrand and Windowskiel Weither headstrand and Weither headstrand Weither h	Step 1: Connect the vectors to phone with part.	Step 2: Long press the power on button of the microphong/the indicator light is green/but is, the boot is successful.	Step 1: The indicator ise lyter of scenare leaders always and, then open the house carries (a) we good order Apps, and the to use the microphone to receive sound. ((a)) ((b)) ((c)	Section Motion: For the use of Boott, there is no battery in receiver, and no need to recharge during like. The phone is two power during Like. It can be included directly through Bypot.	Processor Decose una Decose una <thdecose th="" una<=""> Decose una <thdecose th="" una<=""> Decose una Decose una</thdecose></thdecose>	Meet in our of the are interactions in the pay on the constant and of the magnetizer that the area too and the constant of the magnetizer state of the magnetizer that the magnetizer that the magnetizer is the magnetizer that the magnetizer that the magnetizer Packetizer Listenation that the magnetizer that the magnetizer Packetizer Listenation that the magnetizer that the magnetizer (a) excerning constraints (b) the magnetizer (c) user manual

(中英文)说明书(风琴折)

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.