Wireless Microphone

User Manual

C ∈ F© ♣ 🖺 ⊕ 🖺 €


Introduction

Thanks for choosing our product.

This product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required. Multiple uses: It can be used in online live broadcast, video Vlog shooting, program interview, recording, video teaching and other occasions.


The wireless Microphone consists of two parts, one is Microphone transmitter, the other one is receiver. (See as below picture)

(Receiver)






ID Diagram






4 Microphone clip




⑤ Switch Key Port to connect phone ⑦ Receiver indicator ® Port of receiver

How to use

Step 1:First connect the receiving end to the interface of the mobile phone, the indicator light will flash



Step 2:Click the power button of the microphone.the red and blue indicator lights will flash, and the blue light will flash until the blue light is always on, that is, the pairing is



Step 3:The light on the receiving end is always on,and the phone can use the microphone to pick up sound by opening the camera, live video and other APPs.



About UI

Microphone Transmitter

Function	How to use	Light
Power on	Press switch key once	Green light on
Power off	Press switch key about 3-4 seconds	Green light flashing
Charging		Green light doesn't go off until it's fully charged
Pairing		Green light flashes slowly
Paired		Green light is always on
Low battery alarm	Battery is below 20%	Green light flashes slowly

Receiver

Function	How to use	Light
Power on	Plug in the device	Green light shining
Power off	Plug off the device	Light off
Pairing		Green light shining
Paired		Green light is always on

Packing List

Content of packing

- (1) Microphone transmitter
- (2) Receiver (3) Charging cable

(4) User manual PCC Statemoor

The paper of the fact that of fact is used of the fact to a fact that the congalaxies and the form of the body shadow. The special growns are private office of transport and had employed an a company of the married Continues of all the last is partially believed in the control for any last books. $\mathcal{A} : \mathbb{R}^{n} \times \mathbb{R}^{n} \to \mathbb{R}^{n} : \mathbb{R}^{n} \times \mathbb{R}^{n} \to \mathbb{R}^{n} \times \mathbb{R}^{n} \times \mathbb{R}^{n} \times \mathbb{R}^{n} \to \mathbb{R}^{n} \times \mathbb{R}^{n} \times \mathbb{R}^{n} \to \mathbb{R}^{n} \times \mathbb{R}^{n} \times \mathbb{R}^{n} \times \mathbb{R}^{n} \times \mathbb{R}^{n} \to \mathbb{R}^{n} \times \mathbb{$

- Name of the part of the Person of the Association and the Person of th
- If the last the spinished filling laster in a party of the filling the state for some to
- Trades for Areas & Application of the darks on Application processing annual to
- The Minter condition for your ET of the SET flows Statement in colors or the Minterlands
- residence. (If the street was not cause business baselinesses and III this decreases some particular care and which provided the contract of the con-

Name of Street and Str The second second second

无线收音麦克风

使用说明书

(€ F© 🌣 🖺 😭 🐼


中国制造

产品介绍


感谢您选择我们的产品。

本产品为智能无线麦克风, 可提供专业级别的录音 输出。即插即用,无需APP。多种用途:可实现网络 直播、视频Viog拍摄、节目访谈、采访录音、视频 教学等场合的使用。

无线收音麦克风由两部分构成, 麦克风发射端, 接 收端。(如下图所示)



ID图示






防风网

④ 麦克风夹


- ② 麦克风指示灯 ③ 麦克风充电接口




⑤ 开关机键 ⑥ 手机接口 ⑦ 接收端指示灯 ⑧ 接收端充电接口

使用方法

第一步:首先把接收端一头接入手机的接口, 指示灯闪亮。



第二步:单击麦克风的开机键,红蓝指示灯闪亮,闪到蓝 灯常亮,即开机配对成功。



第三步:接收端灯常亮,手机打开相机、直播视频 等APP 即可使用麦克风收音。



UI功能

麦克风发射端

功能/状态	操作	灯效
开机	按键单击	绿灯亮
关机	按键长按3-4S	绿灯闪亮
充电		绿灯常亮,充满绿灯灭
搜索配对		绿灯慢闪
配对成功		绿灯常亮
低电报警	电量低于20%	绿灯慢闪

接收端

功能/状态	操作	灯效
开机	插入设备上电	绿灯闪亮
关机	拔掉设备断电	灯灭
搜索配对		绿灯慢闪
配对成功		绿灯长亮

包装清单

包装清单内容 (1) 麦克风发射端

- (2) 接收端
- (3) 充电线
- (4) 用户说明书

