



User Manual

iMiki MB1



Scan the QR code to get the
manual in more languages

Download the App


Scan the following QR code, download and install the IMIKLife App

"Scan QR Code and Download"



Charge and Active

Charge the device to active before the first time using; To charge your device, plug the charging cable into the adaptor or USB port into the computer.



Pairing



The MAC address on the "Setting"-"About" page could help you identify your device on the scanning list.

Use the Touch Screen



Smart Watch Features



BT Phone Call

After connecting the Smart Watch to the phone, you can use the watch to dial to control the phone for making calls and answering the phone calls. You can also view the call history of the watch.



Heart Rate Monitor

The Smart Watch could record your heart rate all day. You also could tap on the page to start measuring heart rate.



Sports

Smart Watch automatically tracks steps taken on the screen.

NOTE: Your movement stats reset to zero at midnight.



Exercise



SpO2 Monitoring

Tap on the SpO2 page to start.



Sleep

If you wear the Smart Watch all the time during sleep, it can provide sleep time and sleep quality statistics both on the screen and the APP.

NOTE: Sleep stats reset to 0 at 8:00 pm.



Weather

It could show the weather info of current and tomorrow on the weather page.

Weather info is synced after connecting with the APP. It will not be updated after a long disconnection.



Message Reminder

The device can sync incoming notifications from the Twitter, Facebook, WhatsApp, Instagram etc.

Note: You can switch on/off the incoming notifications in the APP.

Smart Watch Features



Remote Shutter

After connecting the device, you can remote control the camera on your phone.



Music

After connecting the device, you can remote control the music player on your iPhone.



Calculator

You can use a calculator on your watch.



Stop Watch

The start button on stop watch page to start timing, and tap the stop button to stop timing.



Remind to Move

The device will vibrate to remind you to make a move after 1 hour sitting. Note: You can switch on/ off the feature in the App.



Breathing Exercises

Click "Start" to breath training.

Getting to Know Your Device

Using in Wet Conditions Your device is water-resistant, which means it is rain-proof and splash-proof and can stand up to even the sweatiest workout.

Note: Do not swim with your Smart Watch. We also don't recommend showering with your Smart Watch; though the water won't hurt the device, wearing it 24/7 does not give your skin a chance to breathe. Whenever you get your Smart Watch wet, dry it thoroughly before putting it back on.

General Info & Specifications

1. **Environmental Conditions** Operating temperature: 14 F to 122F (-10°C to 50°C)
Non-operating temperature: -4F to 140F(-20°C to 60°C)
2. **Size** Fits a wrist between 5.7 and 8.2 inches in circumference.
3. **Disposal and Recycling** Please kindly be aware that it is the consumer's responsibility to properly dispose and recycle Smart Watch and accompanying components. Do not dispose of Smart Watch with common household waste, the Smart Watch unit is considered **electronic*** waste and should be disposed of at your **local** electronic equipment collection facility. For more information, please contact your **local** electronic equipment waste management authority or the retailer where you bought the product.
4. **Frequency Band:** BLE5.3 2.402MHz - 2.480MHz
5. **Max. Signal Transmission:** $\leq 4\text{dBm}$

Disposal of electrical and electronic equipment



The crossed-out garbage can means that you are legally obliged to collect these devices separately from unsorted municipal waste. Disposal in the residual waste bin or yellow bin is prohibited. If the products contain batteries or accumulators that are not permanently installed, they must be removed before disposal and disposed of separately as batteries.

Possibilities of returning old appliances

Owners of old devices can hand them in within the framework of the options set up and available by public waste disposal authorities for returning or collecting old devices to ensure that the old devices are properly disposed of.

Data protection

We would like to point out to all end users of waste electrical and electronic equipment that they are responsible for deleting personal data on the old equipment to be disposed of.



We, IMIK Co., Ltd., hereby declare that this device complies with the basic requirements and the other applicable provisions of the EU Declaration of Conformity according to the Radio Equipment Directive 2014/53/EU and the RoHS Directive 2011/65/EU. The full EU declaration of conformity can be found on the website: <https://www.imiklife.com/declarations>

Manufacturer: IMIK Co., Ltd

Address: 1401F, South Area, Jingji Yujing Times Building, Longgang District, Shenzhen, China

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions:

(1) This device may not cause harmful interference, and

(2) this device

must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the

equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party