

1.Introduction

Lintroduction

Thanks for choosing our wireless audio adapter. This device is a inplane Bulectooth transmitter, when the movib begins on your need to giffeet, bug & AFOI into your seets; jack and listen to the film with your wireless should be headylones. AFOI use Bulectooth to connect your wireless sethouts or headylones in the Bulectooth connect your wireless sethouts of headylones wireless produced by the production of the Bulectooth sething wireless headylones or settling which headylones or settling which headylones is settling with the production of the Bulectooth devices like Bulectooth headylones, Bulectooth speaker, etc.

2.Specifications Eluctooth chipset: V4.2+EDR Bluetooth frequency: 2402 MHz-2480 MHz Supported protocol: A2DP, AVRCP Bluetooth distance: 10M (Free space) Build in Pattern 200 mg/h Build-in battery: 200 mAh Charging input voltage: DC 5.0V

3.Packing content: Bluetooth Transmitter x1 pc User manual x1 pc Charging cable x1 pc Airplane audio connector x1 p

① Micro USB charging interface ② ON/OFF



5.Charging

S.Charging When using for the first time, please fully charge the product. When the unit is in low power state, please charge it through the standard USB charging cable. The red light will be on when charging, the red light is off and blue light is on when full charged. 6.Power ON/OFF

b. Power DN/OFF .ON: Long press the ON/OFF button 3s to turn on. .OFF: Long press the ON/OFF button 3s to turn off. .Automatic shutdown: The device in the absence of the connection state, after 5 minutes, it will automatically turn off.

7.Operation Steps

7. Operation Steps
(When you use its in airplane
APress ON/OFF button to turn on AF-001 and turn on
your Blustooth headphones.
B.Enter the search pairing state, the red and blue light
slash alternately. It will connect with your Blustooth
headphones automatically.
CARter paired saccessfully, the blue light flashes slowly.
D.Plug AF-001 line your exert jack on the airplane.
For our on literator to audio from your Bluetooth headphone

②When you use it as a transmitter at home

(When you use it as a transmitter at home AFress OW/OFF beam to turn on AF-001 and turn on your Blustooth headphones. Childre the search paining state, the red and blue lights lack the search paining state, the red and blue lights beadphones automatically. CAHP paired successfully, the bus legis flathest slowly. DFUL AF-001 into your home non-Blustooth devices, like TV, Y NB, on the search pair search pair Like TV, Y NB, on these to home audio from your Bluetooth headphones.

If the unit can't work normally, pleas see below info:

A.Confirm power is on and it's not in low power state. B.Please try to reboot the adapter, check if it can work

normally.
C.Please make the product as close as the Bluetooth

devices.

D.Different Bluetooth devices use the different chipset D.Different Bluetooth devices use the different chipset and protocols, the searching and connecting time maybe different.
E.Please contact us if you can't solve problems according the manual.please don't disassemble the unit or repair by yourself.

F. Because of Bluetooth chip scheme and transport protocol are different, there will be something wrong with connection, we will continue optimizing the device thanks for supporting.

Trainis for supporting.

POD Salamate
MOTE: This explanes that sale training the post to comply with
MOTE: This explanes that sale that the post to post to 5 th FOD
Publics: Those informs sale
Publics: Those informs sale
Publics: Those informs sale
Publics: Those informs sale
Information in a second production against harmful in
Information in a second public information in a second in
Information in the second in a second in a second in
Information or many and, if not installed and used in accordance with
Requestion years grant of not installed and used in accordance with
Requestion years grant in the second in a second in a periodize installation. If this exaplament does
will not occur in a periodize installation. If this exaplament does
will not occur in a periodize installation. If this exaplament does
will not be a second in a se

Recrient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outset on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IO Statement.
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada' licence-exempt RSS(s). Operation is subject to the following two oversitions:

Ilicence-alxempt house, house, or conditions:

(1) This device may not cause interference, including interference that may cause undesired operation of the device.

L' émetisurirécopteur exempt de licence contenu dans le présent apparail est conforme aux CNR d' Innovation, Sciences et Développement éconorrique Canada applications aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes:

