

STEREO EARPHONES with Bluetooth® Wireless Technology

Owner's Manual

PLEASE READ BEFORE OPERATING THIS EQUIPMENT.

Model: CBH515

FCC INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digita device, pursuant to part 15 of the FCC Rules. These limits are designed to provide residential protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance wit the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on the circuit different from that to which the equipment into an outlet on the circuit different from that to which the equipment into an outlet on the circuit different from that to which the equipment into an outlet on the circuit different from that to which the equipment into an outlet on the circuit different from that to which the equipment into an outlet on the circuit different from that to which the equipment into an outlet on the circuit different from that to which the equipment into an outlet on the circuit different from that to which the equipment into an outlet on the circuit different from the circuit d receiver is connected
- . Consult the dealer or an experienced radio/TV technician for help.

FCC NOTICE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Location of Controls





- 1. + Button
- 2. Red Indicator
- 3. C Button 4. Blue Indicator
- 5. Button
- 6. Micro USB Port (For Charging Only)
- 7. Built-in Microphone
- 8. Ear Hook

Hooks installation:



The unit has a built-in DC === 3.7V Li-ion rechargeable battery, recharges it before use or

- 1. Connect the Micro USB plug from the USB connection cable to the Micro USB Port on the
- 2. Connect the full size USB plug from the USB connection cable to the USB Port on a computer or any USB charger having DC 5V output.
- 3. During charging, the Red Indicator will illuminate. When finished, Red Indicator will turn off.

Your battery will last longer if you follow these simple guidelines for charging and storing.

- A. Recharge and store the device within the temperature range of 5°C ~35°C (40°F~95°F).
- B. Do not overcharge (longer than 24 hours). Excessive charging or discharging may shorten the battery's life.
- C. Battery life naturally shortens slowly over time.
- D. The rechargeable battery incorporated in this product is not replaceable.

Operation:

The first time you use the unit or pair it to a new Bluetooth device, follow these instructions:

- 1. Press and hold the C Button approx. 2 seconds until the Blue and Red Indicators
- 2. Power on the external BT device and enter to BT searching mode. Start pairing following the on screen instructions from the external BT device. After pairing, the Red Indicator will not light and the Blue Indicator will stop blinking. (For details pairing procedures, please refer to the user's manual of your BT device.)

- When the external BT device searched the unit, our model number "CBH515" will appear appear on the display of external BT device.
- Pairing code "0000" or "1234" may need to enter

Normal operation after pairing:

- 1 Power on the external RT device and enter RT mode
- 2. Press and hold the \(\int \) Button approx. 2 seconds until the Blue Indicator is illuminate and blink then release the button. Wait a few seconds until the unit auto paired to the external BT device. (The Blue Indicator will stop blinking.)
- Plays the music in the paired BT device as usual. (Make sure the sound level of the paired BT Device is set to high. Otherwise, sound from this unit is weak.)
- Press and hold the "-" or "+" Buttons to adjust volume level.
- Press the \(\int^{\text{B}}\) Button to pause, press again to resume normal playback.
 Press and release the "-" or "+" Buttons repeatedly to skip tracks.

- When you receive an incoming call while listening to music, press the
 Button to pause the music then speak into the built-in Microphone to answer the call. When your call is complete, press the CButton to end the call and resume to the music playback.
- Press and hold the \(\int \) Button approx. 3 second to reject incoming call.
- Press the Button twice to redial the last dialed phone number.
- 6. To shut off the unit, press and hold the C Button approx. 3 seconds until the Blue and Red Indicators illuminate and blink then release the button to shut off the unit.

Specifications:

....Built-in DC === 3.7V; 70 mAH (0.259WH) rechargeable Li-ion Power Source:..... battery, recharge by DC === 5V through Micro USB Port Bluetooth version: Bluetooth 4.1+FDR Impedance of Earphone:16 ohm. 5 mW x 2 Audio power:....4 mW per channel

Accessories:

- 1 x User's Manual
- 1 x USB Connection Cable (for charge only) 1 x Earphone Hooks (1 pair)

SPECIFICATIONS AND ACCESSORIES ARE SUBECT TO CHANGE WITHOUT NOTICE

LIMITED WARRANTY

Craig warrants this product to be free from manufacturing defects in material and workmanship under normal use for a period of 90 days from date of purchase. If service is required, please return the product to the store where it was purchased for exchange, or, pack the unit in the oniginal packing material with all accessories if applicable, a copy of your sales receipt and a Cashier's check or Money Order for \$3.00 (to cover shipping and handling ossis) payable to Craig Electronics Inc. For consumers in Canada, please make sure that the cashier check or money order is redeemable through a U.S. bank. Ship your product freight pre-paid. Your unit lible be repaired, replaced or if the unit can not be repaired or replaced, a refund will be forwarded to you within four weeks of receipt of your unit. Pleases ship your profuses ship your profuse. of your unit. Please ship your unit to:

Craig Electronics Inc. 1160 NW 163 Drive Miami, FI 33169

This warranty is void if the product has been: a) Used in a commercial application or Inis warranty is void in the product as been: a) Used in a commercial application for rental. b) Damaged through misses, negligence, or abuse. o) Modified or repaired by anyone other than an authorized craig service center. d) Damaged because it is improperly connected to any other equipment. Note: This warranty does not cover: a) Ordinary adjustments as outlined in the Owner's Manual Minich can be performed by the customer. b) Damage to equipment not properly connected to the product. c) Any cost incurred in shipping the product for repair. d) Damage to the product not valve of the USA.

This warranty is not transferable and only applies to the original purchase. Any implied warranties, including the warranty of merchantability, are limited in duration to the period of this expressed warranty and no warranty whether expressed or implied shall apply to the product thereafter.

Under no circumstance shall Craig be liable for any loss or consequential damage arising out of the use of this product. This warranty gives specific legal rights. However, you may have other rights which may vary from state to state. Some states do not allow limitations on implied warranties or exclusion of consequential damage. Therefore, these restrictions may not apply to you.

To Obtain Service on your Product email:service@craigelectronics.com

Printed in China

CBH515 WC E0FF1 A0US

Size: 148.5(W) x 210(H)mm (A5)

