Subsection

2.983(d)(9): Factory Tune-up Procedure

Test Equipment

1. BNC-P Coaxial RF cable Audio Technica custom RF cable

Kenwood PR-18 2. DC Power Supply 3. Audio Signal Generator Leader LAG126 4. Modulation Meter (FM liner detector) Anritsu MS61A 5. Spectrum Analyzer Advantest R3261A 6. Pre amplifier Anritsu MH648A 7. Oscilloscope Iwatsu SS-5705 8. DC Volt Meter Advantest TR6845 9. AC Millivolt Meter National VP9680A

Adjustment of T602 circuit board

- 1. Connect the audio, switch and RF circuit board of ATW-T602.
- 2. Supply 9V from DC power supply to the power supply terminal (CNP 24 and 25) of T602
- 3. Connect BNC-P coaxial RF cable with input connector of Spectrum analyzer.
- 4. Connect BNC-P coaxial RF cable to JK100 terminal of T602
- 5. Set T602 to channel "3".
- 6. Set the center frequency of Spectrum analyzer to oscillation frequency of T602, and set frequency span to 3GHz.
- 7. Set the power switch of T602 (SW50) to ST-BY position. Make sure to confirm that when turn the power on, power LED lights.
- Make sure that RF signal appears on Spectrum analyzer and no parasitic oscillation observed.
- Adjust and set the VR100 where Maximum RF output (10mW) could obtainable as well as power supply current not exceeded 65mA and spurious level could set minimum (less than 45dB).
- 10. Set frequency span of the Spectrum analyzer to 100KHz.
- 11. Set RF signal on the Spectrum analyzer to a desired Oscillating frequency by turning the VC130 onT602.
- 12. Gradually reduce power supply voltage from 9 V to 6.5V and make sure that Oscillating frequency stay same.
- 13. Check the power indicator LED start to blink I when power supply voltage reached to 6.5V.
- 14. Set frequency span to maximum.
- 15. Gradually move power supply voltage from 9 V to 6.5V and make sure that no parasitic oscillation observed.
- 16. Set the Power supply voltage back to 9V.
- 17. Remove the BNC-P coaxial RF cable from the input connector of Spectrum analyzer, and connect it to the Preamplifier.
- 18. Make sure that the Preamplifier and Modulation Meter (FM linear detector) are connected together.
- 19. Input –38.0dBV at 1kHz signal from the Audio signal generator to the Mic input of T602 by checking the level of the signal on AC milli voltmeter.
- 20. Set T602 trimmer (VR1) to maximum.
- 21. Set T602 to channel "3" and set the frequency range of the Modulation meter (FM linear detector) to the oscillation frequency of T602
- 22. Make sure that Oscilloscope has no irregular wave. Then, set the modulation levels appeared on the Modulation meter (FM linear detector) to +/-10KHz by turning VR2 on T602.
- 23. Set T602 to channel "0" and "7". Make sure that Deviation of the each cannel stays same.