


Linear PCM Recorder Operating Instructions


Let's try out your new linear PCM recorder

Charge



- 1 Charge the linear PCM recorder. Slide the USB connector into the direction of the arrow, and insert the USB connector into the USB port of a running computer. When the battery is fully charged, the battery indicator changes from the charging operation to "BATT".

Power on



- 1 Slide and hold the HOLD/POWER switch in the direction of "POWER" until the display appears. To turn the recorder off, slide the HOLD/POWER switch to "POWER" and then hold until "Power Off" appears on the display window. To prevent unintentional operations (playback), slide the HOLD/POWER switch in the direction of "HOLD".

Owner's Record

- Linear PCM Recorder (1) • MicroSD card (2) • Display window (3) • Operating instructions (this sheet) • Warranty card (4) • Application Software, Sound Organizer 2 (Install file stored in the built-in memory so that you can install it on your computer).

Refer to the Help Guide

This is the Operating Instructions, which provides you with instructions on the basic operations of the linear PCM recorder. The Help Guide is an online manual. Refer to the Help Guide when you would like to know further details, operations and possible solutions when a problem occurs.

http://rd1.sony.net/help/idx/pcm10a/h_uk/




Check the supplied items

- Linear PCM Recorder (1) • MicroSD card (2) • Display window (3) • Operating instructions (this sheet) • Warranty card (4) • Application Software, Sound Organizer 2 (Install file stored in the built-in memory so that you can install it on your computer).

Optional accessories


- Note condenser microphone ECM-131

Parts and controls




- 1 Built-in microphones 2 Peak indicator 3 Display window 4 OPTION button 5 BATT/REC (back mark) button 6 BATT/REC HOME button 7 STOP button 8 REC/PAUSE (record/pause) button, recording indicator 9 [play/return] button* 10 Control button (A/C) [Digital Pitch Control] "C" (A/B repeat A/B), [microphone/flat back] (backward) [flat back/forward] (forward) button 11 USB connector (You can find the USB connector retracted behind the cover.) 12 VOL +/- (Volume +/-) button 13 REVERSE/BATT button 14 [Microphone] jack 15 [Microphone] jack 16 [Microphone] jack 17 [Microphone] jack 18 [Microphone] jack 19 Strap Hole (No strap is supplied with your linear PCM recorder.)

Select




- 1 Select "Recorded Files" from the HOME menu. 2 Select "Label Recordings," "Search by REC Date," "Search by REC Scene," or "Folders." 3 Select your desired file. Playback starts.

Initial settings




- 1 Press VOL +/- to adjust the volume. 2 Press [STOP] to stop playback. 3 Press [SELECT] to start the initial settings. 4 Select "Yes" to start the initial settings. 5 Select the display language. 6 Set the current year, month, day, hour, and minute. 7 Go back to the previous clock setting item, press BACK/HOME.

Make device registration (pairing)




- 1 Place the Bluetooth audio device to which you establish a Bluetooth connection in pairing mode. Be sure to place the linear PCM recorder within 1 m from the Bluetooth audio device. 2 While recording is on standby, select [Bluetooth] "Audio Device" "Add Device (Pairing)" from the HOME menu. When "Other" (not Bluetooth ON) "Disconnect Connected Audio Device" continues to appear on the display window, select the "Connect" option on the display window, press the [SELECT] button to start searching. The search for Bluetooth audio devices that are available for device registration starts and the list of the found devices appears on the display window. 3 Select the Bluetooth device to which you register for establishing a Bluetooth connection. When the device is registered, "Connection Complete" appears on the display window. 4 Start playback on the linear PCM Recorder. Now, you can listen to audio from the Bluetooth audio device.

Record




- 1 Press and hold [REC/PAUSE] button. The recording standby screen appears. 2 Select a storage and a folder to save the recorded file. 3 Place the recorded file on the microSD card, and you need to change the file storage destination folder. Select "Recording Folder" "SD Card" from the OPTION menu, and then start recording. 4 Adjust the angle of the linear PCM recorder's built-in microphones with your fingertips so that they point in the direction of the recording source. 5 Turn the linear PCM recorder so that its built-in microphones point in the direction of the target sound source. 6 Press and hold [REC/PAUSE] button. The recording indicator flashes in red and the linear PCM recorder begins recording. When the built-in microphones pick up sounds, the peak level meter bars change in length to indicate the recording volume levels.

Operations with the smartphone (REC Remote)



- 1 To operate your linear PCM recorder using a smartphone, you need to install the REC Remote on the smartphone and make a pairing between the smartphone and your linear PCM recorder. Pairing means having Bluetooth devices connect with each other to establish a wireless connection for the first time. To make a pairing with the linear PCM recorder using REC Remote, you need the latest version of REC Remote. If your smartphone has REC Remote already installed, be sure to update it to the latest version. 2 When the Bluetooth function of your linear PCM recorder, you can operate your linear PCM recorder (recording, changing the recording settings, etc.) using a smartphone.

Listen



- 1 Select "Recorded Files" from the HOME menu. 2 Select "Label Recordings," "Search by REC Date," "Search by REC Scene," or "Folders." 3 Select your desired file. Playback starts.

Using the HOME menu



- 1 Press and hold BACK/HOME. The HOME menu screen appears. 2 The HOME menu items are aligned in the following category: Music, Record, Bluetooth, Settings, Back, and Exit. 3 Select your desired function from the following: Music: You can select and play one of the files you have imported from a computer. To locate a music file, select "All Songs," "Albums," "Artists," or "Folders." When importing files, be sure to import them into the MUSIC folder. Record: You can select and play one of the files you have imported with your linear PCM recorder. To locate a recording file, select "Label Recordings," "Search by REC Date," "Search by REC Scene," or "Folders." Bluetooth: You can display the recording standby screen, and then start recording. Settings: You can display the menu screen for items that use the Bluetooth function, such as REC Remote, NFC, and Bluetooth audio devices. Additionally, you can turn on/off the Bluetooth function to make device registration (pairing). Back to Exit*: You can go back to the screen that was displayed before the HOME menu screen. *The function you are currently using is displayed in "OK".

Delete




- 1 Press and hold BACK/HOME. The HOME menu screen appears. 2 The HOME menu items are aligned in the following category: Music, Record, Bluetooth, Settings, Back, and Exit. 3 Select your desired function from the following: Music: You can select and play one of the files you have imported from a computer. To locate a music file, select "All Songs," "Albums," "Artists," or "Folders." When importing files, be sure to import them into the MUSIC folder. Record: You can select and play one of the files you have imported with your linear PCM recorder. To locate a recording file, select "Label Recordings," "Search by REC Date," "Search by REC Scene," or "Folders." Bluetooth: You can display the recording standby screen, and then start recording. Settings: You can display the menu screen for items that use the Bluetooth function, such as REC Remote, NFC, and Bluetooth audio devices. Additionally, you can turn on/off the Bluetooth function to make device registration (pairing). Back to Exit*: You can go back to the screen that was displayed before the HOME menu screen. *The function you are currently using is displayed in "OK".

Enjoy music wirelessly Listen to audio from the BLUETOOTH® audio device

- 1 You can establish a wireless connection between a Bluetooth audio device and the linear PCM recorder and listen to audio from the Bluetooth audio device. 2 Make device registration (pairing) To establish a wireless connection between Bluetooth audio devices for the first time, you need to have device registration with each other. This device registration process is called "pairing." 3 Place the Bluetooth audio device to which you establish a Bluetooth connection in pairing mode. Be sure to place the linear PCM recorder within 1 m from the Bluetooth audio device. 4 While recording is on standby, select [Bluetooth] "Audio Device" "Add Device (Pairing)" from the HOME menu. When "Other" (not Bluetooth ON) "Disconnect Connected Audio Device" continues to appear on the display window, select the "Connect" option on the display window, press the [SELECT] button to start searching. The search for Bluetooth audio devices that are available for device registration starts and the list of the found devices appears on the display window. 5 Select the Bluetooth device to which you register for establishing a Bluetooth connection. When the device is registered, "Connection Complete" appears on the display window. 6 Start playback on the linear PCM Recorder. Now, you can listen to audio from the Bluetooth audio device. 7 To disconnect the Bluetooth connection between the linear PCM recorder and the Bluetooth audio device, select [Bluetooth] "Audio Device" "Disconnect" from the HOME menu. When the Bluetooth connection is disconnected, playback stops. 8 To switch the audio output destination between the Bluetooth headphones and the connected headphones (when a Bluetooth connection is established) to the headphones connected to the headphones jack, you need to disconnect the Bluetooth connection. 9 You cannot monitor the recording audio with the connected Bluetooth audio device. The recording audio is output to (a) headphones/jack. Use the headphones for monitoring.

Copying files from your linear PCM recorder to a computer



- 1 Copy the files and folders from your linear PCM recorder to a computer to them. 2 Follow the instructions in "Change" to connect your linear PCM recorder to a computer. 3 Drag and drop the files or folders you want to copy from the PC window to the local disk on the computer. To copy a file or folder (drag and drop): 1 Click and hold. 2 Drag. 3 and then drop. 4 Release. 5 Release. 6 Release. 7 Release. 8 Release. 9 Release. 10 Release. 11 Release. 12 Release. 13 Release. 14 Release. 15 Release. 16 Release. 17 Release. 18 Release. 19 Release. 20 Release. 21 Release. 22 Release. 23 Release. 24 Release. 25 Release. 26 Release. 27 Release. 28 Release. 29 Release. 30 Release. 31 Release. 32 Release. 33 Release. 34 Release. 35 Release. 36 Release. 37 Release. 38 Release. 39 Release. 40 Release. 41 Release. 42 Release. 43 Release. 44 Release. 45 Release. 46 Release. 47 Release. 48 Release. 49 Release. 50 Release. 51 Release. 52 Release. 53 Release. 54 Release. 55 Release. 56 Release. 57 Release. 58 Release. 59 Release. 60 Release. 61 Release. 62 Release. 63 Release. 64 Release. 65 Release. 66 Release. 67 Release. 68 Release. 69 Release. 70 Release. 71 Release. 72 Release. 73 Release. 74 Release. 75 Release. 76 Release. 77 Release. 78 Release. 79 Release. 80 Release. 81 Release. 82 Release. 83 Release. 84 Release. 85 Release. 86 Release. 87 Release. 88 Release. 89 Release. 90 Release. 91 Release. 92 Release. 93 Release. 94 Release. 95 Release. 96 Release. 97 Release. 98 Release. 99 Release. 100 Release. 101 Release. 102 Release. 103 Release. 104 Release. 105 Release. 106 Release. 107 Release. 108 Release. 109 Release. 110 Release. 111 Release. 112 Release. 113 Release. 114 Release. 115 Release. 116 Release. 117 Release. 118 Release. 119 Release. 120 Release. 121 Release. 122 Release. 123 Release. 124 Release. 125 Release. 126 Release. 127 Release. 128 Release. 129 Release. 130 Release. 131 Release. 132 Release. 133 Release. 134 Release. 135 Release. 136 Release. 137 Release. 138 Release. 139 Release. 140 Release. 141 Release. 142 Release. 143 Release. 144 Release. 145 Release. 146 Release. 147 Release. 148 Release. 149 Release. 150 Release. 151 Release. 152 Release. 153 Release. 154 Release. 155 Release. 156 Release. 157 Release. 158 Release. 159 Release. 160 Release. 161 Release. 162 Release. 163 Release. 164 Release. 165 Release. 166 Release. 167 Release. 168 Release. 169 Release. 170 Release. 171 Release. 172 Release. 173 Release. 174 Release. 175 Release. 176 Release. 177 Release. 178 Release. 179 Release. 180 Release. 181 Release. 182 Release. 183 Release. 184 Release. 185 Release. 186 Release. 187 Release. 188 Release. 189 Release. 190 Release. 191 Release. 192 Release. 193 Release. 194 Release. 195 Release. 196 Release. 197 Release. 198 Release. 199 Release. 200 Release. 201 Release. 202 Release. 203 Release. 204 Release. 205 Release. 206 Release. 207 Release. 208 Release. 209 Release. 210 Release. 211 Release. 212 Release. 213 Release. 214 Release. 215 Release. 216 Release. 217 Release. 218 Release. 219 Release. 220 Release. 221 Release. 222 Release. 223 Release. 224 Release. 225 Release. 226 Release. 227 Release. 228 Release. 229 Release. 230 Release. 231 Release. 232 Release. 233 Release. 234 Release. 235 Release. 236 Release. 237 Release. 238 Release. 239 Release. 240 Release. 241 Release. 242 Release. 243 Release. 244 Release. 245 Release. 246 Release. 247 Release. 248 Release. 249 Release. 250 Release. 251 Release. 252 Release. 253 Release. 254 Release. 255 Release. 256 Release. 257 Release. 258 Release. 259 Release. 260 Release. 261 Release. 262 Release. 263 Release. 264 Release. 265 Release. 266 Release. 267 Release. 268 Release. 269 Release. 270 Release. 271 Release. 272 Release. 273 Release. 274 Release. 275 Release. 276 Release. 277 Release. 278 Release. 279 Release. 280 Release. 281 Release. 282 Release. 283 Release. 284 Release. 285 Release. 286 Release. 287 Release. 288 Release. 289 Release. 290 Release. 291 Release. 292 Release. 293 Release. 294 Release. 295 Release. 296 Release. 297 Release. 298 Release. 299 Release. 300 Release. 301 Release. 302 Release. 303 Release. 304 Release. 305 Release. 306 Release. 307 Release. 308 Release. 309 Release. 310 Release. 311 Release. 312 Release. 313 Release. 314 Release. 315 Release. 316 Release. 317 Release. 318 Release. 319 Release. 320 Release. 321 Release. 322 Release. 323 Release. 324 Release. 325 Release. 326 Release. 327 Release. 328 Release. 329 Release. 330 Release. 331 Release. 332 Release. 333 Release. 334 Release. 335 Release. 336 Release. 337 Release. 338 Release. 339 Release. 340 Release. 341 Release. 342 Release. 343 Release. 344 Release. 345 Release. 346 Release. 347 Release. 348 Release. 349 Release. 350 Release. 351 Release. 352 Release. 353 Release. 354 Release. 355 Release. 356 Release. 357 Release. 358 Release. 359 Release. 360 Release. 361 Release. 362 Release. 363 Release. 364 Release. 365 Release. 366 Release. 367 Release. 368 Release. 369 Release. 370 Release. 371 Release. 372 Release. 373 Release. 374 Release. 375 Release. 376 Release. 377 Release. 378 Release. 379 Release. 380 Release. 381 Release. 382 Release. 383 Release. 384 Release. 385 Release. 386 Release. 387 Release. 388 Release. 389 Release. 390 Release. 391 Release. 392 Release. 393 Release. 394 Release. 395 Release. 396 Release. 397 Release. 398 Release. 399 Release. 400 Release. 401 Release. 402 Release. 403 Release. 404 Release. 405 Release. 406 Release. 407 Release. 408 Release. 409 Release. 410 Release. 411 Release. 412 Release. 413 Release. 414 Release. 415 Release. 416 Release. 417 Release. 418 Release. 419 Release. 420 Release. 421 Release. 422 Release. 423 Release. 424 Release. 425 Release. 426 Release. 427 Release. 428 Release. 429 Release. 430 Release. 431 Release. 432 Release. 433 Release. 434 Release. 435 Release. 436 Release. 437 Release. 438 Release. 439 Release. 440 Release. 441 Release. 442 Release. 443 Release. 444 Release. 445 Release. 446 Release. 447 Release. 448 Release. 449 Release. 450 Release. 451 Release. 452 Release. 453 Release. 454 Release. 455 Release. 456 Release. 457 Release. 458 Release. 459 Release. 460 Release. 461 Release. 462 Release. 463 Release. 464 Release. 465 Release. 466 Release. 467 Release. 468 Release. 469 Release. 470 Release. 471 Release. 472 Release. 473 Release. 474 Release. 475 Release. 476 Release. 477 Release. 478 Release. 479 Release. 480 Release. 481 Release. 482 Release. 483 Release. 484 Release. 485 Release. 486 Release. 487 Release. 488 Release. 489 Release. 490 Release. 491 Release. 492 Release. 493 Release. 494 Release. 495 Release. 496 Release. 497 Release. 498 Release. 499 Release. 500 Release. 501 Release. 502 Release. 503 Release. 504 Release. 505 Release. 506 Release. 507 Release. 508 Release. 509 Release. 510 Release. 511 Release. 512 Release. 513 Release. 514 Release. 515 Release. 516 Release. 517 Release. 518 Release. 519 Release. 520 Release. 521 Release. 522 Release. 523 Release. 524 Release. 525 Release. 526 Release. 527 Release. 528 Release. 529 Release. 530 Release. 531 Release. 532 Release. 533 Release. 534 Release. 535 Release. 536 Release. 537 Release. 538 Release. 539 Release. 540 Release. 541 Release. 542 Release. 543 Release. 544 Release. 545 Release. 546 Release. 547 Release. 548 Release. 549 Release. 550 Release. 551 Release. 552 Release. 553 Release. 554 Release. 555 Release. 556 Release. 557 Release. 558 Release. 559 Release. 560 Release. 561 Release. 562 Release. 563 Release. 564 Release. 565 Release. 566 Release. 567 Release. 568 Release. 569 Release. 570 Release. 571 Release. 572 Release. 573 Release. 574 Release. 575 Release. 576 Release. 577 Release. 578 Release. 579 Release. 580 Release. 581 Release. 582 Release. 583 Release. 584 Release. 585 Release. 586 Release. 587 Release. 588 Release. 589 Release. 590 Release. 591 Release. 592 Release. 593 Release. 594 Release. 595 Release. 596 Release. 597 Release. 598 Release. 599 Release. 600 Release. 601 Release. 602 Release. 603 Release. 604 Release. 605 Release. 606 Release. 607 Release. 608 Release. 609 Release. 610 Release. 611 Release. 612 Release. 613 Release. 614 Release. 615 Release. 616 Release. 617 Release. 618 Release. 619 Release. 620 Release. 621 Release. 622 Release. 623 Release. 624 Release. 625 Release. 626 Release. 627 Release. 628 Release. 629 Release. 630 Release. 631 Release. 632 Release. 633 Release. 634 Release. 635 Release. 636 Release. 637 Release. 638 Release. 639 Release. 640 Release. 641 Release. 642 Release. 643 Release. 644 Release. 645 Release. 646 Release. 647 Release. 648 Release. 649 Release. 650 Release. 651 Release. 652 Release. 653 Release. 654 Release. 655 Release. 656 Release. 657 Release. 658 Release. 659 Release. 660 Release. 661 Release. 662 Release. 663 Release. 664 Release. 665 Release. 666 Release. 667 Release. 668 Release. 669 Release. 670 Release. 671 Release. 672 Release. 673 Release. 674 Release. 675 Release. 676 Release. 677 Release. 678 Release. 679 Release. 680 Release. 681 Release. 682 Release. 683 Release. 684 Release. 685 Release. 686 Release. 687 Release. 688 Release. 689 Release. 690 Release. 691 Release. 692 Release. 693 Release. 694 Release. 695 Release. 696 Release. 697 Release. 698 Release. 699 Release. 700 Release. 701 Release. 702 Release. 703 Release. 704 Release. 705 Release. 706 Release. 707 Release. 708 Release. 709 Release. 710 Release. 711 Release. 712 Release. 713 Release. 714 Release. 715 Release. 716 Release. 717 Release. 718 Release. 719 Release. 720 Release. 721 Release. 722 Release. 723 Release. 724 Release. 725 Release. 726 Release. 727 Release. 728 Release. 729 Release. 730 Release. 731 Release. 732 Release. 733 Release. 734 Release. 735 Release. 736 Release. 737 Release. 738 Release. 739 Release. 740 Release. 741 Release. 742 Release. 743 Release. 744 Release. 745 Release. 746 Release. 747 Release. 748 Release. 749 Release. 750 Release. 751 Release. 752 Release. 753 Release. 754 Release. 755 Release. 756 Release. 757 Release. 758 Release. 759 Release. 760 Release. 761 Release. 762 Release. 763 Release. 764 Release. 765 Release. 766 Release. 767 Release. 768 Release. 769 Release. 770 Release. 771 Release. 772 Release. 773 Release. 774 Release. 775 Release. 776 Release. 777 Release. 778 Release. 779 Release. 780 Release. 781 Release. 782 Release. 783 Release. 784 Release. 785 Release. 786 Release. 787 Release. 788 Release. 789 Release. 790 Release. 791 Release. 792 Release. 793 Release. 794 Release. 795 Release. 796 Release. 797 Release. 798 Release. 799 Release. 800 Release. 801 Release. 802 Release. 803 Release. 804 Release. 805 Release. 806 Release. 807 Release. 808 Release. 809 Release. 810 Release. 811 Release. 812 Release. 813 Release. 814 Release. 815 Release. 816 Release. 817 Release. 818 Release. 819 Release. 820 Release. 821 Release. 822 Release. 823 Release. 824 Release. 825 Release. 826 Release. 827 Release. 828 Release. 829 Release. 830 Release. 831 Release. 832 Release. 833 Release. 834 Release. 835 Release. 836 Release. 837 Release. 838 Release. 839 Release. 840 Release. 841 Release. 842 Release. 843 Release. 844 Release. 845 Release. 846 Release. 847 Release. 848 Release. 849 Release. 850 Release. 851 Release. 852 Release. 853 Release. 854 Release. 855 Release. 856 Release. 857 Release. 858 Release. 859 Release. 860 Release. 861 Release. 862 Release. 863 Release. 864 Release. 865 Release. 866 Release. 867 Release. 868 Release. 869 Release. 870 Release. 871 Release. 872 Release. 873 Release. 874 Release. 875 Release. 876 Release. 877 Release. 878 Release. 879 Release. 880 Release. 881 Release. 882 Release. 883 Release. 884 Release. 885 Release. 886 Release. 887 Release. 888 Release. 889 Release. 890 Release. 891 Release. 892 Release. 893 Release. 894 Release. 895 Release. 896 Release. 897 Release. 898 Release. 899 Release. 900 Release. 901 Release. 902 Release. 903 Release. 904 Release. 905 Release. 906 Release. 907 Release. 908 Release. 909 Release. 910 Release. 911 Release. 912 Release. 913 Release. 914 Release. 915 Release. 916 Release. 917 Release. 918 Release. 919 Release. 920 Release. 921 Release. 922 Release. 923 Release. 924 Release. 925 Release. 926 Release. 927 Release. 928 Release. 929 Release. 930 Release. 931 Release. 932 Release. 933 Release. 934 Release. 935 Release. 936 Release. 937 Release. 938 Release. 939 Release. 940 Release. 941 Release. 942 Release. 943 Release. 944 Release. 945 Release. 946 Release. 947 Release. 948 Release. 949 Release. 950 Release. 951 Release. 952 Release. 953 Release. 954 Release. 955 Release. 956 Release. 957 Release. 958 Release. 959 Release. 960 Release. 961 Release. 962 Release. 963 Release. 964 Release. 965 Release. 966 Release. 967 Release. 968 Release. 969 Release. 970 Release. 971 Release. 972 Release. 973 Release. 974 Release. 975 Release. 976 Release. 977 Release. 978 Release. 979 Release. 980 Release. 981 Release. 982 Release. 983 Release. 984 Release. 985 Release. 986 Release. 987 Release. 988 Release. 989 Release. 990 Release. 991 Release. 992 Release. 993 Release. 994 Release. 995 Release. 996 Release. 997 Release. 998 Release. 999 Release. 1000 Release. 1001 Release. 1002 Release. 1003 Release. 1004 Release. 1005 Release. 1006 Release. 1007 Release. 1008 Release. 1009 Release. 1010 Release. 1011 Release. 1012 Release. 1013 Release. 1014 Release. 1015 Release. 1016 Release. 1017 Release. 1018 Release. 1019 Release. 1020 Release. 1021 Release. 1022 Release. 1023 Release. 1024 Release. 1025 Release. 1026 Release. 1027 Release. 1028 Release. 1029 Release. 1030 Release. 1031 Release. 1032 Release. 1033 Release. 1034 Release. 1035 Release. 1036 Release. 1037 Release. 1038 Release. 1039 Release. 1040 Release. 1041 Release. 1042 Release. 1043 Release. 1044 Release. 1045 Release. 1046 Release. 1047 Release. 1048 Release. 1049 Release. 1050 Release. 1051 Release. 1052 Release. 1053 Release. 1054 Release. 1055 Release. 1056 Release. 1057 Release. 1058 Release. 1059 Release. 1060 Release. 1061 Release. 1062 Release. 1063 Release. 1064 Release. 1065 Release. 1066 Release. 1067 Release. 1068 Release. 1069 Release. 1070 Release. 1071 Release. 1072 Release. 1073 Release. 1074 Release. 1075 Release. 1076 Release. 1077 Release. 1078 Release. 1079 Release. 1080 Release. 1081 Release. 1082 Release. 1083 Release. 1084 Release. 1085 Release. 1086 Release. 1087 Release. 1088 Release. 1089 Release. 1090 Release. 1091 Release. 1092 Release. 1093 Release. 1094 Release. 1095 Release. 1096 Release. 1097 Release. 1098 Release. 1099 Release. 1100 Release. 1101 Release. 1102 Release. 1103 Release. 1104 Release. 1105 Release. 1106 Release. 1107 Release. 1108 Release. 1109 Release. 1110 Release. 1111 Release. 1112 Release. 1113 Release. 1114 Release. 1115 Release. 1116 Release. 1117 Release. 1118 Release. 1119 Release. 1120 Release. 1121 Release. 1122 Release. 1123 Release. 1124 Release. 1125 Release. 1126 Release. 1127 Release. 1128 Release. 1129 Release. 1130 Release. 1131 Release. 1132 Release. 1133 Release. 1134 Release. 1135 Release. 1136 Release. 1137 Release. 1138 Release. 1139 Release. 1140 Release. 1141 Release. 1142 Release. 1143 Release. 1144 Release. 1145 Release. 1146 Release. 1147 Release. 1148 Release. 1149 Release. 1150 Release. 1151 Release. 1152 Release. 1153 Release. 1154 Release. 1155 Release. 1156 Release. 1157 Release. 1158 Release. 1159 Release. 1160 Release. 1161 Release. 1162 Release. 1163 Release. 1164 Release. 1165 Release. 1166 Release. 1167 Release. 1168 Release. 1169 Release. 1170 Release. 1171 Release. 1172 Release. 1173 Release. 1174 Release. 1175 Release. 1176 Release. 1177 Release. 1178 Release. 1179 Release. 1180 Release. 1181 Release. 1182 Release. 1183 Release. 1184 Release. 1185 Release. 1186 Release. 1187 Release. 1188 Release. 1189 Release. 1190 Release. 1191 Release. 1192 Release. 1193 Release. 1194 Release. 1195 Release. 1196 Release. 1197 Release. 1198 Release. 1199 Release. 1200 Release. 1201 Release. 1202 Release. 1203 Release. 1204 Release. 1205 Release. 1206 Release. 1207 Release. 1208 Release. 1209 Release. 1210 Release. 1211 Release. 1212 Release. 1213 Release. 1214 Release. 1215 Release. 1216 Release. 1217 Release. 1218 Release. 1219 Release. 1220 Release. 1221 Release. 1222 Release. 1223 Release. 1224 Release. 1225 Release. 1226 Release. 1227 Release. 1228 Release. 1229 Release. 1230 Release. 1231 Release. 1232 Release. 1233 Release. 1234 Release. 1235 Release. 1236 Release. 1237 Release. 1238 Release. 1239 Release. 1240 Release. 1241 Release. 1242 Release. 1243 Release. 1244 Release. 1245 Release. 1246 Release. 1247 Release. 1248 Release. 1249 Release. 1250 Release. 1251 Release. 1252 Release. 1253 Release. 1254 Release. 1255 Release. 1256 Release. 1257 Release. 1258 Release. 1259 Release. 1260 Release. 1261 Release. 1262 Release. 1263 Release. 1264 Release. 1265 Release. 1266 Release. 1267 Release. 1268 Release. 1269 Release. 1270 Release. 1271 Release. 1272 Release. 1273 Release. 1274 Release. 1275 Release. 1276 Release. 1277 Release. 1278 Release. 1279 Release. 1280 Release. 1281 Release. 1282 Release. 1283 Release. 1284 Release. 1285 Release. 1286 Release. 1287 Release. 1288 Release. 1289 Release. 1290 Release. 1291 Release. 1292 Release. 1293 Release. 1294 Release. 1295 Release. 1296 Release. 1297 Release. 1298 Release. 1299 Release. 1300 Release. 1301 Release. 1302 Release. 1303 Release. 1304 Release. 1305 Release. 1306 Release. 1307 Release. 1308 Release. 1309 Release. 1310 Release. 1311 Release. 1312 Release. 1313 Release. 1314 Release. 1315 Release.

Enregistreur PCM linéaire Mode d'emploi



PCM-A10

Consultation du Guide d'aide.

Ce Mode d'emploi présente des instructions sur les opérations générales de l'enregistreur PCM linéaire... Le Guide d'aide est un manuel en ligne...

http://rd1.sony.net/help/pcm10h_uc/




Vérification des éléments fournis

- 1 Enregistreur PCM linéaire (1)
2 Câble d'alimentation HCLD-POWER (1)
3 Mode d'emploi (cette feuille)
4 Carte de garantie (1)
5 Logiciel Sound Organizer 2 (fichier d'installation enregistré en mémoire intégrée à la fonction.)

Accessoires en option

- 1 Batterie rechargeable Li-ion
2 Câble de connexion USB
3 Câble de connexion FireWire
4 Câble de connexion FireWire

Composants et commandes




- 1 Microphone intégré
2 Indicateur de niveau maximal
3 Écran
4 Touche OPTION
5 Touche T.MARK (repaire de piste)
6 Touche B.MARK + HOME
7 Touche STOP
8 Touche REC/PAUSE (enregistrement/pause), indicateur
9 Touche FICHERS/RETOUR
10 Touche HCLD-POWER
11 Touche [P] (Prépare N)
12 Touche [M] (Mode)
13 Touche [L] (Lecture)
14 Touche [R] (Recherche)
15 Touche [E] (Émission)
16 Touche [D] (Démarrage)
17 Touche [V] (Volume)
18 Touche [H] (Home)

- 19 Touche [P] (Prépare N)
20 Touche [M] (Mode)
21 Touche [L] (Lecture)
22 Touche [R] (Recherche)
23 Touche [E] (Émission)
24 Touche [D] (Démarrage)
25 Touche [V] (Volume)
26 Touche [H] (Home)

- 27 Touche [P] (Prépare N)
28 Touche [M] (Mode)
29 Touche [L] (Lecture)
30 Touche [R] (Recherche)
31 Touche [E] (Émission)
32 Touche [D] (Démarrage)
33 Touche [V] (Volume)
34 Touche [H] (Home)


Opérations de votre nouvel enregistreur PCM linéaire

Charge




- 1 Chargez l'enregistreur PCM linéaire.
2 Débranchez l'enregistreur PCM linéaire.
3 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Mise sous tension




- 1 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.
2 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Configuration initiale




- 1 Sélectionnez « Oui » pour commencer la configuration initiale.
2 Sélectionnez « Oui » pour commencer la configuration initiale.

Enregistrement




- 1 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.
2 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Profiter de sans fil pour les musiques



- 1 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.
2 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Modification de la destination de la sortie audio



- 1 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.
2 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Opérations sur un smartphone



- 1 Recherchez l'application REC Remote sur Google Play ou App Store.
2 Sur l'enregistreur PCM linéaire, sélectionnez « Bluetooth ».
3 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Suppression



- 1 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.
2 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Opérations sur un smartphone (REC Remote)



- 1 Recherchez l'application REC Remote sur Google Play ou App Store.
2 Sur l'enregistreur PCM linéaire, sélectionnez « Bluetooth ».
3 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Précautions



- 1 Ne laissez pas fonctionner l'appareil en conduisant une voiture.
2 Ne laissez pas fonctionner l'appareil en conduisant une voiture.

Précautions



- 1 Ne laissez pas fonctionner l'appareil en conduisant une voiture.
2 Ne laissez pas fonctionner l'appareil en conduisant une voiture.

Précautions




- 1 Ne laissez pas fonctionner l'appareil en conduisant une voiture.
2 Ne laissez pas fonctionner l'appareil en conduisant une voiture.

Précautions




- 1 Ne laissez pas fonctionner l'appareil en conduisant une voiture.
2 Ne laissez pas fonctionner l'appareil en conduisant une voiture.

Copie de fichiers de l'enregistreur PCM linéaire vers un ordinateur




- 1 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.
2 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Installation de Sound Organizer 2



- 1 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.
2 Appuyez sur le bouton [P] pour sélectionner le niveau sonore d'enregistrement optimal de la source sonore.

Précautions



- 1 Ne laissez pas fonctionner l'appareil en conduisant une voiture.
2 Ne laissez pas fonctionner l'appareil en conduisant une voiture.

Précautions



- 1 Ne laissez pas fonctionner l'appareil en conduisant une voiture.
2 Ne laissez pas fonctionner l'appareil en conduisant une voiture.

Précautions



- 1 Ne laissez pas fonctionner l'appareil en conduisant une voiture.
2 Ne laissez pas fonctionner l'appareil en conduisant une voiture.

Précautions



- 1 Ne laissez pas fonctionner l'appareil en conduisant une voiture.
2 Ne laissez pas fonctionner l'appareil en conduisant une voiture.

AVERTISSEMENT

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

ATTENTION

- Ne laissez pas fonctionner l'appareil en conduisant une voiture.
• Ne laissez pas fonctionner l'appareil en conduisant une voiture.

Compatibilité

- iPhone 5, iPhone 4S, iPhone 4, iPhone 3GS, iPhone 3G, iPhone 2G
• iPod touch (5e génération), iPod touch (4e génération), iPod touch (3e génération), iPod touch (2e génération), iPod touch (1e génération)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Android 4.0 ou supérieur
• iOS 7.0 ou supérieur

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Compatibilité

- Windows 10, Windows 8.1, Windows 8, Windows 7, Windows Vista, Windows XP
• Mac OS X (10.6 ou supérieur)

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur

Bluetooth

- Bluetooth 4.0 ou supérieur
• Bluetooth 4.0 ou supérieur