

imiLAB

IMILAB C20 User Manual

Read this manual carefully before use, and retain it for future reference.

Product Overview

Top view

Front view

Rear view

LEDs

MicroSD Slot

Micro USB Charging Port

Package Contents: IMILAB C20 x 1, power adapter x 1, power cable x 1, wall-mounting accessories (screw x 1, user manual x 1)

Installation

1. Mount IMILAB C20 on a wall.

2. Insert the two plastic anchors into the holes on the wall.

3. Make sure to position the base unit so that the arrow is pointing up. Secure the base unit to the wall by tightening the screws into the plastic anchors.

4. Matching the grooves on the bottom of the camera unit with the spaced slots on the bracket. Press down until the two sections are flush. Then turn the camera unit in either direction to lock it in position.

Warning:

Do not install the device in a location where it is exposed to direct sunlight or rain. The device must be securely fastened to the wall and not be tilted. Please note that the wall must be able to support at least twice the product's total weight.

Product Instructions

Turning the Device On

1. If the indicator light is flashing orange, that means the device is activated successfully.

2. Once the IMILAB C20 is turned on, please do not attempt to rotate it head by force. If the camera position is incorrect, adjustments can be made through the app.

Indicator Light

When the indicator light is on, it means the device is powered on. If the light is flashing orange, it means the device is in the process of upgrading the system.

Installing a MicroSD Card

Make sure that the power to IMILAB C20 is already disconnected. Insert the MicroSD card into the slot on the back of the device. Please note that the MicroSD card must be inserted with the gold contacts facing the device. Please refer to the MicroSD card packaging for more details.

Reset Factory Settings

Press and hold the reset button with fine needles that you can find the "Reset" button.

Install IMI Home App

Connect your phone to the IMI Home app. This product needs to be connected to the Internet. Please refer to the IMI Home app for more details.

Add Device

Open the IMI Home app. Tap "+" on the upper right. Tap "C20" and scan the QR code with the device you phone. Then you can follow the steps to add your device.

Note: The version of the app might have been updated, please follow the instructions based on the current app version.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

EU Declaration of Conformity

Shanghai IMI Technology Co., Ltd. declares that the radio equipment type IMILAB C20 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://www.imi.com.cn/global/service/support/declaration.html>

CE

Specifications

Model: IMILAB C20
Resolution: 1080P
Lens Angle: 112°
Power Input: 5V 2A

Manufacturer: Shanghai IMI Technology Co., Ltd.
Address: Room 1018, Floor 11, Block 1, No. 100 Dongchuan Road, Minhang District, Shanghai, China.
For further information, please go to www.imi.com.cn.
Support: globalcustomer@imi.com.cn

MADE IN CHINA