



Before you get started

Activate the Dash

1

To activate The Dash connect The Charger including The Dash to your computer via the USB Cable. The Dash is activated when the LightGuide flashes blue. You may now safely eject and disconnect at any time.

2

Download the Bragi App on bragi.com

3

Register your Dash through the bragi app to get full support.



Bragi App

Download it

Customize


Download the free Bragi App now to personalize and set up your Dash bragi.com/app





1

How to charge

The Dash & Charger



Place The Dash in The Charger and make sure it sits on the MagSnap.




To charge the battery, connect The Charger to your Computer or another power source via USB. The Charger fully charges The Dash up to 5 times while on-the-go.


2

How to check the battery

The Dash & Charger



full high medium low
Shake The Dash
And you will see the current battery status of your Dash.



high medium low

Check out the LED on the side of The Charger to see the current battery status. The Dash needs to be placed in The Charger or The Charger needs to be connected to a power source.


3

How to insert

The Dash

1 & 2


Take The Right Dash, tilt it slightly forward and insert the speaker tip into your ear canal. Adjust to a PerfectFit by rotating The Dash backwards until it feels comfortable and secure in your ear.



4

How to wear

The PerfectFit



3

With The PerfectFit you should feel The Dash completely closing off your ear canal while it sits snugly in your ear.


4

Achieving The PerfectFit may require some adjustment. To adjust you can use one hand to lift up in your ear and adjust with the other. By doing this you should be able to press the upper part of The Dash into a locked position as shown in the diagram above.

5


How to change

The FitSleeves




The Dash is already fitted with XS FitSleeves. Try different sizes to find your PerfectFit.

The PerfectFit is important to maximise performance of The Dash and accuracy the DataHub.



6 How to interact

Basic gestures




Left Dash	Right Dash
Track	Listen & Communicate
-	● Tap Play / Pause music
Activity feedback	●● 2x Tap Next song
Audio Transparency On/Off	↔ Swipe Volume Up / Down
Pairing mode Activity Data	5 sec Pairing mode Audio
Activity Menu Start / Exit	Hold Playlist Menu Start / Exit
Start / End activity	● Tap Select playlist
Next activity	●● Next playlist
	● Tap Answer a call
	Hold End a call
	Only R Dash inserted
	●● 2x Tap Activate standalone mode

7 How to connect


Bluetooth & The Dash

Touch and hold The Right Dash for 5 seconds to enter pairing mode. Select The Dash in your Bluetooth settings and connect.



8 What's inside the box?

The Dash



9 Manual & Registration

Reveal all features

bragi.com/support

Experience the full capabilities of The Dash & reveal all of it's exciting features.

The Dash
The Charger & The Slide

FitSleeves
XS / S / M / L

USB to Micro USB Cable

Quick Start Guide
The Dash



CE statement:

Do not use the product in the environment at too high or too low temperature, never expose the product under strong sunshine or too wet environment.

The suitable temperature for the product and accessories is 0°C-50°C.

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



Excessive sound pressure from earphones and headphones can cause hearing loss.

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction

CE 0560

Hereby, Bragi GMBH declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

FCC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

FCC RF exposure:

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction

IC statement:

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Should be translated to:

Cet appareil est conforme avec Industrie Canada RSS exemptes de licence standard(s).

Son fonctionnement est soumis aux deux conditions suivantes:

- (1) cet appareil ne peut pas provoquer d'interférences, et
- (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.

IC RF exposure:

The SAR limit of Canada is 1.6 W/kg averaged over one gram of tissue. Device types B1000H has also been tested against this SAR limit.

The highest SAR value reported under this standard during product certification for use when properly worn on the body is 0.074W/kg and for head is 0.017W/kg.