


Model: SK-01



APP5

# ELECTRIC HEATED SOCKS



Ring heating makes your feet warmer

## Packing List:



## PRODUCT PARAMETERS

Rated voltage:5V/2A      Rated power:5W  
Charging time:8-10H      Service times full power:4-13H  
Weight(g):About 510g      Single battery capacity:5000mAh  
Socks material: 22.5% viscose fiber, 52.5% nylon, 10% polyester, 15% spandex.

SIZE	Size of corresponding countries				Length of stockings(in)		
	USA	EU	UK	CHN	Length of stocking	Foot Length	Foot width
S	4-5	34-35	4-5	34-35	12.6	7.5	3.1
M	5.5-7	36-39	4.5-6	36-39	12.6	8.3	3.1
L	6.5-9	38-43	5.5-8	38-43	14.1	9.1	3.5
XL	8-11	40-46	7-10	40-46	14.1	9.8	3.5


## WASHING INSTRUCTIONS:

- 1.The water temperature should not exceed 122°F
- 2.The battery must be removed before cleaning, and the battery connecting wire must be sorted and put back into the battery bag.(note that the battery cannot ne washed with water)
- 3.Socks must be machine washed after being put into the laundry bag. It is recommended to wash them by hand.
- 4,Turn the power cord out and dry it naturally. Do not use a high-temperature iron or dry it at high temperature.

## BATTERY CONTROL INSTRUCTIONS:

1. Check the battery level of the special battery for socks, and charge them to the full state.
2. Distinguish between left and right socks and wear them correctly, keep the battery pocket on the outside of the shins.
3. When not using the product, please unplug the plug from the battery for storage.
- 4.Tie the battery to your calf, then put on socks, insert the type-C plug into the battery.
- 5.The green indicator of the battery is the power indicator, which corresponds to: four indicators: 100% power; Three indicator lights: 75% power; Two indicator lights: 50% power; One indicator light: 25% power. The red indicator light is the gear indication, which corresponds to: four indicator lights: four gears (the highest temperature gear); Three indicator lights: third gear (sub high temperature gear); Two indicator lights: second gear (medium temperature gear); One indicator light: first gear (low temperature gear).
- 6.Battery button: long button press for 3 seconds to switch the machine on and off. Short press the case to switch gears, and the default fourth gear (high temperature gear) works when starting up. Press the button gently to switch between gears 4 and 1.
- 7.After the battery is turned on, if the sock type-C plug is not inserted within 30 seconds, the device will automatically shut down. If you want to continue to use it, you need to restart it.

## Battery control instructions



\* The following data are laboratory test data at room temperature of 77°F.

Light Status	Current Mode	Reference Temperature(F)	Reference Endurance(H)
● ● ● ●	4	158±3	4.5~5H
● ● ● ○	3	140±3	5.5~6H
● ● ○ ○	2	122±3	8~8.5H
● ○ ○ ○	1	104±3	12~13H

## PRECAUTIONS:

1. It is forbidden to approach high-temperature, flammable or explosive objects.
2. Do not hit the battery with force, and do not disassemble or reassemble it.
3. If the battery is not used frequently it is recommended to recharge and activate it every 60 days.

4. It is recommended not to use high temperature for a long time to avoid skin discomfort.
- 5.Keep the battery in good condition. The battery shall be stored in a dry and cool environment.
- 6.Prevent low-temperature burns (if the human body is in a low-temperature environment, the body feels dull, and there are differences in physical fitness. Please lower the temperature in time when the body feels slightly burning.

## APP TEMPERATURE CONTROL INSTRUCTIONS:

1. Use your mobile phone to scan the QR code on the last page to download the Bluetooth temperature control APP (WARM UPING)
2. The battery must be turned on to use the app function. When it is turned off, the phone will not be able to search for the battery. After turning off the battery through the mobile app, you need to turn it on manually from the battery button.
3. Turn on the mobile phone positioning and Bluetooth functions for APP Bluetooth control.
- 4.If the mobile app app is not connected to the battery device after the battery device is powered on, please check whether other permissions of the mobile app are opened.
- 5.If you have more than two battery devices, it is recommended to turn off all devices and only turn on two battery devices for app connection to avoid confusion.
- 6.After opening the battery, open the mobile application, and the mobile application will automatically connect to the battery device without binding and manual connection.
- 7.It is recommended not to use multiple devices at the same time. Please keep the unused devices off.

## How to download APP?

1. Scan QR code below to download APP
2. Search "WARM UPING" on phone APP store



GOOGLE PLAY




APP STORE



GENERIC VERSION



## App main interface description



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction