

# APPENDIX A

## EQUIPMENT LIST AND INSTALLATION

### 1. List of Material

- Qty 1 - SelectAmp NBPCS-900-3 Paging Repeater
- Qty 1 - User's Guide (AE02B-A3659)
- Qty 1 - Programming Cable (ECABA-20058)
- Qty 1 - Adapter, DB-9 (M) to DB-25 (F) (ECNND-95003)
- Qty 1 - Power Cable, 6 ft. (ECABL-31111)
- Qty 1 - Diskettes (3) containing control software (AE04R-A5949-001)

### 2. Installation

Set the amplifier on a suitable shelf or attach the slides and mount in a 19" rack mount cabinet.

Connect the coaxial cable that is attached to the roof antenna (or other device intended to communicate with the base station) to the FWD IN / REV OUT port on the back of the amplifier.

Connect the coaxial cable that is attached to the interior antenna (or other device intended to communicate with the pagers) to the REV IN / FWD OUT port on the back of the amplifier.

Attach the supplied power cord to the power entry module at the rear of the amplifier and then plug the power cable into an appropriate outlet.

Turn the main power switch on (located at the rear of the amplifier).

Refer to Appendix B for loading the control software and programming the amplifier for operation.

It is recommended to turn down (counter clockwise) the gain adjustment pots on any unused channels.