

SENTRY

DGSP.TIKI



patient model

In flammable and explosive areas, please turn off such equipment and follow the relevant instructions to avoid explosion or fire, including areas with explosive mole in fuel areas, areas with "two-way radio equipment off". Please turn the sound in a flammable volume or turn it off, so as not to damage your health and equipment.

- [Bluetooth Audio]** Bluetooth 2.1 EDR, the maximum receiving distance is 12 meters.
- [Bluetooth call]** allows call transfer, voice address, convenient and fast.
- [MP3 playback]** directly play MP3 file played by TF card and USB memory.
- [FM Radio]** FM digital radio, radio memory broadcast.
- [Audio input]** stereo audio input interface, easily connect computers, digital music players, mobile phones and other sound source devices.
- [TWS object function]** Bluetooth of the module phone connects two audio hosts at the same time which makes the music feel more stereoscopic and realistic.




- ① Type-C ② Fluorescence ③ Charging indicator
④ USB connector ⑤ Anti-corrosion ⑥ Internal fan
⑦ Noise isolator ⑧ Screen plug

The machine automatically detects and identifies the external device when it is started, and then enters Bluetooth® FM mode. Insert T-rapid is automatically identify the latter priority principle, can also be from the Live-wireless playback mode, switch to AUX mode through the key, details please read item 4. 'Specifications and Jack Location Definitions of products'



- Adjust the light
- Long press the adding time and tap the first song in the radio station
- Mode switching
- Long press plus time and tap the last song in radio station
- Long press 3 seconds switch on and off
 - gently press play or pause
 - gently press twice to turn on the FM, otherwise

DISPTIK Bluetooth sound is suitable for outdoor and indoor use. With its support rods, the audio main body is not equipped with a rod, can be indoor, semi-outdoor, put on the table, etc.; in the state of the assembly rod of the audio main body, it can be used in some different use such as camping, lawn, outdoor, etc., inserted into the main body of underground support.



1. Fold the thread being knit at the bottom of the cast-on edge.
2. Countersink the cast knit and place the cast front and fitting.
3. Sew in the middle part of the mounting rod into the main engine.
4. Sew the front fitting of the rod into the middle fitting of the rod.

(J27) Select the IP port to ping MIPs from.

(J28) Call name, select factory or download, it can also be set as others if needed.

1. Turn on the screen, the screen key to switch Bluetooth mode, will enter a "Find"
2. Turn on the Bluetooth feature of mobile device (mobile phone, computer, etc.) and search for Bluetooth device. The display name "T4211190" appears
3. Click manually on the device, automatically pop up the connection, and if the connection successful, a "OK" will be

- Click manually on the device automatically giving the connection, and if the connection is successful, a "OK" will be opened.
- If the device is not connected successfully, try to find and automatically connect.

3. Press **Alt** to switch audio and enter FM mode.
4. Search platform: short press **Alt** key to start automatic search platform, search platform after automatic memorization the table.
5. Memory updates: after automatic search, press **[]** or **[+]** keys to select the next station at the next station.
6. Volume adjustment: long press **[]** key to reduce volume, long press **[+]** key to increase volume.

1200 model: insert the ID card into the back of the 1200 reader and push the M button on the screen in the prompt line "ID" and into the ID card product mode.
1210 model: insert the ID card into the card slot socket of the machine and press the M button on the screen in the prompt line "ID" and into the ID card product mode.

Insert the audio cable into the AUX-In port of the receiver and the other end into the mobile phone / computer / audio device output line, press M-Function key according to prompt tone "AUX" and sound, put into audio playback mode.

Single color long nose
colorful running nose long, long white long, turn off the
nose
Instructions for use
connect three lighting modules through the right function
button.

When indicator light is the charging mark, the indicator light will be on.

When the power is low, the system will automatically shut down, power change is immediately. If you do not use the machine for a long time, change at least once a month, can to extend the service and reduce the failure. The

Plug one end of the green cord into the Type II socket of the machine and the other end of the USB into the USB interface of the computer, or connect to the charging interface of the standard 3y2A The "red light" is on in the charging, and the "red light" is turned off after filling. This machine has built in overcharge protection circuit, which

Q: Turns it off automatically when it's cool?
A: The battery is not enough. Please charge it in time. It is recommended that it be used after charging for two hours.

Q: Unable to charge?
A: Please use the charging line delivered by the machine and determine the USB interface to be connected. The voltage is normal.

• **Use multiple and/or regional safety elements.** Offer guests adaptive, low-rebound seats and safety elements, and using built-in supports could prove a risk of death or injury.

1. *Country of residence*
2. *Group of countries*
3. *Group of religions*
4. *Country of residence*

10. Do not change your any health insurance until an individual, local, regional, or other appropriate coordinating organization that provides help.

11) Mating the specimens during lightning storms and other changes is complete.

11. If you have a question, is there someone you can ask for help?

11. The rate law is "first-order" in H_2O changing volume/pressure will not change the changing rate. It will change the amount available.

