

420mm

封面 (84mm)

M200 Instruction



- 本打印机为桌面式打印机，适用于家庭、办公室、学校等场所。
- 本打印机支持 A4、A5、B5、10cm x 15cm、15cm x 10cm、10cm x 5cm 等多种纸张尺寸。
- 本打印机支持 2560 x 1440 dpi 的高分辨率打印。
- 本打印机支持 USB、Wi-Fi、蓝牙等多种连接方式。
- 本打印机支持打印照片、文档、图表等多种内容。
- 本打印机支持打印彩色、黑白等多种颜色。
- 本打印机支持打印单面、双面等多种打印方式。
- 本打印机支持打印单页、多页等多种打印方式。
- 本打印机支持打印小册子、传单等多种打印方式。
- 本打印机支持打印信封、名片等多种打印方式。
- 本打印机支持打印标签、条码等多种打印方式。
- 本打印机支持打印二维码、条形码等多种打印方式。
- 本打印机支持打印名片、请柬等多种打印方式。
- 本打印机支持打印证书、奖状等多种打印方式。
- 本打印机支持打印合同、协议等多种打印方式。
- 本打印机支持打印发票、收据等多种打印方式。
- 本打印机支持打印各种办公文档、报表等多种打印方式。
- 本打印机支持打印各种宣传资料、海报等多种打印方式。
- 本打印机支持打印各种艺术作品、照片等多种打印方式。
- 本打印机支持打印各种商业文件、合同等多种打印方式。
- 本打印机支持打印各种法律文书、协议等多种打印方式。
- 本打印机支持打印各种财务文件、报表等多种打印方式。
- 本打印机支持打印各种医疗文件、报告等多种打印方式。
- 本打印机支持打印各种教育文件、试卷等多种打印方式。
- 本打印机支持打印各种科研文件、论文等多种打印方式。
- 本打印机支持打印各种工程文件、图纸等多种打印方式。
- 本打印机支持打印各种设计文件、方案等多种打印方式。
- 本打印机支持打印各种法律文件、合同等多种打印方式。
- 本打印机支持打印各种财务文件、报表等多种打印方式。
- 本打印机支持打印各种医疗文件、报告等多种打印方式。
- 本打印机支持打印各种教育文件、试卷等多种打印方式。
- 本打印机支持打印各种科研文件、论文等多种打印方式。
- 本打印机支持打印各种工程文件、图纸等多种打印方式。
- 本打印机支持打印各种设计文件、方案等多种打印方式。

01. Product Introduction - Part and Features

Part Name	Function
Power Button	Turns the printer on or off.
Display Panel	Shows the printer's status and settings.
Control Panel	Allows you to navigate through the printer's menu.
Print Button	Starts the printing process.
Cancel Button	Stops the printing process.
Pause Button	Pauses the printing process.
Resume Button	Resumes the printing process.
Back Button	Returns to the previous menu.
Home Button	Returns to the home screen.

02. Product Specifications

Specification	Value
Model	M200
Color	Color / Black
Resolution	2560 x 1440 dpi
Print Speed	10 pages per minute
Print Volume	1000 pages per month
Connectivity	USB, Wi-Fi, Bluetooth
Power Consumption	10W
Dimensions	100mm x 100mm x 100mm
Weight	100g

03. Product Introduction - Part and Features

Part Name	Function
Power Button	Turns the printer on or off.
Display Panel	Shows the printer's status and settings.
Control Panel	Allows you to navigate through the printer's menu.
Print Button	Starts the printing process.
Cancel Button	Stops the printing process.
Pause Button	Pauses the printing process.
Resume Button	Resumes the printing process.
Back Button	Returns to the previous menu.
Home Button	Returns to the home screen.

04. Product Introduction - Part and Features

Part Name	Function
Power Button	Turns the printer on or off.
Display Panel	Shows the printer's status and settings.
Control Panel	Allows you to navigate through the printer's menu.
Print Button	Starts the printing process.
Cancel Button	Stops the printing process.
Pause Button	Pauses the printing process.
Resume Button	Resumes the printing process.
Back Button	Returns to the previous menu.
Home Button	Returns to the home screen.

05. Product Introduction - Part and Features

Part Name	Function
Power Button	Turns the printer on or off.
Display Panel	Shows the printer's status and settings.
Control Panel	Allows you to navigate through the printer's menu.
Print Button	Starts the printing process.
Cancel Button	Stops the printing process.
Pause Button	Pauses the printing process.
Resume Button	Resumes the printing process.
Back Button	Returns to the previous menu.
Home Button	Returns to the home screen.

06. Product Introduction - Part and Features

Part Name	Function
Power Button	Turns the printer on or off.
Display Panel	Shows the printer's status and settings.
Control Panel	Allows you to navigate through the printer's menu.
Print Button	Starts the printing process.
Cancel Button	Stops the printing process.
Pause Button	Pauses the printing process.
Resume Button	Resumes the printing process.
Back Button	Returns to the previous menu.
Home Button	Returns to the home screen.

07. Product Introduction - Part and Features

Part Name	Function
Power Button	Turns the printer on or off.
Display Panel	Shows the printer's status and settings.
Control Panel	Allows you to navigate through the printer's menu.
Print Button	Starts the printing process.
Cancel Button	Stops the printing process.
Pause Button	Pauses the printing process.
Resume Button	Resumes the printing process.
Back Button	Returns to the previous menu.
Home Button	Returns to the home screen.

08. Product Introduction - Part and Features

Part Name	Function
Power Button	Turns the printer on or off.
Display Panel	Shows the printer's status and settings.
Control Panel	Allows you to navigate through the printer's menu.
Print Button	Starts the printing process.
Cancel Button	Stops the printing process.
Pause Button	Pauses the printing process.
Resume Button	Resumes the printing process.
Back Button	Returns to the previous menu.
Home Button	Returns to the home screen.

09. Product Introduction - Part and Features

Part Name	Function
Power Button	Turns the printer on or off.
Display Panel	Shows the printer's status and settings.
Control Panel	Allows you to navigate through the printer's menu.
Print Button	Starts the printing process.
Cancel Button	Stops the printing process.
Pause Button	Pauses the printing process.
Resume Button	Resumes the printing process.
Back Button	Returns to the previous menu.
Home Button	Returns to the home screen.

297mm

封面 (74.25mm)

色值:

	C(%)	M(%)	Y(%)	K(%)
Black	0	0	0	95
Red	20	100	100	0
Yellow	0	10	85	0

材质:

80克书写纸

工艺:

双面印刷/折叠

单页尺寸:

420×297mm(A3纸)

折叠要求:封面在上

封面 (84mm)



标题: M200 英日德中性说明书-A3纸折叠


图纸编号:

制图者	比例	1:1
时间	材料	
审批	大小	

专利及保密协议:

这份图纸的所有信息，包括版权、设计及其他知识产权均属于珠海趣印科技有限公司所有。此文件的条款不赋予你使用及复制产品，或拥有产品所有权的权利。上列权利均属于珠海趣印科技有限公司所有。未经珠海趣印科技有限公司书面同意，严禁在任何情况下复制、披露、转载产品信息。

M200 Instruction




- ① Please read this instruction carefully before using this product and keep it properly.
- ② 本製品を使用する前に説明書もしっかりお読みください。
- ③ Bitte lesen Sie dieses Handbuch sorgfältig durch, bevor Sie dieses Produkt verwenden.
- ④ Veuillez lire attentivement ce manuel avant d'utiliser ce produit et le conserver correctement.
- ⑤ Si prega di leggere attentamente questo manuale prima di utilizzare questo prodotto e conservarlo correttamente.
- ⑥ Por favor, lea cuidadosamente este manual antes de usar este producto y guárdelo adecuadamente.



- ① Multilingual detailed instruction manual
- ② 多言語詳細説明マニュアル
- ③ Detaillierte Anleitung in mehreren Sprachen
- ④ Edition détaillée de la notice en plusieurs langues
- ⑤ Istruzioni dettagliate multilingue
- ⑥ Manual de instrucciones detallado multilingüe

Language switching | 言語の切り替え | Sprachwechsel | Changement de langue | Cambio di lingua | Cambio de idioma

- ① Click the button to select the language and click the button to switch the language.
- ② ③ボタンをワンクリックして言語を選択し、④ボタンをワンクリックして言語を切り替えます。
- ④ Klicken Sie auf die Taste , um eine Sprache auszuwählen, klicken Sie auf die Taste , um die Sprache zu wechseln.
- ⑤ Cliquez sur le bouton pour sélectionner la langue, puis sur le bouton pour changer la langue.
- ⑥ Haga clic del pulsante , seleccionar el idioma, haga clic en el botón para cambiar el idioma.



Contains three languages: English, Japanese, German

English

01. Item Checklist




The number of paper rolls in the list is subject to the actual shipment.

02. Product Specifications

Name	Multifunctional Portable label Maker
Model	M200
Technology	Thermal Printing
Width of label	20-75mm
Supported Consumables	Black mark thermal Label, Pre-cut Label, Continuous Label
Consumable specifications	80mm x ϕ50mm (Max width + Max diameter)
Printing speed	30-50mm/s
Darkness	1-15 levels
Resolution	203dpi
Printhead Lifespan	500K
Communication Port	Bluetooth / Data wire
Product Dimensions	120*117*60mm (4.92*4.58*2.3in)
Power Input	5V = 2A
Power Supply	Data wire / Lithium battery
OS Supported	Android / iOS
Command set	ESC / PDS
Barcode	1D barcode and QR code are supported
Working environment	5℃~50℃
Storage environment	-20℃~60℃
Working humidity	20%~85%
Storage humidity	20%~95% (Not frozen)

03. Product Introduction - Parts and Features



Button functions

Diagram	Button	Instruction	Function
	Power Button	Long press 3s Press once	Switch on/off Switch between the main menu pages, Eject one label and reposition the label paper to the head of the next label.
	Eject Button	Long press (for Continuous paper) Hold for 3 seconds	Hold to eject paper. Release to stop. Return to the main menu.
		Continuous click	1. After switching to the desired main menu page using the Power Button, press Eject Button to go through the sub-menu. 2. Press once to eject one sheet of paper when the printer is in standby mode.

04. Parts Description

Main Menu - Settings


Options	Parameters (Contents)
Language	Chinese, English
Ink Intensity	1(weakest), 2, 3, 4(weak), 5, 6 (Normal), 7, 8, 9, 10 (Dark), 11, 12, 13, 14, 15 (Darkest)
Print speed	1 (Slowest), 2 (Slow), 3 (Normal), 4 (Fast), 5 (Fastest)
Paper Type	Non-continuous paper, Continuous paper, Black mark thermal paper
Automatic Shutdown	15 minutes, 15 minutes, 30 minutes, 1 hour, 2 hours, 4 hours, 8 hours, 24 hours, Stay on (Default)
Factory Reset	Restore to default factory configuration
Firmware version	Show firmware version
Device address	Show device address

05. Paper Roll Installation

- ① Slide down the Open-Cover Button to open the paper compartment cover.
- ② Take out the paper holder inside the compartment.
- ③ Remove the left disk and insert the label roll (with the printing side facing down). Insert the left disk and push it to the right.




- ④ After the label holder is complete, insert the holder into the paper compartment.




- ⑤ Pull out around 15 mm of paper and close the paper compartment cover.



- ⑥ Hold the Power Button for 3 seconds.



- ⑧ The label paper is repositioned once it comes out.




On your first use or after you have replaced the label paper, the printer automatically ejects paper to reposition the label paper. This helps avoid printing errors (incomplete print, non-centered content, etc.).

06. App Download Method

NOTE


- On your first use or after you have replaced the label paper, the printer automatically ejects paper to reposition the label paper. This helps avoid printing errors (incomplete print, non-centered content, etc.).

Method I:
Use your phone to scan the QR code to install the App



07. Connecting the Printer

- ① Turn on GPS, Location Services (Android phones only)
- ② Open Print Master
- ③ Tap the button to search for your device.
- ④ Press "Start using"




This product needs to be connected to the printer in the App after the Bluetooth is turned on.
According to the official requirements of Google, Android mobile phones need to open the GPS permission before they can use the Bluetooth function.

- When connecting the App, please make sure that the printer is turned on and the Bluetooth of the mobile phone is turned on.

08. Identifying the Label Size

The App is required to set the label size or template before printing. Please follow the instructions to download it.

Method I:
Check your label package.



09. FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not used and properly shielded, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- *RF warning for Portable device:
- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.

10. IC Caution

Radio Standards Specification RSS-Gen, Issue 5- English:
This device contains a license-exempt radio transmitter (y receiver(s)) that comply with Industry Canada's RSS-247, Class 2, license-exempt RSS (y receiver(s)).
(9) Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-French-


Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

Cet appareil ne doit pas causer d'interférences.
Le fonctionnement de cet appareil est soumis aux deux conditions suivantes: susceptibles de provoquer un brouillement indésirable de l'appareil.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

日本語


01. パッケージ内容



注意

商品箱に貼られるローラ紙の数は実物と異なる場合があります。

02. 製品外観紹介



ボタン紹介

アイコン	ボタン名称	操作方法	機能
	電源ボタン	3秒長押し 1回押す	電源オン/オフ メインメニューに切り替え
	用紙送りボタン	1回押す ダブルクリックはアラーム音が鳴ります アイコン付き機能説明書に次のページを印刷	ラベルを1枚送り用紙を排出し、調整用紙の次ページを印刷
	用紙送りボタン	長押し (連続印刷の場合) 調整用紙の次ページを印刷し、調整用紙を印刷	調整用紙を印刷し、調整用紙を印刷
	用紙送りボタン	3秒長押し	メインメニューに戻る
	用紙送りボタン	1回押す	電源ボタンでメインメニューに切り替え後、用紙送りボタンを押すとサブメニューに切り替える 2. スリープ中に1回押すと用紙を1枚送る


03. 部品について

ディスプレイ設定メインメニュー

オプション	パラメーター (内容)
言語	中国語、英語
印刷濃度	1(最も薄い) 2, 3, 4(薄い) 5, 6 (標準) 7, 8, 9, 10 (濃い) 11, 12, 13, 14, 15 (最も濃い)
印刷速度	1(最も遅い) 2(遅い) 3(標準) 4(速い) 5 (最速)
用紙の種類	タイプライター用紙、連続紙、アイマーク付き用紙
自動電源オフ	5分、15分、30分、1時間、2時間、4時間、8時間、24時間、オフ(しない/いつでも)
初期化する	工場出荷時の状態に戻す
ファームウェアバージョン	ファームウェアのバージョンを表示する
IPアドレス	IPアドレスを表示する

04. 用紙をセット方法


- ① カバーを開閉ボタンを下に押してラベル紙トレイのカバーを開けてください。




- ② 用紙のナールを右側へ入れてください。印刷面を下にする。





- ③ 用紙のナールを右側へ入れてください。印刷面を下にする。



- ④ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑤ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。



- ⑥ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑦ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑧ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。





- ⑨ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑩ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。



- ⑪ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑫ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑬ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。



- ⑭ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。



- ⑮ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑯ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑰ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




- ⑱ 用紙の一部を開けたカッターを右側のほ込み位置に合わせて紙トレイにセットしてください。




02. 本製品の説明書の読み方




- ① 本製品の説明書をよく読んでください。




- ② 本製品の説明書をよく読んでください。




- ③ 本製品の説明書をよく読んでください。




- ④ 本製品の説明書をよく読んでください。




- ⑤ 本製品の説明書をよく読んでください。




06. 本製品の説明書の読み方




- ① 本製品の説明書をよく読んでください。




- ② 本製品の説明書をよく読んでください。



- ③ 本製品の説明書をよく読んでください。




- ④ 本製品の説明書をよく読んでください。




- ⑤ 本製品の説明書をよく読んでください。



06. 本製品の説明書の読み方




- ① 本製品の説明書をよく読んでください。



- ② 本製品の説明書をよく読んでください。




- ③ 本製品の説明書をよく読んでください。




- ④ 本製品の説明書をよく読んでください。




- ⑤ 本製品の説明書をよく読んでください。



06. 本製品の説明書の読み方




- ① 本製品の説明書をよく読んでください。



- ② 本製品の説明書をよく読んでください。



- ③ 本製品の説明書をよく読んでください。



- ④ 本製品の説明書をよく読んでください。



- ⑤ 本製品の説明書をよく読んでください。

