


Qingping Technology (Beijing) Co., Ltd.
Address: Room 401, Block B, Fangsheng Times Square, No. 1
Wangjing Street, Chaoyang District, Beijing 100102, China
Website: qingping.co
Email: support@qingping.co



Insert Battery

Press the battery cover with two thumbs on the back of the device, turn it counterclockwise to unlock and remove the battery cover.

Insert a CR2032 button battery into the compartment and put back the battery cover — turn it clockwise until it clicks shut. And LEE GLITARS Bluetooth Thermo-Hygrometer will start automatically.



Connect to Lee Guitars App

Please visit gingling.co/lee-guitars/app or scan the QR code below to download the app:



Note: when connecting to the app, make sure Bluetooth of your phone is enabled. There should be no obvious obstacle between the phone and the LEE GUITARS Bluetooth Thermo-Hygrometer. And the distance between these two devices should be less than 5 meters.

Change Temperature Unit


Press the button on LEE GUSTARS Bluetooth Thermo-Hygrometer to switch the temperature display unit to Fahrenheit (°F) or Celsius (°C).

Supported Instruments

LEE GUITARS Bluetooth Thermo-Hygrometer can be used for acoustic guitar with different sizes as well as other instruments. We suggest to remove the LEE GUITARS Bluetooth Thermo-Hygrometer from your instrument while closing

Setup LEE GUITARS Bluetooth Thermo-Hygrometer

Attach the screen of LEE GLITARS Bluetooth Thermo-Hygrometer on the edge of guitar's sound hole, then bend the middle part and put the sensor into the sound hole, as well as you can rotate the extended side by side.



Specifications:

Model: CGM1
Weight: 30 g (battery not included)
Size: 131 x 37 x 12.4 mm
Screen Size: 26 x 20 mm
Wireless Connectivity: Bluetooth® S.O.
Temperature Measuring Range: 0°C – 50°C
Humidity Measuring Range: 0–99%RH (non-condensing environment)
Battery: CR2032
FCC ID:

Attention

- Do not block the vent hole of the sensor.
- This product is not waterproof or dust-proof.
- Do not use the product for too long in an environment where humidity is greater than 90%.
- Do not throw the battery or the product with the battery into the fire to avoid an explosion.
- Do not disassemble the product by yourself to avoid injury.
- When you don't use this product for a long time, please take out the batteries to avoid the damage caused by the possible battery leakage.

FAQ

Question	Answer/Solution
No content shows on the screen	Please check whether the battery is placed correctly. If it is, please replace it.
E1 shows on the screen	The environment temperature exceeded the measuring range of the product. Please put the product in a normal indoor environment.
E2 shows on the screen	The temperature and humidity sensor is malfunctioning.

Performance Faults

When a battery with sufficient power is correctly placed in the product, the screen of the product still does not display any content, or the content displayed on the screen is abnormal.

When the specified app is correctly installed on the mobile phone and Bluetooth of the mobile phone is on, and the distance between the mobile phone and the product is in the Bluetooth transmission range, the app still unable to connect the product.

The button cannot be pressed down, or cannot bounce back after releasing.

When the temperature and humidity in the use environment are stable and haven't exceeded the measuring ranges of the product, the product still can correctly display the temperature and humidity readings.

Warranty

In the countries and regions where Qingting Technology (Beijing) Co., Ltd. has established branches or after-sales service centers, we provide a 3-year limited warranty service for the locally sold LEE GUITARS Bluetooth Thermo Hygiene. The warranty service terms are:

1. Within 7 days from the date of the receipt, if the product has faults that listed in the "Performance Faults", after the faults are confirmed by our after-sales service department, the customer can have the refund or exchange the product for free.
2. From the 8th to the 15th day after the receipt, if the product has faults that listed in the "Performance Faults", after the faults are confirmed by our after-sales service department, the customer can have a replacement or repair service for free.
3. Within 12 months from the date of receipt, if the product has faults that listed in the "Performance Faults", after the faults are confirmed by our after-sales service department, the customer can have the maintenance service for free.

Non-warranty

1. Unauthorized repair, misuse, collision, negligence, abuse, liquid injection, accident, alteration, improper use of accessories not originally supplied with this product.
2. The warranty period has expired.
3. Damage caused by force majeure.
4. The situation does not meet the fault listed in the Performance Faults.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.