



Run the following C# code, download and install the App.



Charging the device to active halts the first time using. To charge your device, plug the charging cable into the socket or USB port on your computer.




Open the App and set up your profile



The diagram shows four main menu categories arranged around a central point:


- Messages** (top): Includes "Swipe Down", "Swipe Up", "Swipe Left", and "Swipe Right".
- Music** (left): Includes "Swipe Left", "Swipe Right", "Swipe Down", and "Swipe Up".
- Custom** (right): Includes "Swipe Left", "Swipe Right", "Swipe Down", and "Swipe Up".
- Control Center** (bottom): Includes "Swipe Down", "Swipe Up", "Swipe Left", and "Swipe Right".

After connecting I have sent WhatsApp to the phone, you remove the watch in that moment the phone for making calls, understanding the phone calls, you can also see the call history of the watch, you need to keep the connection between the watch and the phone stable otherwise the iPhone Call function.



Click on the **Input** input interface to measure the current blood oxygen value


More **result** analysis and data recording can be viewed in the client



Smart Watch automatically tracks blood glucose on the screen.




The device can sync incoming notifications from Twitter, Facebook, Whatsapp, Instagram etc. Recently 5 messages can be stored.



After connecting the device, you can remote-control the music player on your phone.

Other Features
Other features include stopwatch, alarm, timer, brightness, mode on/off, theater mode, factory reset, power off and about.



Warning to Move
The device will vibrate to remind you to make a relax after 1 hour sitting.

Note: You can switch on/off the feature in the APP.



1. Using in Wet Conditions
Your device is water-resistant, which means it is rain-proof and splash-proof and can stand up to even the sweatiest workout.
NOTE: Do not swim with your Smart Bracelet. We also don't recommend showering with your wristband, though the water won't hurt the device, wearing it 24/7 does not give your skin a chance to breathe. Whenever you get your bracelet wet, dry it thoroughly before putting it back on.

2. Using Quick View

With Quick View you can check the time or the message from your phone on your Smart Bracelet without tapping. Just turn your wrist towards you and the time screen will appear for a few seconds.

1.Environmental Conditions
Operating temperature: 14°F to 122°F (-10°C to 50°C)
Non-operating temperature: -4°F to 140°F (-20°C to 60°C)

Please kindly be aware that it is the consumer's responsibility to properly dispose and recycle Smart Bracelid and accompanying components. Do not dispose of Smart Bracelid with common household waste, the Smart Bracelid unit is considered electronic waste and should be disposed of at your local electronic equipment collection facility.

For more information, please contact your local electronic equipment waste management authority or the retailer where you bought the product.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause there to be interference to other devices. It is guaranteed that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

