


封面 (74.25mm)

User's Guide
P3100D




Thank you for choosing our products!
Please read this instruction carefully before using this product and keep it properly.

Contents		
01	02	03
Packaging List	Product Specifications	Parts Description
04	05	06
Guidance on Switching on the power supply	App Download Method	Installation for Label Tape
07	08	09
Printer Connection	Print Head Cleaning	Instruction for Replacing Cutter Holder
10	11	12
FCC Caution	Solutions for Common Problems	After-sale Support











































02.Product Specifications	
Product name	Portable label maker
Product model	P3100D
Version	Alkaline battery version
Printing technology	Thermal transfer printing
Width for label tape	6mm, 9mm, 12mm
Type for supported label tape	Continuous label and can be cut in different lengths
Printing density	Light, standard, dark
Printing resolution	180 dpi
Print head service life	50 KM
Communication interface	Bluetooth 4.2
Product size	145*143*57mm (5.72*5.69*2.2inch)
Input power	9V=2A
Power supply mode	Adapter Alkaline battery
Supported operating system	Android iOS



03.Parts Description		
Button	Operation method	Functions
Power button	Long press for 3 seconds Double click	Turn on/off Print the self-checking label

Indicator light		
Indicator light	State	Description
Power indicator light	Blue light is frequently on	Normal status
	Orange light flashing quickly	Please check whether the label tape is installed properly. Press the cutter key during printing.
	Blue light is frequently on	Battery power is less than 10%
	Blue light flashing slowly	Battery power is less than 5% and cannot support printing.
Bluetooth indicator light	Blue light is frequently on	Connected to USB or Bluetooth
	Blue light flashing slowly	No device is connected

04.Guidance on Switching on the Power Supply		
NOTE		
A. This label maker is powered by adapter or AAA alkaline batteries, but it does not support charging. B. This label maker is NOT equipped with batteries. You need to purchase 6 standard AAA alkaline batteries, or it may have a shorter printing time and worse printing effect. C. This product is NOT equipped with an adapter. It is recommended to purchase 902A adapter that complies with CE/CCC certification. D. If install the AAA batteries and insert the adapter at the same time, the battery power will not be consumed. After unplugging the adapter, it will automatically switch to the battery power supply. E. After printing, please remove the AAA batteries to prevent this label maker can not be used normally because of the alkaline battery's corrosion. F. If the battery power is low, kindly replace all six batteries at the same time.		



封面 (74.25mm)

Power Button and Indicator Light

06.Installation for Label Tape

09.Instruction for Replacing Cutter Holder

10.FCC Caution

03.Maschinenbeschreibung

06.Montage des Farbbandes

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

01.Packaging List

02.Product Specifications

07.Printer Connection

11.Solutions for Common Problems

01.Auspackenliste

02.Produktspezifikationen

07.Druckerverbindung

08.Kopfreinigung Drucken

08.Kopfreinigung Drucken

08.Kopfreinigung Drucken

08.Kopfreinigung Drucken

02.Product Specifications

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

03.Maschinenbeschreibung

04.Anleitung zum Einschalten

05.App - Herunterladen

06.Montage des Farbbandes

07.Druckerverbindung

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters

10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

03.Parts Description

04.Guidance on Switching on the Power Supply

05.App Download Method

06.Installation for Label Tape

07.Printer Connection

08.Kopfreinigung Drucken

09.Anweisung zum Auswechseln des Messerhalters


10.Fehlerbehebung

11.Farbbandfach

12.After-sale Support

13.After-sale Support

包装工艺: 折叠

除非另有说明，否则公差按下表：				产品型号		ZEGUAN泽冠 珠海泽冠科技有限公司					
尺寸标注	CLASS A	CLASS B	CLASS C	P3100D产品 (英德)							
<6.0	±0.5	±1	±2								
6.0~30.0	±0.5	±1	±2								
30~120	±0.5	±1	±2								
120~400	±0.5	±1	±2								
400~1000	±0.5	±1	±2	名 称		说明书		材 料		80g书写纸	
设 计	乐晓凯20210813			料 号		30400300322		颜 色			
确 认	乐星20210813			版本号		A0		比 例		1:1	
审 核	彭理艳20210813			第三角度投影						第 1 张 共 1 张	