

only, the actual product may vary. Please refer to the actual product.





The measurement starts after the green indicator light at the bottom is on, and is completed after the vibration occurs in about 30~60s. The measurement is based on PPG technology.



Blood oxygen monitoring

he measurement starts after the red indicator light at the bottom is on, and is completed after the vibration occurs in about 30~60s. The measurement is based on PPG technology.



records and shows your sleep status that day. The data is updated every day and synchronized



Get active your way by choosing your favorite workout modes, including hiking, running, climbing, cycling, basketball, yoga and elliptical and so on.



Select the corresponding time, and follow the prompts on the watch until it is completed.



Set your gender to female in the app and add information about the menstrual period. You can set up a period reminder with app.

06:00 -- 0

Find the alarm function in the list and add alarm clock according to the corresponding settings.



06:30 ...

Click the triangle icon to start and click again to pause (the left icon means resetting).



Count down from a specified time with the timer, and it ends with the vibration reminder.



Turn on notification reminder in the app and open the music player on the watch to control music playback.



Long press the home screen to switch watch faces. You can install hundreds of different watch faces on your watch through the app, or customize your favorite picture as a watch face.



Select a menu style in watch settings. The menu supports list mode and smart mode.



Long press button for 3s to power on. The watch will automatically power on when it is charging. Choose 'Power Off' in the watch setting and click √ icon to shutdown.



View the Bluetooth name, Mac address, Firmware version number and other information of the



All personal data will be removed if you confirm to restore factory settings.



Warranty card

Date	Malfunction	Process result



Packing list



Specifications



Product model: C1 PROS

Battery capacity: 280mAh

Working temperature: -10°C~50°C

Waterproof rating: IP68

Synchronization method: Bluetooth Resolution: 240×296



Sensor: 3-axis G-sensor

Battery life: about 7-10 days

Compatible system: IOS 12.0 or above, Android 6.0 or above



22 XINII

Smart Watch Charging Watch Bands User Manual



Please read the instructions before use • The watch has a water resistance • Charge the battery for two hours

- In the watch has a water resistance rating of SATM. It can be used normally in daily life such as washing hands, raining, etc. Do not put the watch in hot water, do not perform underwater pressing operations or door before. We have the watch and the end of the above the properties of the proper deep diving. Not recommended to charging cable magnetically sticks to • The waterproof function is not properly.
- permanently effective, and the Please use the charger with an input protective performance may be reduced due to daily wear and tear.

 voltage of 5V/1A or 5V/2A and XINJI's original charging cable.
- Do not disassemble the product or replace the battery without authorization. If the product falls, please contact the after-sales any medical condition. Detection Avoid touching the screen surface with sharp or sticky objects to avoid damage. Avoid dropping the product on the ground or both stropping the product of the ground or both stropping the ground or
- The company reserves the right to change or modify all the information at void exposing the watch to corrosive liquids to avoid damage to consolve liquids to avoid damage. may vary in specific software versions.

APP download & login



IOS12.0 or above /Android6.0 or above);



OnWear Pro App download 1. Get OnWear Pro app in the App Store on your iPhone.

2. Get OnWear Pro app in Google Play on your Android phone. 3. Or scan the QR code in the watch to download the APP (compatible:

After installing the APP, please register and log in according to the interface prompts, and turn on Bluetooth at the same time:

In the Device interface of OnWear Pro app, select the Bluetooth name: "XINJI-C1PROS" for binding, and the watch can be used normally.

Method of operation



From the home screen, swipe up from the bottom of the screen to enter the function menu list interface



From the home screen, swipe down from the top of the screen to enter the the information list interface.



From the home screen, swipe left from the right of the screen to enter the interface of steps, heart rate, sleep and other interfaces.



From the home screen, swipe right from the left of the screen to enter the fast interface.



Check the corresponding date for the day, including steps, distance, and calories.







Turn on notification reminder and call reminder in the app, and information received by the mobile phone will be pushed to the smart watch ynchronously. The watch can store multiple pieces of information.

urn on Weather Push in the app, and the weather will be automatically synchronized to the



Min-porari

Language Assistant fter the watch is connected to the mobile APP, the language assistant function can be used

After the watch is connected to the mobile APP,

find the frequently used contacts in the settings,

After connecting the APP, match the watch

Bluetooth with the mobile phone, the Bluetooth

display connection state, you can call from the

and add contacts as required.

说明书折页 128克双面铜版, 4C印刷, 正反14P风琴折, 490×70mm

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

