


User Manual

DF created with pdfFactory Pro trial version www.pdffactory.com

Understanding Your Watch



Steps for Use

You can follow these steps to use :

1 Wear \rightarrow **2** Power On \rightarrow **3** Set up \rightarrow **4** Start Using

The following steps will take approximately 5 to 10 minutes, please schedule a suitable time.

1 Wear Your Watch

For optimal data accuracy, please observe the following guidelines while wearing the watch:

1. Wear the watch at a position approximately two finger-widths from your wrist bone.


2. For comfort, adjust the band to allow a finger's width between it and your wrist. This ensures both contact and fit.



2 Power On

Press the Digital Crown until the startup screen appears.

Note: If the watch can't power on, it may be because the battery has drained due to long periods of inactivity. Please charge it for approximately 10 minutes and wait for it to power on automatically



3 Set up the Watch

Step 1: Download the Fitbeing app



Go to the app store on your phone, search for Fitbeing, and install it.

· For Android phones, go to the Google Play.

· For iPhone, go to the App Store.



You can also scan the QR code on the left to quickly go to the Fitbeing app in the app store, and install it.


Step 2: Pair with the App

Open the Fitbeing app and select "Set Up a Device" on the home page. Follow the instructions to pair your via Bluetooth. Then you can start using the watch.

Attentions:

1. To prevent connection issues between the app and the watch, please do not pair directly within the Bluetooth device list in your phone's system settings.

2. To ensure successful pairing, please grant Fitbeing App permissions to access Bluetooth, Location, and Camera on your phone.






4 Get Started

Touchscreen Operation

Support full-screen touch (swipe, tap, touch and hold)



Press crown

1. Press the digital crown to wake up the screen. 2. Press the digital crown to enter the app

center from the watch face screen.

3. Exit the app

Rotate crown

1. Toggle between screens or navigate through menus.

2. Adjust the volume of prompt tones and phone calls.

Press the button

- 1. Press to start Workout quickly.
- 2. Long press to activate SOS.

Common Functions



Notification Center

Swipe down on the watch face screen.

Change the Watch Face


To change the watch face, press and hold the screen for 1 second to access the watch face gallery.



Control Center

To access the Control Center, swipe up on the watch face screen. Enable features like Silent Mode, Sleep Mode, Always-on Display, and adjust brightness and volume swiftly.

English 3





Record Workouts

To start your workout recording, access the Workout app and select a specific workout.

For outdoor workouts, wait in an open area until the GPS connects. The blinking icon "••• " shows it's acquiring a location fix and will stop blinking upon success.

Tiles

To switch quickly between the Suggestions, Activity, Heart Rate, Sleep, Weather, or Workout tiles, swipe left or right on the watch face screen.

Health Metrics Measurement

ا 🕫 ال

When wearing the watch, it automatically measures health data such as heart rate, sleep, stress, and activity. You can also view and track this data in the application.

4:21

Face Gallery

New Faces >




Install New Watch Faces

In the Fitbeing app, navigate to the Face Gallery page to pick up your preferred watch face.


PDF created with pdfFactory Pro trial version www.pdffactory.com

Charge the Watch

To charge the watch, connect the charging cable to a USB power source. Attach the other end to the charging contact on the back of the watch. The watch will display a charging icon while it is being charged.



Change the Band



Note:

Make sure the USB charging plug is at the same side as the crown.

Ensure to use a standard USB power source with an output of 5V - 1A or above.

Prior to charging, ensure to clean the charging contacts of the watch to eliminate any lingering sweat or moisture.

Remove band

1. Lift the spring bar from the groove.

Push and hold the spring bar.
Pull it out gently to remove the band.


Install band

1. Insert the metal pin at position " A" in the hole.

2. Push and hold the spring bar.

3. Press the band into the body and release the spring bar.

4. Pull the watch band to confirm the firm installation.





Wear and Care

• It is advised to remove the watch for approximately one hour daily. If you experience discomfort or irritation like redness, tingling, or a burning sensation, take off the watch and rest your wrist.

• To maintain hygiene, regularly clean your watch and wrist, particularly after workouts and sweating. Avoid using hand soap, shower gel, dishwashing liquid, or cleaning wipes as they can cause skin irritation. Instead, use mild soap and fresh water to clean the band.

Specifications

Product Name	SMART WATCH
Display	1.75 inch IPS
Resolution	240*296
Battery Capacity	380 mAh
Wireless Connection	Bluetooth 5.3
Water resistance	IP68
Satellite positioning	GPS+BDS
Body Dimension	45*53*13.5mm
Working Temperature	0°C ~ 50°C
Compatible Operating Systems	iOS 13.0 and above, Android 9.0 and above

6 English



Scan the QR code to download Fitbeing.

*This product is not designed to be a medical device, and is not intended to diagnose, treat, cure or prevent any disease. All data and measurements should be used for personal reference only.

All images on the packaging are for reference only, the actual product may differ from images on the packaging (including but not limited to colors, shape, and screen display).

Battery warning: Do not disassemble, puncture, crush, heat, or burn.



Made in China

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment for portable condition. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.