



# INTELLI PUSHER AND RECEIVER OPERATIONS Installation Instructions




**INTELLI PUSHER** THE PUSHER HAS A ADJUSTMENT SCREW FOR ADJUSTING DISTANCE TO SENSE TRAVEL. THE PUSHER IS PRESET TO APPROXIMATELY 3/4" to 3".

**PADDLE OPERATION** THE PUSHER WILL SIGNAL (BEEP) ONCE EVERY TIME THE PADDLE IS SLIDE FORWARD BY THE SELECTED DISTANCE UP TO 4 TIME IN A 10 SECOND PERIOD PADDLE WILL ALARM FOR 5SEC. IF THE PADDLE SLIDE MORE THAN 4X THE PRESET DISTANCE IN SINGLE MOTION, THE PADDLE WILL SEND A SILENT RF SIGNAL TO THE ECHO BOX RECIEVER TO ALARM FOR 5 SEC. NOTE THE DISTANCE CAN BE CHANGED WITH THE ADJUSTMENT SCREW. THE PADDLE IS INOPERATIVE WHEN PUSHED BACK FOR STOCKING TO PREVENT FALSE ALARMS. THE LED LIGHT WILL BLINK EVERY TIME THE PUSHER BEEPS OR ALARM.

Auxiliary terminals  
R-SONR-REC-PXA




No auxiliary terminals  
R-SONR-REC-XA



Illustrated above is showing a receiver with and without wire terminals.  
Both the Hook and Receiver run on batteries, which are included.  
Hook uses a CR2430 and the receiver uses 3 AAA batteries

R-SONR-REC-PXA System Connections



**OPERATION MODES FOR THE R- SONR-REC-XA AND R-SONR-REC AUDIO BEEP AND ALARM "A" MODE** THE RECEIVER'S AUDIO IN "A" MODE WILL MIMIC THEPUSHER BEEP AND ALARM. THE OUTPUTTERMINALS WILL ALSO ACTIVATE WHEN IN THE ALARM SEQUENCE. THE RESET BUTTON WILL TURN THE ALARM OFF ON THE RECEIVER ONLY. THE PUSHER WILLCONTINUE TO ALARM FOR 5 SECONDS.  
**"B" MODE** THE RECEIVER AUDIO IN "B" MODE WILL ONLY MIMIC THE PUSHERBEEPS WITH NO ALARM SEQUENCE ATTHE RECEIVER. AUXILIARY PORTS WILLSTILL ACTIVATE WHEN RECEIVING AN ALARM SIGNAL FROM THE PUSHER ALARM.

**R-SONR-REC-XA RECEIVER** WILL ONLY ALARM AND BEEP.

**R-SONR-REC-PXA RECEIVER** WILL ALARM AND BEEP AND SEND SIGNALS TO THE AUXILLARY TERMINALS.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/IN technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.