

Wireless Power Bank

WPC10000

User Manual

ONETNES

1.0 INTRODUCTION	-----	1
2.0 FEATURES	-----	1
3.0 SPECIFICATIONS	-----	2
4.0 PACKAGE CONTENTS	-----	2
5.0 OPERATION	-----	3-4
6.0 CONNECTION DIAGRAM	-----	5-6

Power Bank Wireless Charger

DEAR CUSTOMER

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or using this product. Please keep this manual for future reference.

1.0 INTRODUCTION

This product is a high-performance wireless charger. This product is suitable for mobile phones, MP3, MP4, digital productions, and other productions based on wireless charging 5W or 10W. Connect the power bank wireless to a power charger, and Or then you can charge your device supported wireless charging (mobile phones, etc) by put it on the charger directly. It is helpful in long time journey and convenient for business!

2.0 FEATURES

- 10000mAh large capacity
- Polymer battery
- Type-C charger : 5V/2A,or9V/1.1A
- Dual USB ports with different outputs:
USB-C: 5V/3A
USB-A: 5V/2A,
Total:5V3A (max)
- Type-C wireless input:10W
- Overcharge and over-discharge protection
- Output over current protection and short circuit protection
- Over temperature protection with auto-recovery
- Automatic power-off
- Intelligent LED battery indicators
- Compliant with FCC,CE,UN38.3 standards
- It is light, smart and convenient to use
- Suitable for smart phone, iPod, Camera etc.

3.0 SPECIFICATIONS

Input/output	
Type-C charger :	5V/2A,or9V/1.1A
Output	Dual USB ports with different outputs: USB-C: 5V/3A USB-A: 5V/2A, Total:5V3A (max) wireless charging 5W/7.5W/10W
Port	2 USB Ports
Protection	
Overload protection	Yes
Over-current Protection	Yes
Over Temperature Protection	Yes
Short circuit protection	Yes
Performance	
Ripple And Noise	$\leq 200\text{mVp-p}$
Standby Power Dissipation	$\leq 700\mu\text{A}$
Power bank Efficiency	$\geq 89\%$
wireless Switch Frequency	87K-205K 127.7K (fixed frequency 7.5W)
Mechanical	
Color	black
Size(L*W*H)	167.7*75.7*18.2mm
Weight	275 \pm 10 g
Environmental	
Operating Temperature Range	0~30°C
Storage Temperature Range	-20 ~ 70°C
Operating Humidity	<85%RH
Storage Humidity	<95%RH
Certification	FCC,CE,UN38.3 QI 1.2.4 (BPP)
User Manual	English Version
Size	167.7(L)*75.7 (W)* 18.2(H)mm

4.0 PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and

make sure the following items are contained in the shipping carton:

- Main unit×1
- User Manual×1

5.0 OPERATION

Operation Procedures



1. Power button: push to turn on the power bank wireless charger
2. LED indicator lights

During charging:

LED indicator status	Battery Percentage	Remark
◎○○○❏	1%-----24%	The current LED indicator light flashing
●◎○○○❏	25% ----- 49%	The current LED indicator light flashing
●●◎○○❏	50% ----- 74%	The current LED indicator light flashing
●●●◎○❏	75% -----99%	The current LED indicator light flashing
●●●●○❏	100%	ALL LEDS Bright

During discharging:

LED indicator status	Battery Percentage	Remark
----------------------	--------------------	--------

●●●●⌘	75% ----- 100%	4 LED lights on
●●●○⌘	50% ----- 74%	3 LED lights on
●●○○⌘	25%-----49%	2 LED light on
●○○○⌘	1% ----- 24%	1 LED light on
○○○○⌘	0	All LED lights off

◎ flashing

● light on

○ light off

⌘ wireless charging

⌘:Put your device (supported wireless charging) on the charger, the light will turn Blue light breath .When finished charging, the light will turn red. The fault turns red light flashing

3. USB-C port: connect a charger for charging or connect a device for discharging;

Input charging: 5V/2A, 9V/1.1A

Output discharging: 5V/3A (max)

Wireless input 10W

4. USB-A port: to connect a digital devices for discharging

Output: 5V/2A

5. wireless charging

Operation Notes

1. For optimum performance, please use the wireless charger according to this user manual.
2. Please connect the wireless charger to a power adapter which output should be QC3.0 standards A to C 56K line
3. Please unplug the wireless charger after using.
4. Do not use the wireless charger with an electronic product which is not in conformity with the specifications, so as to avoid any problem caused by specification mismatching.
5. It's normal that wireless charger will be a little overheated in the use process.
6. When the wireless charger stops working under some accidents occurs, you need to check whether the device is compatible with this charger.
7. Do not let the wireless charger close to fire, such as stove, candles and etc.
8. Do not let the wireless charger soak into liquid, such as swimming


- pool, bathtub, etc.
9. Do not wash the wireless charger with corrosive cleaner.
 10. If the wireless charger cannot work properly, please contact the store or distributor in your area.
 11. This device complies with Part 15 of the FCC Rules
 12. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference ,and
 - (2) This device must accept any interence received
 13. Including interference that may cause undesired operation

6.0 CONNECTION DIAGRAM


6.0 OPERATION

Operation Procedures

- a) Charge the power bank
 - Plug to a standard wall outlet via the TYPE-C



- b) Charge the devices



c) wireless charger the devices



FCC Warning

This device complies with part 18 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

P/N