


2. Power on

1 Auto positioning: Powered on. The mobile and the power bank are magnetically adsorbed and automatically positioned, then wireless charging is turned on with a snap. ② Short-press: Power on (the light displays), then wireless charging starts.



3. Power off

① Double-click the button. ② When the mobile Power Bank is in the no-load state (without charging any external devices), the digital tube power indicator automatically shuts down after 40 seconds.

4. Description of power display ① Discharge indicator status:

Capacity	LED1	LED2	LED3	LED4
75%~100%	ON	ON	ON	ON
50%~75%	ON	ON	ON	OFF
25%~50%	ON	ON	OFF	OFF
5%~25%	ON	OFF	OFF	OFF
1%~5%	Flicker	OFF	OFF	OFF
0%	OFF	OFF	OFF	OFF

(2) Charging indicator status

S								
Capacity	LED1	LED2	LED3	LED4				
100%	ON	ON	ON	ON				
75%~99%	ON	ON	ON	Flicker				
50%~75%	ON	ON	Flicker	OFF				
25%~50%	ON	Flicker	OFF	OFF				
0%~25%	Flicker	OFF	OFF	OFF				

③ Wireless charging indicator:

Wireless charger: Orange LED light is on

Wireless charge Slow charge (5W): Orange LED light is on Wireless charging fast charge (7.5W / 10W / 15W): Orange LED light is on Wireless foreign object: Orange light flashing fast



• This wireless charger is not compatible with non-MagSafe phone cases, such as Otterbox Defender cases.

 Wireless chargers make charging more convenient than wired chargers, but confined by current wireless technology. Their charging speed is slower than that of wired chargers.

• Do not use an adapter with an output of 20W or less.

• High temperatures will reduce charging speed and restrict power, which is something that happens to all wireless chargers. It is recommended that you charge your device in environments with temperatures be between 0°C to 25°C / 32°F to 77°F.

 Both the protective phone case and the position of your device on the wireless charger will affect the charging speed. The farther it is placed from the center of the wireless charger the slower the charging speed will be.

Important Safety Instructions

When using this product, basic precautions should always be followed, including the following

1) Store the product in a cool, dry place 2) Do not store the product in a hot or humid env

3) Do not dispose of the product in heat or fire. 4) Do not clean the product with harmful chemicals or detergents

5) Operating temperature should be between 0°C to 45°C / 32°F to 113°F. 6) Do not disassemble the product. Take it to a qualified service

person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.

7) If the product is not used for long periods of time, you should charge and discharge it once every three months. 8) When charging a device, the product may feel warm. This is a normal operating condition and should not be a cause for

concern. 9) In normal conditions, the battery performance will decline over several years.

10) Misuse, dropping, or excessive force may cause product damage.

11) When disposing of secondary cells or batteries, keep cells or batteries of different electrochemical systems separate from

each other. 12) Be aware that a discharged battery may cause fire or smoke. Tape the terminals to insulate them.

FAOs

FCC Statement

Q: Can this be used with any phone other than an iPhone? A: This magnetic power bank is designed specifically to charge the iPhone series phones. Only iPhone series phones support magnetic charging. Nevertheless, you can only use the USB-C port to charge other USB-C devices, or use the magnetic attraction ring to attach to other phone models that have wireless charging, however the charging speed will be slower.

Q: What is the wattage of this power bank?

A: This wireless power bank charges the iPhone series phones with a maximum output of 15W.

Q: Will the wireless magnetism work if the phone has a case?

A: This magnetic wireless charging mobile power can work well with the magsafe iPhone series phone case. If you use a normal case, the magnetic force will be very weak. For that reason, it is generally advised that it will not be effective with a thick protective case.

Q: Is it normal for the battery to heat up when charging? A: Compared to conventional charging devices, wireless technology charging devices tend to cause slight heat generation. However, this temperature is within the normal operating temperature range of the phone, so please feel free to use it despite it being slightly hotter.



Customer Service:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, i not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. This equipment does call equipment off and on, the user is encouraged to ty to correct the interference by one or more of the following measures: —Roorient or relocate the receiving anterna. —Increase the sequationent the outpent of and on outlet on a circuit different from that to which the receiver is connected.

acted. nsult the dealer or an experienced radio/TV technician for help.

🖂 support@pambee.cn 💮 www.pambee.cn