
# **USER MANUAL**



# What's in the box? 1. Speaker\*1

2.Type-C cable\*1


MADE IN CHINA

100mm

FCC ID: 2BCGV0025 IC: 31955-0010 HVIN: 010

#### Overview

- 1. Power ON/OFF/Mode
- 2. Previous track / Vol -
- 3. Play/Pause/Answer/End/Redial/Reject call
- 4. Next track/ Vol+
- 5. Light button
- 6. Reset button
- 7. TF slot
- 8. Aux port
- 9. Type-C port
- 10.LED Indicator 11.Lamp



#### Specifications:

- 1. Item: 7195-72BK
- 2.Input: DC 5V/2A
- 3. Speaker output power: 20W4. Frequency Response: 20Hz-20KHz
- 5. Battery capacity: 7.2 V, 2600mAh, 18.72Wh

## Operation Instructions

- 1. Power On: Long press the power button to turn on the speaker, you will hear a tone.
- Pairing: Once speaker is turned on, open your mobile device, search the wireless devices, and select wireless ID 'Party Speaker', It will pair automatically.
- 3. Play/Pause/Answer/End/Redial/Reject call: Short press the button to play or pause the music in paly music mode. When call is incoming, short press the button to answer the call, short press again to end call, double press the button to redial the number you last called. Long press to reject the call.
- Next track/Vol+: Long press to next track, short press to increase volume
- 5. Previous track/Vol -: Long press to last track, short press to decrease volume
- 6. Switch Bluetooth, TF and Aux (If ready) mode: Press once the mode button.
- Aux: Using the Aux cable (Not included) to connect the speaker and your device. It will automatically enter Aux mode, then you can enjoy the music.
- 8. TWS function mode: Turn on both speaker, double press the power button of either of speaker, the both speakers will pair automatically and enter TWS mode, then you can pair them with your device and enjoy the music. Double press the

# **75mm**

- power button of either of speaker again to disconnect them and turned off the TWS mode.
- TF card play: Plug the TF card into TF slot, it will play the music.
- Charging: Use the Type-C cable included to connect the speaker to a computer or adaptor, the LED indicator will illuminate a solid red. When the speaker is fully charged, the red LED will be turned off.
- Power Off: Long press the power button to turn off the speaker.
- Lamp: Double press the button to turn on/off the light.
   Tap the light button to change different light mode.

# Caution:

- Please enjoy music with an appropriate volume, which will avoid to damage your hearing and sound system.
- Please avoid exposure, rain, water droplets, avoid prolonged exposure to high temperature, high humidity environment.
- 3. During use, please make it away from heat, high pressure, and prevent children from playing with this product.
- 4. Please use the power which meets the requirements.
- 5. Do not drop or bump and applied heavy pressure to avoid damage to the product.

## FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.

Warning: Any changes or modifications not expressly

approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## RF Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## IC Caution:

ICES-003 CLASS B NOTICE-AVIS NMB-003, CLASSE B This Class B digital apparatus complies with Canadian ICES-003

Cet appareil numérique de la classe B est conforme à la normeNMB-003 du Canada.

# - English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.
- French:

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1.L'appareil ne doit pas produire de brouillage;
- 2.L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction. (Portable)

L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux RF.

L'appareil peut être utilisé dans des conditions d'exposition portables sans restriction.