

WIRELESS KEYBOARD AND MOUSE User Manual



Packing List




1. Keyboard x1
2. Mouse x1
3. USB Receiver (Stored in battery compartment) x1
4. User Manual x1
5. VIP Card x1

Instructions

1. Take out keyboard and mouse from the package, and take out USB receiver from battery compartment of the mouse.
2. Insert two 1.5V AA batteries into the keyboard with the correct polarity direction. And turn on its power switch.
3. Insert a 1.5V AA battery into mouse with the correct polarity direction.
4. Plug the USB receiver in computer port.
5. They are available after the drive is installed on computer automatically.

Combined Multimedia Functions

Fn+F1	Fn+F2	Fn+F3	Fn+F4	Fn+F5	Fn+F6
Player	Volume -	Volume +	Mute	Previous Track	Next Track
FN+F7	FN+F8	FN+F9	FN+F10	FN+F11	FN+F11
Play/Pause	Stop	Homepage	Email	My Computer	Favorites



-01-

Note

1. The multimedia functions of keyboard are not available in Mac OS.
2. The keyboard and mouse are only workable with AA alkaline dry battery. Please take out the battery and keep it properly when it is not used for a long time, so as not to corrode the parts.

Solutions for Connecting Problems

Mouse

1. Plug USB receiver in computer port after the mouse is installed with battery, and keep the distance between receiver and mouse within 20cm.
2. Simultaneously press scroll wheel button and right button for over 3s and the mouse will enter code paring mode.
3. It indicates the successful pairing if the mouse movement is responsive on computer screen in 20s.

Keyboard

1. Turn on the switch after the keyboard is installed with batteries.
2. Plug USB receiver in computer port and keep the distance between receiver and keyboard within 30cm.
3. Simultaneously press "ESC" button and "K" key for over 3s and the indicator light turns on showing that keyboard enters code paring mode.
4. The indicator light of keyboard will go out if the code pairing is successful.

Note

If the product is still unworkable after above solutions, please repeat those steps for code pairing again. If your problems can't get solved yet after that, please contact our customer service for help (Email: csforcustomer@gmail.com).

-02-

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-03-