


# Mini 2S

ORIGINALITY DESIGN SMART AND BEAUTIFUL



## QUICK GUIDE



## What's in the box

Please consult this checklist for all parts.




Mini 2S




Power adapter




USB cable



Adhesive tape



Manual




## Description


Power	DC5V $\pm$ 10%
Status light	<ul style="list-style-type: none"> <li>Red light solids on: the device or network is abnormal</li> <li>Blinking red light: awaiting WiFi connecting</li> <li>Blue light solids on: camera running correctly</li> <li>Blinking blue light: currently connecting</li> </ul>
Microphone	Captures sounds for your video
SD card slot	Supports local SD Card storage (Max.128G)
Reset	Press and hold the 'RESET' for 5 seconds to reset the device(if you have modified settings, they will return to factory defaults)

## Install

- 1 Stick the adhesive tape in the middle of camera bottom



- 2 Put the camera on the clean plane



## Connect

### Download

Smart Life is available for both iOS and Android OS. Search the name 'Smart Life' in App Store or Android Market, or scan upper QR-Code to download the App.

• Support



iOS



Android



Download App on Android

### Set up router

This device only supports 2.4GHz frequency band router, does not support 5GHz frequency band router, please set the relevant parameters of the router before WiFi configuration, WiFi passwords do not include special characters such as ~!@#\$%^&\*(). When the device is configured in WiFi, the mobile phone and device are as close as to the router, which can speed up the configuration of the device.



Please keep network available



## Registration process

Step 1 Open the Smart Life App, click "Register", read the "Privacy Policy" and click "Agree" .




Step 2 input a legal and valid Mobile number or Email address and click "Continue". Input Verification Code, then log in the app.



## QR Code Configuration

- 1 Open the Smart Life App, click "Create family", and you can customize the Family name and related settings .



- 2 Continue to click "Security & Sensor" >> "Smart Camera",and then choose "Add Device" or "+",ready to add camera.



- 3 In "Add Device" this interface,continue to click "next step",and then you should input your WiFi's passwords.



Note:

- 1) Camera only supports 2.4GHz WiFi network.
- 2) The number of bits in the ssid and passwords of the router should not exceed 24 digits.



- 4 In this interface, you should scan the QR code in your phone with the camera, when the camera comes out "dong dong dong". And you can complete the configuration about 30s.



- 5 When connecting, you should make sure your router, mobile, and camera are as close as possible. When camera added successfully, click " " you could also DIY the camera's name.

### Connecting

Make sure your laptop, mobile, and camera are as close as possible.



Device added successfully

### Device added successfully

Smart Camera 2

Device Name	Device ID	Device Type
Smart Camera 2	1234567890	Smart Camera

Download

## Settings

In "Smart Camera" interface,click ,you can set the camera common functions.



Q: The camera cannot be previewed properly?

A: Check whether the network is normal, you can place the camera close to the router, if not, it is better to reset the camera and add it again.

Q: Why is it still in the list of devices after resetting?

A: The reseted camera only resets the network configuration of the camera, but cannot change the configuration in the App, remove the camera in your account, need to add again.

Q: How to cut the camera network to other router?

A: First remove and reset the camera in your App account and then configure your camera again by the App.

Q: Why doesn't the camera identify the SD card?

A: It is recommended to plug in SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And the TF card can't be identified when the internet environment is not good.

Q: Why I can't get the notifications with my cell phone App?

A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened; Message notification and authority confirmation in the mobile phone system have been opened.

## Functions

### Video flip

Flip your video stream vertically anytime for maximum flexibility.

### Motion detection

Motion sensors will notify you when movement is detected.

### Record

Record every moment using high capacity SD card storage.

### Daytime& Night

Powerful night vision means no interruptions, even in complete darkness.



Daytime



Night

## FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

## FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.