## Wireless Dongle



## **Summarize**

- This product is a USB 2.4G transceiver
- CH582 Bluetooth chip as the core data processing, Bluetooth version: V5.0
- Transmission power: Class II, indoor range of 8 meters (the actual range depends on the equipment connected to it)
- Frequency range: Bluetooth standard, 2.402 ~ 2.480GHz; 2.4G:2404~2478MHz
- Working temperature: -40~85 °C
- Net weight: about 2g
- Size: 19.3\*15.5\*6mm

## **Operation Instructions**

- 1, power on: Insert the USB port into the computer device and it will auto-power on.
- 2. Power off: When the device is started, dial out the USB port Product to power off.
- 3, enters the pairing state: The system automatically enters the pairing state after disconnection .
- 4, connect back: in the state of no interference, power on when there is a pairing record, enter the connect back state.
- 5, clear pairing: You need to follow the keyboard operation manual to perform the corresponding key operations on the keyboard.



## **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.