

TRANSFORMERS



TF-T50真无线蓝牙耳机 使用说明书

包装清单



产品展示图



温馨提示

1. 除说明书中有明确标识的操作方式以外，请勿尝试拆解或使用产品内的任何零件。
2. 请勿将产品放入水或其他任何液体中。本产品为防水设计。
3. 如果有任何液体不小心进入产品内部，请立即断开电源并停止使用产品。
4. 为避免触电，请在安装或拆卸产品时，确保手上没有沾水。
5. 请勿将此产品置于高温环境或将产品暴露于火源附近。
6. 请勿将本产品放置在强电磁力的环境中，否则会导致产品故障。

产品规格

蓝牙版本: V5.4
传输距离: <10米
通话时间: 约6小时 (80%音量)
续航时间: 约13小时
充电时间: 约1.5小时
电池容量: 55mAh
额定输入: 5V ~ 500mA

充电盒规格

电池容量: 520mAh
充电时间: 约1.5小时
额定输入: 5V ~ 500mA
(所有技术指标均以实际性能为准)

快充组合充电器

Type-C 充电线连接充电仓到 Type-C 适配器

温馨提示: 当耳机充电量极低时充电器将显示: battery low, 每10秒钟1次) 时, 请及时给耳机充电



额定输入: 5V ~ 520mA (快充)

额定输入: 5V ~ 500mA (充电仓)

LED指示状态

开机	红灯亮一下
关机	红灯亮一下
TV功能状态	红灯闪烁
进入设置初始状态	蓝灯闪烁5秒，制噪模式
新开通	蓝灯闪烁5秒，制噪模式
耳机充电提醒	耳机红灯闪烁一下
耳机充电	耳机红灯常亮
耳机无电	耳机红灯灭

充电盒指示说明(仅供参考,以实物为准)

充电盒无电提示	充电盒红灯常亮5秒后熄灭
充电盒无电提示	耳机提示红灯常亮30秒后熄灭
充电盒无电提示	充电盒红灯常亮5秒后熄灭
充电盒有电提示	充电盒红灯常亮5秒后熄灭
充电盒有电提示	充电盒红灯常亮5秒后熄灭

产品使用说明

1. 开机

- 方法一: 充电盒上盖打开, 耳机自动开机。
方法二: 长按左/右侧功能键5秒, 耳机开机。
(开机提示音 "power on")

2. 关机

- 方法一: 长按充电盒盖, 耳机自动关机。
方法二: 长按左/右侧功能键5秒, 耳机关机。
(关机提示音 "power off")

3. 配对

- 步骤一: 开机后, 耳机与充电盒连接, 耳机自动开机。
步骤二: 打开充电盒盖, 耳机自动开机, 提示音 "TV-TV" 持续。
温馨提示: 耳机充电盒在不配对时, 请关闭出厂设置, 避免因电量耗尽导致无法配对。



触控操作

■ 触控模式



- 触控 - 单击左耳的 Touch 键 (单击左耳的 Touch 键)
- 触控 - 单击右耳的 Touch 键 (单击右耳的 Touch 键)

■ 触控模式



- 触控/触控模式 Touch 键
- 上一级/上一级 Touch 键
- 下一级/下一级 Touch 键

■ 触控模式



- 触控/触控模式 Touch 键
- 触控/触控模式 Touch 键
- 触控/触控模式 Touch 键

■ 触控/触控模式



- 触控/触控模式 Touch 键 2秒/触控模式/触控模式
- 触控/触控模式 Touch 键 2秒/触控模式/触控模式

恢复出厂设置

方法一: 长按左/右侧功能键5秒, 耳机自动关机。
方法二: 长按左/右侧功能键5秒, 耳机自动关机。
方法三: 长按左/右侧功能键5秒, 耳机自动关机。
方法四: 长按左/右侧功能键5秒, 耳机自动关机。

产品中有毒物质名称及含量

部件名称	有毒物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBBs)	多溴二苯醚 (PBDEs)
印刷电路板零件	○	○	○	○	○	○
开关电源结构件	○	○	○	○	○	○
本电源按照GB/T 11364标准检测。 ○表示没有检测到该部件所有材质材料中的含量均在GB/T 26572 规定的限量要求以下。 +表示该有毒物质至少在该部件的某一材质材料中的含量超出 GB/T 26572 规定的限量要求。 按照IEC 61247的附件，按照全球技术发展水平检测而无法检测有 物质时替代。						
印刷电路板零件：包括印刷电路板及其零件、电子元件等。按照产品型号不 同，附件所述的部件可能包含有以上所有部件						
	在中华人民共和国境内销售的电子电气产品必须标注此 标志。标志内的数字代表在正常的使用状态下的产品的 环保使用期限。					

保修声明

免责声明

本电源于非没有任何形式的时候，以书面或印刷的方式。本电源非附件制造的产品，附件
 制造在附件中，内容包含附件制造于附件，但不对其限制。

保修声明

在本文件所列的产品范围内，该产品在附件中已标注十二个月（“保修期”），在
 正常使用情况下因质量问题发生损坏、故障的，免费维修、更换或退货（以无法维修的，选
 择更换）。但须满足附件的条件。在保修期内（保修期不少于30天）内维修费用有保修，附件以
 以销售发票日期为准；如无法维修或退货，则保修期由产品生产日期起算十二（12）个月
 计算。如保修期，须由附件产品保修书标注，并附我们标注的方式执行。申请保修时，您需
 提供保修书，并附上清晰标注的有附件附件。

以上保证不适用于下列情况：

1. 附件上标注有故障的；
2. 附件损坏，产品损坏或产品未正常使用；
3. 因使用、误用或不适当的安装、使用、维护或保管而导致附件损坏；
4. 因不可抗力（如地震、战争、火灾等）造成附件损坏或附件损坏；
5. 因附件受到外力（如火灾、水灾等）造成附件损坏；
6. 因附件受到外力（如火灾、水灾等）造成附件损坏；
7. 附件因附件损坏造成的损坏；
8. 附件因附件损坏造成的损坏；
9. 附件因附件损坏造成的损坏；
10. 附件因附件损坏造成的损坏；
11. 附件因附件损坏造成的损坏；
12. 附件因附件损坏造成的损坏；

产品保修期内的产品在附件中不标注保修期，如在附件中产品标注保修期，
 附件中不标注保修期。

以上保证是我们对产品制造的全部保证，只在中国大陆地区内适用。本文件的附件
 内容均不影响附件中规定的不能保修或附件的保修书标注。

服务热线：400-885-8888



保修卡

尊敬的客户，本保修卡请您妥善保管并填写，请您配合我们为您提供售后服务！

用户信息			
用户名		电子邮箱	
联系电话		邮政编码	
通讯地址			
产品信息			
产品名称		产品型号	
产品序列/编号/型号			

经销商信息			
经 理			
地 址			
联系电话		邮政编码	
销售日期		发票号码	
备 注			

合格证

产品名称: _____
 生产日期: _____
 检验员: _____

TRANSFORMERS



TF-T50 True Wireless BT
headphones user manual

Packing list



Product diagram



Warm reminders

1. Do not attempt to remove or replace any parts in the product except for the replacement method specifically indicated in the instruction manual.
2. Do not put the product into water or any other liquids. This product is not waterproof.
3. If any liquid accidentally enters the product, immediately disconnect and remove the product.
4. To avoid electric shock, please make sure that your hands are not stained when installing or uninstalling the product.
5. Do not place the product near the heat source or directly expose it to direct sunlight.
6. Do not place this product in a strong electromagnetic environment, otherwise it will cause the product to fail.

Product specifications

BT version: V5.4

Transmission distance: <10 meters

Music time: about 4 hours (80% volume)

Speaker size: 45mm

Charging time: about 1.5 hours

Battery capacity: 350mAh

Rated input: 5V/0.50mA

Specifications of charging compartment

Battery capacity: 320mAh

Charging time: about 1.5 hours

Rated input: 5V/0.50mA

Number of headphones available for charging: about 3 times

148 technical information is subject to actual performance

To charge the charging compartment

The Type-C charging cable is connected to the charging compartment to the 5V power adapter.

Tip: When the headphone battery approaches a low-power reminder sound prompt, battery low, each every minute, please charge the headphones in time.



LED indicates the status

Start	The white light is on.
Start done	The white light is on.
Start pairing status	The white light flashes.
Start the device pairing mode	The white light of the start is flashes, and the secondary led light on.
Stop	The white light of the start is flashes, and the secondary led light off.
Stop	The white light of the start is flashes, and the secondary led light off.
Headphones charging	The white light of the headphones flashes once in 4 seconds.
Headphones charging	The white light of the headphones is always on.
The headphones are fully charged	The headphones light is off.

Instructions for charging compartment

Put reference only, subject to the specific object

Charging status is charging on	The display screen of the charging compartment is on flashing.
The charging compartment is full (charge)	The display screen shows that the power is 100 full and extinguished.
The charging compartment charge	The display screen shows "on the left and right side of the charging compartment".
The charging compartment is full (charge)	The display screen shows 100 power and turn off the light and 30 seconds.
Low power state of the charging compartment	The display screen of the charging compartment flashes 3 times, then 100% (20 seconds).

Product how-to instructions

How to use

Method 1: Press the side of the charging case and turn on the headphones automatically.
Method 2: Long press any key/light multi-function button for 3 seconds, and the headphones turn on (Power on) (Time: 10 seconds).

Stand down

Method 1: As a back in the charging compartment, and the headphones will automatically turn off.
Method 2: The headphones will automatically shut down without connecting the device within 1 minutes.

How to turn on "power off"

Pairing

Step 1: After turning on, the left and right headphones will automatically interconnect and enter the pairing state, and the middle green light "flashes".
Step 2: Open the BT list of smart devices, search for "T9-T10T" and connect.

How: When the left and right headphones are fully paired, please confirm the factory settings, and then back in the charging case with them upon the automatic pairing.



Successfully connected the device
Make pairing successful



Touch operation

General mode



Volume - Click the left headphone Touch key (bottom half "Long")

Volume + Click the right headphone Touch key (the maximum half "Long")

Music playback mode



Play/Pause Double-click the touch key

Previous song Tap/click the Touch key of the left headset

Next song Press/click the Touch button on the right headset

Call mode



Answer the call Double-click the left/right headphone Touch button

End the call Double-click the left/right headphone Touch button

Reject the call Long press the left/right headphone Touch key 2s

Game/Music Mode



Long press the right headphone Touch key 2s to switch game/music mode

Long press the Touch button of the left headset 2s to activate the voice assistant

Restore factory settings

Method 1: Unconnected state, after 3 consecutive clicks on the left/right headphones, the white light turns on for 1 second to turn off, after the pairing information, turn off the left/right headphones.
Method 2: Power-on connection state, the left/right headphones are respectively clicked 5 times, and the white light turns on for 10 seconds with 2 seconds to turn off for 1 second to clear the pairing information between the headphones and the BT device and then turn it off.

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances					
	Pb	Hg	Cd	C+Ni	PBB	PBDE
Printed circuit assembly	0	0	0	0	0	0
Small structural parts such as shell	0	0	0	0	0	0
This form is compiled in accordance with SJ/T 11384. 0 indicates that the content of the hazardous substance in all homogeneous materials of the part is at below the limit required by GB/T 26572. X indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds the limit requirements specified in GB/T 26572. The parts marked with "X" on this form are all harmful due to the limitations of global technological development. Substitution of substances.						
Printed circuit board components: including printed circuit boards and their parts, electronic components, etc., and depending on the product model (the earbuds you purchased) may not contain all the above components.						
 Electronic and electrical products sold in the People's Republic of China must mark this LOGO, the number in the logo represents the product under normal use Environmental protection use period.						

Warranty statement

Disclaimer

This user manual does not have any form of guarantee provision expression or other implication. The mentioned products specifications and information are for reference only and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:

The product attached to this document is guaranteed as follows if the product is within (12) months from the date of purchase ("warranty period"). Under normal conditions of use due to quality defects (damaged) can be repaired. Free repair free replacement. If the manufacturer confirms that it cannot be repaired, repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by the ticket date shall prevail. If the purchase date cannot be determined, the warranty period shall be 13 (13) months. If you apply for a warranty, please call the product service hotline first and receive it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:

1. Exceeding the validity period of the three packs;
2. Altering the warranty card and product code does not match the product body;
3. Damages caused by misuse, abuse or improper transportation, use, maintenance or storage (strikes or damage);
4. Failure or damage caused by force majeure (such as earthquakes, floods, fires, etc.) or accident (loss);
5. The upper and lower buds are damaged due to excessive force;
6. Distortion or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or swelling;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other issues that occur during the normal use of the product;
11. If the original identification label of the product is changed or damaged, the guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and leave objections to any discrepancies.

The above guarantee are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law of the People's Republic of China.

Service supervisor hotline: 400-885-8828



Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info			
User name		Email	
Contact number		Postal code	
Mailing address			
Product information			
Product name		Product number	
Product barcode / Serial number / Batch number			

Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate of Approval

Product No: _____
Production Time: _____
QC: _____



TRANSFORMERS

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.