

快速安装指南

(中继模式)

扩展器插上通电，在手机打开设置页面，WiFi或者（WLAN）选项，选择（Repeater-XXX）的WiFi名称，跳转到连接界面。

步骤1：先切换中文



步骤2：选择中继模式



步骤3：找到自家WiFi名称



步骤4：输入自家WiFi密码后点击下一步



步骤5：点击完成配置即可。



LED指示灯说明

LED	说明
Power LED	电源指示灯
Signal LED	信号指示灯
Repeater LED	中继指示灯
LAN LED	网络端口指示灯
WPS LED	WPS连接指示灯
Reset/WPS Button	长按7秒，指示灯熄灭，设备恢复出厂设置。短按2秒，WPS指示灯闪烁，与上级路由器配对成功时灯亮。

快速安装指南

(AP模式)

扩展器插上通电，在手机打开设置页面，WiFi或者（WLAN）选项，选择（Repeater-XXX）的WiFi名称，跳转到连接界面。

步骤1：先切换中文



步骤2：选择AP模式



步骤3：创建WiFi名称和密码，点击下一步



步骤4：点击完成配置即可。



LED指示灯说明

LED	说明
Power LED	电源指示灯
Signal LED	信号指示灯
Repeater LED	中继指示灯
LAN LED	网络端口指示灯
WPS LED	WPS连接指示灯
Reset/WPS Button	长按7秒，指示灯熄灭，设备恢复出厂设置。短按2秒，WPS指示灯闪烁，与上级路由器配对成功时灯亮。

Quick Installation Guide

(Relay Mode)

Plug in the extender to power up. Open the settings page on the phone, select WiFi or (WLAN) option. Select the WiFi name or Repeater-XXXX to jump to the connection interface.

Step1: Switch to English first




Step2: Select relay mode




Step3: Find your own WiFi name



Step4: Enter your own WiFi password and click Next



Step5: Click to complete the configuration



LED指示灯说明

LED	说明
Power LED	Single frequency 2.4G
Signal LED	The power on indicator is on
Repeater LED	After power on for about 10 seconds, the signal indicator is on. Connection settings can be made.
LAN LED	The expansion is successful, the indicator route and the indicator light is on.
WPS LED	The network port indicator connects to the network cable, connects to the superior route, and the indicator lights up.
Reset/WPS Button	WPS connection indicator. Press and hold for 7 seconds and all the indicator lights are off. The machine returns to the factory state. Short press for 2 seconds, WPS indicator flashes. After the connection with the superior router is successful, the indicator is on.

Quick Installation Guide

(AP MODE)

Plug in the extender to power up. Open the settings page on the phone, select WiFi or (WLAN) option. Select the WiFi name or Repeater-XXXX to jump to the connection interface.

Step1: Switch to English first




Step2: Select AP mode



Step3: After creating a WiFi name and password, click Next



Step4: Click to complete the configuration



LED指示灯说明

LED	说明
Power LED	Single frequency 2.4G
Signal LED	The power on indicator is on
Repeater LED	After power on for about 10 seconds, the signal indicator is on. Connection settings can be made.
LAN LED	The expansion is successful, the indicator route and the indicator light is on.
WPS LED	The network port indicator connects to the network cable, connects to the superior route, and the indicator lights up.
Reset/WPS Button	WPS connection indicator. Press and hold for 7 seconds and all the indicator lights are off. The machine returns to the factory state. Short press for 2 seconds, WPS indicator flashes. After the connection with the superior router is successful, the indicator is on.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.