

Doorbell Wi-Fi Cam!

Front

Mounting Holes

TF Card Slot

Reset Button
Hold 5 seconds to reset and enter AP mode.

Back

Terminals

LED Indicator

Blue Light	Flashing	Doorbell is ready for Wi-Fi configuration.
Blue Light	Steady on	Doorbell is working.
Red Light	Flashing Fast	Device Exception
Red Light	Steady on	Doorbell is powering on.

To reset the camera, press and hold the RESET button for 5 seconds

Reference Installation Distance

SMART, CONVENIENT, RELIABLE

Doorbell From Your Trusted Surveillance System Company

ACCESSORIES

Wire Harness (x1)

Security Screws (x2)

Wire Connectors (x4)

Surveillance Stickers

Power Kit (x1)

Fuse Wire (x1)

Fixing Screws (x2)

Mounting Screws (x3)

QSG

Mini-Level (x1)

U-shaped Wires (x2)

Doorbell Screws (x2)

Anchors (x5)

Quick Start Guide

More from LaView

QUICK START GUIDE

ONE Halo

Wi-Fi Doorbell Camera


1 Remove existing doorbell

Turn off the power at the breaker. Remove your existing doorbell and disconnect the cables

a) Place drill template onto the surface you have chosen to mount the camera.


b) Drill screw holes according to the template and insert expansion screws. (For cement wall/ceiling only)

c) Insert the screws.



2 Connect the Doorbell camera to existing cables

Remove the faceplate from the doorbell camera and connect the doorbell camera to the existing doorbell wiring. Use the included power connector if needed. Then restore your home power at the breaker.



⚠ If you have a chime installed, follow **Option A**; if not, follow **Option B**
⚠ It doesn't matter which cable connects to which screw.

3 Complete the in-app setup


Download and install **LaView ONE** from App Store or Google Play Store. Select the option to add a new device. Wait until the LED indicator on the camera flashes Blue to start network configuration.



For more instruction and video tutorials, visit: laviewsecurity.com/support

4 Secure faceplate

Mount the faceplate with the included security screws.



For complete support information, please scan the QR code or visit www.laviewsecurity.com/onehalo

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This product has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.