# DEKALA



# **T2 Pro User Manuel**

Please read the instruction manual carefully before use and retain it for future reference. (vl.0)

## Content

Add Your T2 Pro	1
Overview of Features	4
Reset Your T2 Pro	5
Operating Instructions	6
Binding and Unbinding Precautions	6
Replace The Battery	7



T2 PRO Guide

Support@dekalastore.com

If you need any assistance please feel free to contact us

### Add Your T2 Pro:

■ Add Your T2 Pro:

- Start the App: Open the Find My™ app on your supported iPhone or iPad and enable notifications. As the T2 PRO only works with Apple's Find My app.

- Connect T2 Pro:

1. Enable Bluetooth: Turn on Bluetooth so the Find My app can detect the T2 PRO.

2. Power On: Press the T2 PRO button to power it on; you'll hear a sound.

3. Enter Pairing Mode: Press the button again to enter pairing mode, confirmed by another sound, making it discoverable in the Find My app.







4.Select the "Items" tab, then tap "Add Item," and next tap "Other Supported Items.





1

## 5. Once T2 Pro is detected, tap "Connect."






6. Choose a recognizable name and emoji for your T2 Pro and tap "Continue."





- 7. Find My<sup>5s</sup> will ask for confirmation to add T2 Pro to your Apple ID; tap "Continue." 8. Tap "Finish." Your T2 Pro is now set up and ready to be connected to whatever item you wish to locate, such as your keys.





- Play Sound: When T2 Pro is nearby, Tap "Play Sound" to make T2 Pro emit a beep. Once found, tap "Stop Sound" to stop the beeping.

  Directions: Navigate to the last known location by tapping 'Directions' to open the Apple Maps app.

  Notify When Found: Enable 'Notify When Found' to receive notifications when another Find My network device locates T2Pro.

  Notify When Left Behind: Enable 'Notify When Left Behind'. If T2Pro is no longer with you after 4 minutes, you will receive a notification, informing you that it is no longer with you.

  Lost Mode: Enable "Lost Mode' to display a message with your concar information on the lock screen of the lost device, allowing on the lock screen of the lost device, allowing on the lock screen of the lost device, allowing on the lock screen of the lost device, allowing on the lock screen of the lost device, allowing on the lock screen of the lost device, allowing on the lock screen of the lost device, allowing on the lock screen of the lost device and the lock when "Lost Mode' is enabled, "Notify When Found" will be used with a new iPhone or iPad.

4

- © 2 ways of Resetting T2 Pro
  Way I: Reset on Find My
  1. Open the Find My™ app and select the "Items" tab.
  2. Tap on your T2 Pro from the list.
  3. Ensure "Lost Mode" is disabled.
  4. Scroll to the bottom of the screen and tap "Remove Item."
  5. A summary will open; then tap "Remove" to confirm. Press the
  T2 Pro button briefly; it can now be connected to other Apple phones.





Way 2: Factory Reset:

Press and hold for 10 seconds. After hearing a beep at 3 seconds, continue holding for another 7 seconds until a series of tones indicates a factory reset. After each reset, press the button briefly to re-enter pairing mode.

- Operating Instructions
  1. Power On: After turning off, press the button once, accompanied by a series of startup tones, then press again to hear a beeping sound, indicating pairing mode. (For first-time connection, a short press is enough to enter pairing mode.)
  2. Power Off: Press and hold the button for at least 3 seconds, release within 1 second after hearing a beep, then listen for another beep to confirm shutdown.
  3. Pairing Mode Timeout: If not paired with a phone within 3 minutes after entering pairing mode, it will stop pairing. Press the button briefly to hear a beeping sound and re-enter pairing mode.

Precautions for Binding and Unbinding:
If the tracker is near the phone and the Find My app does not detect the tracker after 15 seconds:
Remove and reinstall the battery of the tracker or replace it with a new one; after hearing a tone, press the button to enter pairing mode.
Follow the factory reset steps again for T2 Pro.

- Other Notes:

  The speed of binding and unbinding in the Find My™ app can vary due to network speed, phone performance, and tracker signal strength.
  Changing the battery does not affect the normal operation of the tracker.
  If the tracker continuously beeps or is silent after installing the battery, it may indicate the battery is depleted. Replace with a new battery. If there is no startup tone after battery replacement, the tracker may be damaged.

### Replace The Battery



Pry open the shell from
the side notch of the product.



3. Insert the new CR2032 battery with the positive side facing up (text side up)..



2. Remove the old CR2032 battery.



Close the shell, replacement is complete.

7

Duttery with the positive side up).

This device complies with part Is of the FCC Rules. Operation is subject to the following two conditions:

(1) Indevice complies with part Is of the FCC Rules. Operation is subject to the following two conditions:

(2) this device may not cause formful interference.

(2) this device may not cause undesired operation.

(3) This device the tray cause undesired operation.

(3) The The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device. The device can be used inportable exposure condition without restriction Federal Communication.

Commission(FCC)Radiation Exposure Statement Power is so low that or RF exposure calculation is needed. This equipment has been tested and found to comply with the limits for a Class B digitaldevice, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates us essend can radiate radio frequency energy and, if not installed and used in-accordance with the instructions. Moveverthere is noguarantee that interference will not occur in a particular installation. This equipment for this equipment generates us essend can radiate radio frequency energy and, if not installed and used in-accordance with the instructions. Moveverthere is noguarantee that interference will not occur in a particular installation. This equipment for an only the determined by turning the equipment off and on, the user is

encouraged to try tocorrect the interference by one or more of the following measures:Reorient or relocate the receiving antenna. increase the separation between the equipment and receiver. Connect the equipment into a no utlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced raido/TV technician for help. The device has been evaluated to meet general Fie exposure requirement. The device can be used in portable exposure condition without restriction. Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer tomeet Apple F ind My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Use of the Works with Apple badge means that a product has been destinated by the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple Find My happle Watch, Find My, iPhone, iPad, Pad OS, iPad touch Mac, mac OS and Watch OS are under Ilcense.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOs, Mac, macOS and watchOS are trademarks of Apple Incregistered in the US. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

To use the Apple Find My app to locate this item, the latest version of IOS, iPadOS or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOs.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find tems app on Apple Watch.

