

尺寸：A5



PANTONE 430 C

PANTONE 185 C



PANTONE 300 C

PANTONE Black C




NEO iDSD

—— User Manual

Thank you for purchasing the iDSD from Neo series.

FEATURES:




1. OLED display
2. Multi-function knob
3. Input channel selector/Bluetooth pairing button

P.4
P.4-5
P.5-6

4. Power On/Off
5. Balanced 4.4mm analogue output
6. Single-ended 6.3mm analogue output

P.6
P.6
P.6



- 7. XLR balanced analogue output
- 8. RCA single-ended analogue output
- 9. Coaxial digital input
- 10. Optical digital input

P.6
P.7
P.7
P.7

- 11. USB audio input
- 12. DC 5V power input
- 13. Antenna

P.7
P.7
P.7



1. OLED display

The OLED display shows the audio format, sampling rate, volume and input mode.

2. Multi-function knob

This knob controls:

- Variable/Fixed mode (use with power button)
- Analogue volume control (turn)
- Mute (short press)
- Brightness (long press)

1) Variable/Fixed mode selection

This mode will determine whether or not the NEO iDSD analogue volume control is used.

The NEO iDSD must first be switched off to allow mode selection when powering on.

Hold down the knob first, and then press the power button to enter the Variable/Fixed mode selection. Turn the knob to cycle between the two modes. Release to accept.

Tip: *If no mode is selected the NEO iDSD will automatically select the previously used mode.*

ii) Analogue volume control

The analogue volume control in the NEO iDSD is superior to any digital volume control. When set to 'Variable', it can be used to control the headphone or the pre-amplifier volume. If the mode is set to 'Fixed', the volume control is bypassed.

Note: *The NEO iDSD uses ONLY a pure analogue volume control.*

iii) Mute

Press the rotary knob to mute. To unmute, press it again or turn the rotary knob.

iv) Brightness

Press and hold the knob (3 seconds) to enter brightness selection. Rotate the knob to cycle through the three brightness modes and press to accept.

Note: *With the 'high' and 'low' brightness modes, the OLED will remain on. With the brightness mode 'off', if no operation is performed, the OLED will go to sleep after three seconds.*

3. Input channel selector/Bluetooth pairing





4. Power On/Off

5. Balanced 4.4mm analogue output

Tip:

6. Single-ended 6.3mm analogue output

7. XLR balanced analogue output

8. RCA unbalanced analogue output

9. Coaxial Digital input

10. Optical Digital input

11. USB audio input

12. DC 5V power input

Tip:

13. Antenna



MQA



The NEO iDSD includes MQA technology, which enables you to play back MQA audio files and streams. 'MQA' or 'MQA.' indicates that the product is decoding and playing an MQA stream or file, and denotes provenance to ensure that the sound is identical to that of the source material. 'MQA.' indicates it is playing an MQA Studio file, which has either been approved in the studio by the artist/producer or has been verified by the copyright owner.

MQA and the Sound Wave Device are registered trade marks of MQA Limited.© 2016

ifi

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complied with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ifi



Balmoral Lodge, 139-141 Cambridge Road, Churchtown, Southport, PR9 7LN. UK.
www.ifi-audio.com

Ver1.0