

FOLDABLE BLUETOOTH CAT HEADPHONES



YS-BT0191 (39611) INSTRUCTION MANUAL

**PLEASE READ ALL INSTRUCTIONS CAREFULLY
AND RETAIN FOR FUTURE USE**

Getting started

- Remove the product from the packaging.
- Please retain all packaging after you have checked and counted all the parts and the contents against the list.

Package Contents

- Bluetooth headphones
- USB charging cable
- 3.5mm auxiliary cable
- Instruction manual


Key Features

- Bluetooth Headphones with light-up cat ears
- LED lights can be turned on/off
- Connect & stream wireless music
- Built-in LED flashing lights on ears and ear-cups
- Built-in mic for hands-free calls
- Built-in memory card reader plays tracks from any Micro SD card (Micro SD Card Not Included)
- Built-in aux for wired connection
- Stereo & dynamic sound output
- Adjustable headband
- Foldable design
- Rechargeable battery
- Micro USB cable and auxiliary cable included

Safety Instructions

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids. Do not operate the unit if it exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit. Do not use the unit if it has been dropped or damaged in any way. Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk. Do not use the unit with wet hands. Do not put objects into any of the openings. Keep the unit free from dust, lint etc. Do not use this unit for anything other than its intended use. Keep the unit out of reach of children. This product is not a toy. Do not use the handset at excessive volume levels, as damage to hearing may occur.

Description of Parts:



1	LED lights
2	Auxiliary input
3	Indicator light
4	Built-in microphone
5	Previous track / Volume decrease (-)
6	Next track / Volume increase (+)
7	Charging port
8	On/Off / Mode button
9	Play/Pause / Phone / Light button
10	Micro SD (TF) card slot

INSTRUCTIONS FOR USE

Charging Instructions

- The Bluetooth Headphones comes with a built-in rechargeable battery. Before using it for the first time, we recommend you fully charge the battery. Please use the supplied USB Cord to charge the Bluetooth Headphones. Please charge for 3 - 4 hours.
- Connect the USB charging cable to a computer USB port and the Micro USB plug into the charging port of the headphones. The Indicator Light turns Red while the device is charging. It takes 3 - 4 hours for the headphones to charge fully. Indicator Light turns blue when the battery is fully charged.

Turning on/off the device

Long Press the On/Off button to turn ON/OFF the headphones.

Pairing the device with Bluetooth devices (phone or music device)

- Long Press the On/Off button to turn ON the headphones. An indication tone will sound and the indicator light will flash red and blue alternatively. Place the Bluetooth Headphones and Bluetooth source device (phone or music device) so that they are not more than 3 feet apart.
- Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions to enable Bluetooth on your device.
- Once you have activated Bluetooth on your device, select "**CAT HEADPHONE**" from the list of available Bluetooth devices.
- You might be prompted with "Pair with **CAT HEADPHONE?**" message on your source device, with "Cancel" and "OK" options. Please click "OK".
- If required, enter the password '0000' to confirm pairing.
- Once paired successfully, another indication tone will sound and the indicator light will flash blue slowly.
- You're now ready to stream wireless music to your headphones.
- If pairing is unsuccessful, turn off the device first and then re-pair following the above steps.
- Once you have paired the Bluetooth Headphones with a device, the Headphones will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.
- The Bluetooth Headphones will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.
- Once the Bluetooth Headphones pairs with your device, the music will transmit through the Bluetooth Headphones. Please refer to your device's user manual for further information.

Function Summary

Listening to Music

- Once the Headphones pair with your device, you can stream music wirelessly through the Bluetooth Headphones. Should you encounter any problems while streaming please refer your device's user manual for further information.

Control Function

Function	Operation	Button
Increase Volume	Playing music	Long press the Volume increase button to increase the volume
Decrease Volume	Playing music	Long press the Volume decrease button to decrease the volume
Pause	Playing music	Short press the Play/Pause button to pause the music

Play	Pausing	Short press the Play/Pause button to restart the music
Previous track	Playing music	Short press on the Previous Track button to return to the previous track
Next track	Playing music	Short press on the Next Track button to skip to the next track

(**Note:** An indication tone will alert you when the volume adjusts to maximum volume.)

Making a call with the Bluetooth Headphones in Bluetooth mode

Basic operation

Function	Operation	Button
Answer a call	Incoming call	Short Press the Phone button once to answer an incoming call
Reject a call	Incoming call	Long Press the Phone button for 2 seconds
End a call	Incoming call	After your phone conversation, short press the Phone button.
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

Please Note

- Not all mobile phones support all the functions listed above. Please refer to your mobile phone's user's manual for further information.
- Certain functions and indication tones may vary depending on your mobile phone.

Listening to Music using Micro SD (TF) card slot

1. Turn on the Headphone.
2. Insert Micro SD (TF) card into the card slot and music will automatically stream.
3. Short press Next track or Previous track button to move forward or backward on your playlist.
4. Short press Play/Pause button to Play or Pause a track.
5. Long press the Volume increase or Volume decrease button to increase or decrease the volume.

Note: While using Bluetooth, if you insert a Micro SD card, the Headphones will disconnect the Bluetooth connection and switch to Micro SD card function. You can press the Mode button again to select the Bluetooth mode.

Tips!!

1. Short press the Mode button to switch between different functions of the Headphones. The functions are – Bluetooth / Micro SD (TF) card.
2. When the headphones are not in use, turn it OFF to save battery power.

Listening to Music using AUX-In Mode

1. Insert the 3.5mm auxiliary cable (provided) to the Aux input of the Headphones, the other end of the cable connects to the audio device (such as computer / tablet etc.).
2. Select your favorite song at the source device and play.

(Note: Using this Aux-in mode, you do not need to turn on the Headphones and you need to control the volume increase/decrease, play/pause, next/previous track through your source device only).

LED Lights

1. Turn on the Headphones.
2. Short press the Light button 3 times to turn on/off the LED lights.

Do's and Don'ts

Do not play music at excessive levels. Damage to hearing and/or equipment may result.

Do not use outdoors in wet or damp surroundings.

Care and Maintenance

Read the following recommendations before using the Bluetooth Headphones. Follow these and you will enjoy the product for many years.

- Don't expose the Bluetooth Headphones to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the device.
- Don't expose the device to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the device in a fire as it will result in an explosion.
- Don't expose the device to contact with sharp objects as this will cause scratches and damage.
- Don't let the device fall on the floor as this may damage the internal circuit
- Don't attempt to disassemble the headphones as it may cause permanent damage to the device.

Specifications

Unit size	7.1" L x 3.1" D x 7.7" H
Unit weight	7.6 Oz
Bluetooth version	5.3
Bluetooth range	33 feet
Speaker output	2x20mW
Charging input voltage	DC 5V
Charging time	3 - 4 hours
Play time	4 - 5 hours
Built-in battery	350mAh
Micro SD (TF) card	Support up to 32GB

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.