

# Tag 2 - User Manual



**Note:** The Tag 2 devices must be installed to provide a separation distance of at least 20 cm from all persons.

#### Deploying Tag 2

Required Equipment: iPad and Tag 2

- 1. Log in the SafeLink app using the provided credentials.
- 2. In the menu at the top right corner select "Deployment". A corresponding map of the event location should be displayed.
- 3. In the dropdown menu select "Deploy Tag".
- 4. Turn the power switch of the Tag 2 on.
- 5. Select the approximate location of the Tag 2 in the map while pressing and holding the tag's button.
- 6. A pairing process should follow. Please hold the tag's button until the pairing process is complete.
- 7. Install the Tag 2 as instructed in the installation part.
- **Note:** The deployed Tag may easily be relocated, but its new location should be manually updated on the map.



## Installation

Required Equipment: Double-sided tape and Tag 2

- 1. Make sure that the deployed Tag 2 remains ON.
- 2. Use double-sided tape to attach the deployed Tag 2 to a wall at a desired location.
- 3. Make sure it is firmly attached to the wall.

## Monitoring

#### Required Equipment: iPad

1. Monitor the deployed Tag 2 devices using the SafeLink app. Active devices should appear in green on the event map.

IC Caution:

-English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

-French:

Le présentappareilestconf orme aux CNR d' Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes:

(1)l'appareil ne doit pas produire de brouillage, et

(2)l' utilisateur de l'appareildoit accepter tout brouillageradioélectriquesubi,mêmesi le brouillageest susceptible d'encompromettre le fonctionnement.

Radiation Exposure Statement

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 20cm entre le radiateur et votre corps.

#### FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different
  - from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.