
# 蓝色虚线为折痕线,不印刷



# **■** IMPORTANT SAFETY INSTRUCTIONS

- 2. Children over 8 and persons with reduced physical, sensory or cognitive
- 4. Cleaning and maintenance should not be made by children.

2. Do not use the device with wet hands or submerge the device into water or

- . 1. Please consult your doctor before use if you are any of the following
- Persons who had undergone eye surgery or eye conditions such as
- Persons with skin infections, sensitivity, redness and/or burns on the skin

- Persons with a heart condition, malignant tumors, or other serious health
- 2. Remove contact lenses, glasses, false eyelashes, hairpins, and any other
- 3. Do not use the device under blankets, pillows, or any other object that can
- 4. Do not use the device if it is not working properly, has been damaged, or dropped into water. Return it to the service center for examination and repair.

01

- 5. Do not use the device while driving, walking or running.
  6. Only use the charger (DC 5V 1A, not included) to recharge the device.
- 7. Avoid contact with sharp objects.
- 8. Use heated surfaces carefully, as they may cause serious burns. Do not use over insensitive skin areas or on persons with poor circulation. Children or incapacitated persons should not use heat unattended.
- High temperature may cause burns to occur regardless of the control setting. Do not use the device on infants, persons who are with disabilities, or sleeping or unconscious. Check frequently where the skin is in contact with the heated area to reduce the risk of blistering.


#### SAVE THESE INSTRUCTIONS

## II WHAT'S INCLUDED

Charging Cable x 1 User Manual x 1 Quick Guide x 1

### II CHARGING YOUR EYEFIT

Fully charge the device before the first use




Note: Do not use the device while charging.

### **III WEARING YOUR EYEFIT**

- 1. Remove any eye accessories (e.g. eyeglasses, false eyelashes, etc.) before
- 2. Wear the device and adjust the elastic band for a proper fit using the



# **II USING YOUR EYEFIT**



#### Dower / Mode Button

- 1. Press and hold to turn on/off the device.
- After power on, mode 1, built-in music and Bluetooth will be enabled by default, and the indicator turns white.
- 2. Short press to switch between 5 modes.
- M 1: Soft Pressure + Heat M 2: Strong Pressure + Heat

- M 4: Soft Pressure M 5: Strong Pressure
- 3. Press twice to switch between voice mode and silent mode. In silent mode, the voice broadcast and music will be disabled, and you can resume the Bluetooth music via your mobile device.

- · For optimal results, it is recommended to use the device for 15 minutes every day.

  This device features a 15mins auto-off timer that automatically shuts the
- device off after 15 minutes of continuous use.

Indicator
Turns solid white
Turns solid blue
Flashes red slowly
Turns solid red
Keeps flashing red quickly for 1 minute and then turns off, indicating an improper charger is used.

# PUREHEAL

Model: PH-G02

### US Importer: JOICOM CORPORATION 14129 The Merge Street, Building 3 Unit A, Eastvale, CA 92880

Manufacturer: Shenzhen Ruiyi Business Technology Co., Ltd. No. 810-C063, 8th Floor, Xiangbin International Financial Centre, No.18, West Free Trade Street, China Special Economic Zone, Qianhai Bay, Shenzhen, Guangdong Province, 518000 China

Made in China

NA1

### **■** CONNECTING TO BLUETOOTH

1. Turn on your device and enable Bluetooth on your mobile device. 2. Search for "PH-GO2" via your Bluetooth settings and connect to play your music playlist through the device.

Once paired successfully, the device will be automatically connected to Bluetooth each time turned on, followed by a voice prompt "Bluetooth connected".

# **■ CARE AND MAINTENANCE**

- 1. Turn off the device and allow it to cool down before cleaning or storing. 2. Wipe the device surface with a soft cotton cloth slightly dampened with mild detergent. Do not use abrasive cleaners or solvents.

  3. Always keep the device dry.
- 4. Store the device in a cool, dry place. Do not expose it to direct sunlight,
- moisture, heat, and corrosive gases.

  5. If the device has not been used for over 3 months, charge it from time to
- time to prolong its lifespan.

  6. Do not disassemble or repair the device by yourself as this may cause damage and void the manufacturer's warranty.

### **■** SPECIFICATIONS

Product Name: Eye Massager

Battery Capacity: 1200mAh

Model: PH-G02 Input: 5V === 1A Rated Power: 5W

### II TROUBLESHOOTING GUIDE

Possible Cause

Power-on failure	Out of power	Charge the device
	Short press the Power button	Long press the Power button to turn on the device
Low air pressure	Low battery	Charge the device
	The mode with soft pressure is selected	Select the mode with strong pressure
No air pressure	The mode without air pressure is selected	Select the mode with pressure
The device shuts off suddenly	Out of power	Charge the device
	The built-in auto-off timer is activated	Restart the device for another massage session if needed
Charging failure	Use other types of charging cables	Use the provided charging cable only
Charging faiture	Use a charger with a voltage higher than 5V	Use a DC 5V 1A charger (not included)
Fail to play Bluetooth music through the device	Bluetooth is not connected or disconnected	Enable Bluetooth on your mobile device and connect to "PH-GO2"
	Silent mode is activated	Tap on your phone to play music or double press the Power button on the device to switch to voice mode
	Connected to another mobile device	Ensure the device is disconnected from another mobile device
There is work noise	For this type of massager, the consistent work noise is considered normal	No action is necessary

If you encounter any other problems, please contact our customer service.

### **■** WARRANTY POLICY (1-YEAR PERIOD)

The manufacturer's warranty is void under the following circumstances but not limited to:

- Improper or inadequate maintenance or modification.
- Accident, misuse, abuse, contamination, or other external causes.
- The use of unspecified accessories. · Loss or damage in transit.
- Damages that occur as a result of one's failure to follow the instructions.

# II CUSTOMER SERVICE

We have an award-winning warranty, exchange, and customer service team that guarantees hassle-free solutions to any issue you might have within business hours.



order number within the specified warranty period. DO NOT dispose of any product parts as they may be required for inspection/repair.

\* For defective products or the return of items, please contact us with your

#### FCC Regulatory Compliance mplies with part 15 of the FCC Rules. Operation is subject to the followin

two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

his equipment complies with IC RSS-102 radiation exposure limits set forth for an