


尺寸:105x148mm


材质:100g书纸

工艺:双面四色印刷 折页













Bluetooth









① 2.4G/Num Indicator:

please look for it carefully. Please contact us to get the free replacement if you have lost the USB

Q1: What should I do if the keyboard gets delayed or stuck?

Please check whether the charging port is connected.

Q3: What should I do if the backlight stops working?

Please try to restart the keyboard and mouse.

Q4: Where is my USB receiver?

Please charge for half an hour and then re-insert the USB.

Try to change the USB port, and if the problem can not be solved, please

The USB receiver is placed on top of the keyboard inside the package,

- 11 -

Please try to replace the charging cable.

feel free to contact us.

Please check there is no 2.4GHz device (e.g. router) nearby to interfere with the connection.

Please check the keyboard has been fully charged. Please check there is no full metal case that may block the signal.

4 ) Please do not expose this product to water because it may cause Q2: What should I do if the keyboard and mouse can not be charged?

short-circuit and damage the product. 5 ) Please do not drop or hit this product because shocks may damage

the components inside.

Changes or modifications not expressly approved by the party

Q5: If the Bluetooth connection fails, what steps should I take? This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC A5: Please attempt to reconnect by removing any other connected Rules. These limits are designed to provide reasonable protection Bluetooth devices from your device. Alternatively, you can turn off the mouse, then turn it on again, and finally reopen the device to establish a against harmful interference in a residential installation. This connection with the mouse. equipment generates uses and can radiate radio frequency

1 ) Please fully charge the keyboard when you first receive the product as this helps to maintain the battery life.

2) Please remove the power supply when charging is complete. 3) If the keyboard is not used for a long time, it is recommended to turn

off the power switch of the keyboard.

6) Please do not place this product near the extreme heat or sources of

receiver is connected. -Consult the dealer or an experienced radio/TV technician for help

> responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is

The multimedia keys are for Win 8 and Win 10, for other systems,

energy and, if not installed and used in accordance with the

will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which

can be determined by turning the equipment off and on, the user

is encouraged to try to correct the interference by one or more of

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from

communications. However, there is no guarantee that interference

instructions, may cause harmful interference to radio

-Reorient or relocate the receiving antenna.

the following measures:

that to which the

there may be no function for some combined keys.

subject to the following two conditions: (1) This device may not cause harmful interference

(2) This device must accept any interference received, including interference that may cause undesired operation.