



Bluetooth Speaker

Product layout



What's in the box

1 x EL162 Bluetooth speaker
1 x Users manual

1 x Micro USB charge cable
1 x AUX cable

Charging

1. Connect to a PC/Laptop/Mac or any 5V USB adapter with the USB cable included.
2. The Red LED will turn ON when charging, and turn OFF when fully charged.
3. Unplug the USB cable when fully charged.

Note: The Red LED will flash and makes a sound when the battery power is low (<21%).

Pairing with Bluetooth enabled devices (Mobile phones/Tablets/PC/Mac etc.)

1. Keep the speaker and device within 1 meter of each other.
2. Switch on the speaker, the LED indicator will blink quickly in blue while the speaker enters search mode.
3. Start the Bluetooth function on your mobile device and look for "EL162" in the Bluetooth device list (depending on the Bluetooth version of your device you may have to enter pass code '0000').
4. If pairing with PC/Mac, open system preference of sound to set speaker as output channel.
5. After successfully connecting, the LED will change to solid blue.

Note:

- If the pairing was not successful, turn off the speaker and re-pair again.
- After successful pairing, paired devices will remember each other so there is no need to pair again unless pairing information is deleted.
- To pair with a new device, just follow steps 1-5 above after un-pairing the existing device.

Re-connecting to a paired device

If the speaker does not connect to the last used device automatically, then you will need to select it manually from the list of devices on your mobile device.

Volume control

A short press of volume+/- will change the volume in small steps.

You can also adjust volume by Bluetooth devices themselves.

Previous/Next

Long press Volume+/Next to go to next track.

Long press Volume-/Previous to go to previous track.

Play/Pause/Bluetooth

Short press to pause music play, press again to continue music play.

Long press to disconnecting Bluetooth connection from existing device, then speaker will enter search mode.

Hands-free phone calls

1. Press the "Hands-free" button to answer an incoming phone call.
2. Press again to end a call.
3. Use the volume buttons to change the volume of the call.

Connecting external devices (AUX port)

You can connect any music device to the TAMBOR speaker via the AUX port using the cable included. The speaker will not use the Bluetooth function while connected via this cable.

FCC Warning:

FCC ID: 2ABPR-SC-400

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter