

EN
AB

SP9i

User Manual

Thanks for using our wireless electronic products. To make good and full use of our products, please read the manual carefully before using the products. Notice: to avoid unnecessary troubles, please do not disassemble these products by yourself and please use the standard charger to charge.

Product Overview

Charging Contact Pin

Earbud Cap

Ear hook

Indicator Light / MIC

MFB Power Switch

Charging Case Indicator Light

USB Charging Port

1 Adjust ear hook through auricle to a comfortable position

2 Tap the earbuds slightly to make it closely attached to your ears

First time using

1.Tear off the insulating film.

2.Put the earbuds into the charging case to charge.

3.Take out from the case, the indicator will turn red and blue alternately.

Warm notice: If the earbuds are not turned on or there is no sound coming out, please put them back in the charging case again to make sure that they are in the charging state before taking them out for use (red/blue light flash alternately)

5.Turn on Bluetooth function on your phone and search for **【SP9i】** and connect it.

Warm notice
△ If indicators of both earbuds keep flashing red and blue, Click either earbud's power switch twice. Then the indicator of one earbud will flash red and blue alternately, another will go off. (in pairing mode)

Button control

ON

1. When open the case and take out to use;

2. Hold MFB power switch for 3s to turn on (when not in the case but off).

OFF

1. When back into the case to charge;

2. Hold MFB power switch for 5s when they are not connected to phone;

3. When no connection for 5 minutes. (but off).

2x **Accept**
L / R Earbud

2x **Decline**
L / R Earbud

2s **Reject**
L / R Earbud

2x **Previous track**
L Earbud

2x **Next track**
R Earbud

1x **Play / Pause**
L / R Earbud

Hold **Volume-**
L Earbud

Hold **Volume+**
R Earbud

3x **Voice assistant**
L / R Earbud

Warm notice
For any single earbud, when it is in standalone mode, you can't use it to play the previous song or decrease the volume.

Restore factory setting

1. Disable the Bluetooth function of the mobile phone or quick clicks the left and right earbuds four times when the earbuds is not connected (red and blue light flash alternately) to restore factory settings, and then they will automatically power off.

2.Please delete all the connection records on the phone and re-search **【SP9i】** after deleting the records and then reconnect.

Earbuds indicator

Status	Light
Turn on	Blue flashes for 1s
Turn off	Red light goes off after flash for 1s
After TWS pairing, the phone successfully connected,in standby state	No light
Connection is successful,Standby status	No light
TWS connection successfully	One earbud will flash red and blue alternately, another will go off.
Music status/Talking	No light
Reconnection status after remote disconnection (Mobile phone)	One earbud will flash red and blue alternately, another will go off.
Reset	Red light flashes once, then power off
Low power	Red light of earbud flashes once every 5s
Charging	Red light on
Full power	Red light off

Charging case indicator

Status	Orange light
Charging to case	Orange light flashes
Full Battery	Orange light on
Low Battery	Orange light flashes
Charging case charging for earbuds	Orange light on
Earbuds fully charged	Orange light off

Charging case
Please use a charger with an output voltage of DC5V/1A to charge the charging case. You can also use a computer USB or other USB interface charger to charge (Must choose a charger certified by regular manufacturers) .

Notice:
△ When the charging case is out of power, it may cause the earbuds fail to shut down and remain connected to the phone even when they are placed in the charging case. So please remember to charge the charging case in time.

Parameter specification

Version	V5.3+EDR
Support	HSP,HFP,A2DP,AVRCP
Transmission distance	10m
Frequency range	2.402GHz~2.480GHz
Hi-fi equipment	Φ10mm*2
Impedance	16Ω
Standby time	100 hours
Talk time	5 hours
Music Playing Time	6 hours
Charging case battery capacity	300mAh
Earbud battery capacity	50mAh
Earbud charging time	About 1.5 hours
Standby Time (full power in off state)	About 5 months
Weight(single earbud)	7.4 g

Attentions

△ If there is noise, broken sound, or low sound, please take off the silicone ear cap and wipe it with a cotton swab.

△ If the earbud is not charging properly, please wipe the charging column with a cotton swab, and then charge it again.

Please make sure that the products are dry. If there is water droplet on the surface, please wipe it with a dry cloth before putting them back into the charging case to avoid damaging the device.

Attentions

1.Do not use corrosive liquid to clean this product.

2.If it is stained with any chemicals, please rub it with a wet cloth wet with clean water.

3.Do not use this product under extreme icircumstances for temperature below -10 degree iCelsius or above 60 degree Celsius .

4.To avoid explosion, please do not throw this iproduct into fire.

5.To avoid scratches, please do not let the iearbuds expose to sharp objects.

6.Do not insert objects into the earbuds, iotherwise it would cause damage to the internal components.

7.Do not disassemble the product.

8. In order to keep their lifetime, please keep regular irectarge to the earbuds and do not leave them iempty battery.

9. Please do not charge products with ipower adapter over 2A current. Excessive icurrent may cause damage to battery.

Battery Warning !

There is a built-in lithium battery in this product. Please do NOT expose it to fire or throw it into fire, otherwise it will cause explosion.

PDF
Adobe

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.