

# Wireless Range Extender

## Mobile phone setup

### 2.4G / 5G

- 1** Plug in your will extender

The 2 lights on the right will be on except the "Extender".

**Abnormal:** Press "reset" hole on the bottom of the product for 8s with paperclip, or contact seller


- 2** Connect your extender SSID

Both 2.4G and 5G are available, choose 5G to setting

**\*NOTE:** You can not surf the Internet until you finish all the setting steps, pls continue


- 3** Sign in to management page (Google Chrome & Mozilla Firefox recommended)

**\*NOTE:** Pls make sure that you have connected the SSID (wiFi-5g-xxxx) of the will extender successfully, most of the PC/Smart will recognize and Sign in to the management page automatically. If not, pls enter 192.168.188.1 on the new browser


- 4** Enter the default password: admin

REPEATER

Login Password: admin


- 5** Scan and select your host router SSID

Please select the main route to be extended

  - ChinaNet 5BC8
  - ITV 5BC8
  - Five 112
  - 1256
- 6** Enter the password of your host router

**\*NOTE:** Pls make sure of the right password (special characters not allowed, like "%")


- 7** Set your Extender SSID and password

Please enter extender wireless information

Default SSID: original SSID-Pro-2.4G/5G can be changed

Default router password


- 8** Check details and make a note of the Wireless Info

Wireless info

After check, click "Start Connect" and wait 30-60s


- 9** When you finished setting, pls wait 30-40s until extender light is on

After the setting is completed, please observe the signal indicator. If it lights up, it means that the setup is successful. Please connect CSG pin to the Internet reference equipment.


- 10** The led light will light up, that means it Extender Mode successfully.

**\*NOTE:**


- 11** Reconnect your extender wifi

Reconnect the extender SSID, then get access to Internet



# Wireless Range Extender

## PC setup step

- 1** Plug in your will extender

The 2 lights on the right will be on except the "Extender".

**Abnormal:** Press "reset" hole on the bottom of the product for 8s with paperclip, or contact seller



- 2** Connect your extender SSID

Both 2.4G and 5G are available, choose 5G to setting

**\*NOTE:** You can not Surf the Internet until you finish all the setting steps, pls continue


- 3** Sign in to management page (Google Chrome & Mozilla Firefox recommended)

**\*NOTE:** Pls make sure that you have connected the SSID (wiFi-5g-xxxx) of the will extender successfully, most of the PC/Smart will recognize and Sign in to the management page automatically. If not, pls enter 192.168.188.1 on the new browser.


- 4** Enter the default password: admin

Login

Username: admin  
Password: admin


- 5** Scan and select your host router SSID

Please select the main route to be extended

**\*NOTE:** Different Channels working together would interfere signal, and the network speed will get slow. Please change the main router channel in time


- 6** Enter the password of your host router


**\*NOTE:** Pls make sure of the right password (special characters not allowed, like "%")


- 7** Set your Extender SSID and password

Please enter extender wireless info

Default SSID: original SSID-Pro-2.4G/5G, can be changed

Recommend: Default router password, can be changed



- 8** Check details and make a note of the Wireless Info

Wireless info

After check, click "Start Connect" and wait 30-60s


- 9** When you finished setting, pls wait 30-40s until extender light is on.

After the setting is completed, please observe the signal indicator. If it lights up, it means that the setup is successful. Please connect CSG pin to the Internet reference equipment.



- 10** The led light will light up, that means it Extender Mode successfully.

**\*NOTE:**


- 11** Reconnect your extender wifi

Reconnect the extender SSID, then get access to Internet





**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.