11N40SISO_Ant2_2447_0.009~30

11N40SISO_Ant2_2447_30~1000

Copyright © Huawei Technologies Co., Ltd.



11N40SISO_Ant2_2447_1000~26500



11N40SISO_Ant1_2452_0~Reference

Copyright © Huawei Technologies Co., Ltd.

11N40SISO_Ant1_2452_0.009~30

11N40SISO_Ant1_2452_30~1000

Copyright © Huawei Technologies Co., Ltd.



11N40SISO_Ant1_2452_1000~26500

11N40SISO_Ant2_2452_0~Reference

Copyright © Huawei Technologies Co., Ltd.



11N40SISO_Ant2_2452_0.009~30

11N40SISO_Ant2_2452_30~1000

Copyright © Huawei Technologies Co., Ltd.



11N40SISO_Ant2_2452_1000~26500

11G-CDD_Ant1_2412_0~Reference

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant1_2412_0.009~30

11G-CDD_Ant1_2412_30~1000

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant1_2412_1000~26500

11G-CDD_Ant2_2412_0~Reference

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant2_2412_0.009~30

11G-CDD_Ant2_2412_30~1000

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant2_2412_1000~26500



11G-CDD_Ant1_2417_0~Reference

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant1_2417_0.009~30

11G-CDD_Ant1_2417_30~1000

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant1_2417_1000~26500



11G-CDD_Ant2_2417_0~Reference

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant2_2417_0.009~30

11G-CDD_Ant2_2417_30~1000

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant2_2417_1000~26500

11G-CDD_Ant1_2437_0~Reference

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant1_2437_0.009~30

11G-CDD_Ant1_2437_30~1000

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant1_2437_1000~26500

11G-CDD_Ant2_2437_0~Reference

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant2_2437_0.009~30

11G-CDD_Ant2_2437_30~1000

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant2_2437_1000~26500



11G-CDD_Ant1_2457_0~Reference

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant1_2457_0.009~30

11G-CDD_Ant1_2457_30~1000

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant1_2457_1000~26500



11G-CDD_Ant2_2457_0~Reference



Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant2_2457_0.009~30

11G-CDD_Ant2_2457_30~1000

11G-CDD_Ant2_2457_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant1_2462_0~Reference

11G-CDD_Ant1_2462_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant1_2462_30~1000



11G-CDD_Ant1_2462_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11G-CDD_Ant2_2462_0~Reference



11G-CDD_Ant2_2462_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11G-CDD_Ant2_2462_30~1000



11G-CDD_Ant2_2462_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N20MIMO_Ant1_2412_0~Reference



11N20MIMO_Ant1_2412_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2412_30~1000



11N20MIMO_Ant1_2412_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant2_2412_0~Reference



11N20MIMO_Ant2_2412_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant2_2412_30~1000



11N20MIMO_Ant2_2412_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2417_0~Reference

11N20MIMO_Ant1_2417_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2417_30~1000



11N20MIMO_Ant1_2417_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant2_2417_0~Reference



11N20MIMO_Ant2_2417_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant2_2417_30~1000



11N20MIMO_Ant2_2417_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2437_0~Reference



11N20MIMO_Ant1_2437_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2437_30~1000



11N20MIMO_Ant1_2437_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N20MIMO_Ant2_2437_0~Reference

11N20MIMO_Ant2_2437_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant2_2437_30~1000



11N20MIMO_Ant2_2437_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2457_0~Reference

11N20MIMO_Ant1_2457_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2457_30~1000



11N20MIMO_Ant1_2457_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N20MIMO_Ant2_2457_0~Reference



11N20MIMO_Ant2_2457_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant2_2457_30~1000



11N20MIMO_Ant2_2457_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2462_0~Reference



11N20MIMO_Ant1_2462_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant1_2462_30~1000



11N20MIMO_Ant1_2462_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N20MIMO_Ant2_2462_0~Reference



11N20MIMO_Ant2_2462_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N20MIMO_Ant2_2462_30~1000



11N20MIMO_Ant2_2462_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N40MIMO_Ant1_2422_0~Reference



11N40MIMO_Ant1_2422_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant1_2422_30~1000



11N40MIMO_Ant1_2422_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant2_2422_0~Reference



11N40MIMO_Ant2_2422_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant2_2422_30~1000



11N40MIMO_Ant2_2422_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N40MIMO_Ant1_2427_0~Reference



11N40MIMO_Ant1_2427_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant1_2427_30~1000



11N40MIMO_Ant1_2427_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N40MIMO_Ant2_2427_0~Reference

11N40MIMO_Ant2_2427_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant2_2427_30~1000



11N40MIMO_Ant2_2427_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N40MIMO_Ant1_2437_0~Reference

11N40MIMO_Ant1_2437_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant1_2437_30~1000



11N40MIMO_Ant1_2437_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N40MIMO_Ant2_2437_0~Reference

11N40MIMO_Ant2_2437_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant2_2437_30~1000



11N40MIMO_Ant2_2437_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N40MIMO_Ant1_2447_0~Reference



11N40MIMO_Ant1_2447_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant1_2447_30~1000



11N40MIMO_Ant1_2447_1000~26500

Copyright © Huawei Technologies Co., Ltd.



11N40MIMO_Ant2_2447_0~Reference

11N40MIMO_Ant2_2447_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant2_2447_30~1000



11N40MIMO_Ant2_2447_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant1_2452_0~Reference

11N40MIMO_Ant1_2452_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant1_2452_30~1000



11N40MIMO_Ant1_2452_1000~26500

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant2_2452_0~Reference



11N40MIMO_Ant2_2452_0.009~30

Copyright © Huawei Technologies Co., Ltd.

11N40MIMO_Ant2_2452_30~1000



11N40MIMO_Ant2_2452_1000~26500

Copyright © Huawei Technologies Co., Ltd.

Copyright © Huawei Technologies Co., Ltd.

Appendix H: Radiated Spurious Emission & Spurious in Restricted Band

Note: We tested all modes, but the data presented below is the worst case.

Below 1GHz, RBW = 100 kHz, VBW = 300 kHz.

Above 1GHz, RBW = 1 MHz, VBW = 3 MHz.

The simultaneous transmission has been considered

Copyright © Huawei Technologies Co., Ltd.

1.1 Part 1: Testing Range of “9 kHz to 30MHz”

Note 1: The test results and plot for testing range of “9 kHz to 30MHz” showed as below is the WORST case for all Test Modes and Channels. This range will not be presented for each Test Mode and each Channel.



Site : 03CH01-SZ
Condition : -13DBM
: RBW:9.000KHz VBW:30.000KHz

Copyright © Huawei Technologies Co., Ltd.

1.2 Part 2: Testing Range of “30 MHz to 1 GHz”

Note 1: The test results and plot for testing range of “30 MHz to 1 GHz” showed as below is the WORST case for all Test Modes and Channels. This range will not be presented for each Test Mode and each Channel.

Note 2: The emissions in this range are mainly from the Platform Device (Notepad PC and its ancillary components).



	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	36.79	30.20	-9.80	40.00	41.12	20.34	0.34	31.60	QP
2	55.22	19.70	-20.30	40.00	37.55	13.25	0.50	31.60	QP
3	88.20	16.90	-26.60	43.50	33.31	14.34	0.75	31.50	QP
4	100.81	19.80	-23.70	43.50	33.68	16.76	0.86	31.50	QP
5	176.47	23.26	-20.24	43.50	37.74	15.35	1.46	31.29	QP
6 pk	638.19	31.06	-14.94	46.00	34.49	24.65	3.12	31.20	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3 Part 3: Testing Range of “1 GHz to 3 GHz”

Note 1: The testing range of “1 GHz to 3 GHz” is for checking radiated emissions located in restricted bands near the EUT operating bands.

Note 2: Two limits are required in the testing range above 1 GHz, that is Peak limit (74 dBμV/m) and Average Limit (54 dBμV/m).

Note 3: The peak spike exceeds the limit line is EUT’s operating frequency.

1.3.1 Test Mode: 11B



Copyright © Huawei Technologies Co., Ltd.

1.3.1.1 Channel 1 @Ant 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI core0
: CH1

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	43.80	-10.20	54.00	38.49	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI core0
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.70	51.49	-22.51	74.00	46.18	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.1.2 Channel 2 @Ant 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11b
: core0
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	41.66	-12.34	54.00	36.35	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11b
: core0
: CH2

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2387.70	53.60	-20.40	74.00	48.29	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

Copyright © Huawei Technologies Co., Ltd.

2, Margin=Limit – Level

1.3.1.3 Channel 10@Ant 1




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11b
              : core0
              : CH10
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
        ________ _____ _____ _____ _____ _____ _____ _____ _________
             MHz dBuV/m    dB dBuV/m  dBuV  dB/m    dB    dB

1 pp  2483.56  47.49  -6.51  54.00 41.72 31.86  6.91 33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11b
: core0
: CH10

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2488.76	57.88	-16.12	74.00	52.04	31.93	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.1.4 Channel 11@Ant 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI core0
: CH11

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2487.20	45.35	-8.65	54.00	39.58	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI core0
: CH13

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.32	63.30	-10.70	74.00	57.53	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.1.5 Channel 1@Ant2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI core1
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.17	41.25	-12.75	54.00	35.94	31.50	6.81	33.00	Average

Huawei Proprietary and Confidential
Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI core1
: CH1

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.07	51.57	-22.43	74.00	46.26	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.1.6 Channel 2@Ant2




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11b
              : core1
              : CH2
```

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	40.49	-13.51	54.00	35.18	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11b
: core1
: CH2

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	50.03	-23.97	74.00	44.72	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.1.7 Channel 10@Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11b
: core1
: CH10

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.72	42.86	-11.14	54.00	37.09	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11b
: core1
: CH10

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2486.68	57.98	-16.02	74.00	52.21	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.1.8 Channel 11@Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI core1
: CH11

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.72	41.63	-12.37	54.00	35.86	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI core1
: CH11

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.80	54.75	-19.25	74.00	48.98	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.2Test Mode: 11G



Copyright © Huawei Technologies Co., Ltd.

1.3.2.1 Channel 1 @Ant 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11G 2.4G WIFI core0
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	40.96	-13.04	54.00	35.65	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11G 2.4G WIFI core0
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.59	60.54	-13.46	74.00	55.23	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.2.2 Channel 2 @Ant 1




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11G
              : core0
              : CH2
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
        ________ _____ _____ _____ _____ _____ _____ _____ _________
             MHz dBuV/m    dB dBuV/m  dBuV  dB/m    dB    dB

1 pp  2389.80  42.47 -11.53  54.00 37.16 31.50  6.81 33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11G
: core0
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	54.61	-19.39	74.00	49.30	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.2.3 Channel 1 @Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11G 2.4G WIFI core1
: CH1

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	39.73	-14.27	54.00	34.42	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11G 2.4G WIFI core1
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	50.03	-23.97	74.00	44.72	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.2.4 Channel 2 @Ant 2

SPORTON LAB.



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11G
: core1
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.70	40.05	-13.95	54.00	34.74	31.50	6.81	33.00	Average

Huawei Proprietary and Confidential
Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11G
: core1
: CH2

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	48.06	-25.94	74.00	42.75	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.2.4 Channel 10@Ant 1




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11G
              : core0
              : CH10
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
          MHz dBuV/m     dB dBuV/m   dBuV   dB/m     dB     dB
1 pp  2483.88  42.72 -11.28  54.00  36.95  31.86   6.91  33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11G
: core0
: CH10

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2487.16	60.26	-13.74	74.00	54.49	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.2.5 Channel 11 @Ant 1




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 11G 2.4G WIFI core0
              : CH11
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
          MHz dBuV/m     dB dBuV/m   dBuV   dB/m     dB     dB
1 pp  2483.64  42.20 -11.80  54.00  36.43  31.86   6.91  33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11G 2.4G WIFI core0
: CH11

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.96	58.11	-15.89	74.00	52.34	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.2.6 Channel 10@Ant 2




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11G
              : core1
              : CH10
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
        ________ _____ _____ _____ _____ _____ _____ _____ _________
             MHz dBuV/m    dB dBuV/m  dBuV  dB/m    dB    dB

1 pp  2483.60  41.15 -12.85  54.00 35.38 31.86  6.91 33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11G
: core1
: CH10

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2485.28	60.27	-13.73	74.00	54.50	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.2.7 Channel 11@Ant 2




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 11G 2.4G WIFI core1
              : CH11
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
          MHz dBuV/m     dB dBuV/m   dBuV   dB/m     dB     dB
1 pp  2483.56  40.69 -13.31  54.00  34.92  31.86   6.91  33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11G 2.4G WIFI core1
: CH11

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2488.76	52.33	-21.67	74.00	46.49	31.93	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.3Test Mode: 11N20



Copyright © Huawei Technologies Co., Ltd.

1.3.3.1 Channel 1@Ant 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N20 2.4G WIFI core0
: CH1

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.70	40.70	-13.30	54.00	35.39	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N20 2.4G WIFI core0
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.70	50.94	-23.06	74.00	45.63	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.3.2 Channel 2@Ant 1




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11N20
              : core0
              : CH2
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
          MHz dBuV/m     dB dBuV/m   dBuV   dB/m     dB     dB
1 pp  2389.91  42.19 -11.81  54.00  36.88  31.50   6.81  33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N20
: core0
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.49	54.88	-19.12	74.00	49.57	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.3.3 Channel 1@Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N20 2.4G WIFI core1
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.59	40.09	-13.91	54.00	34.78	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N20 2.4G WIFI core1
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1	pp	2389.80	49.01	-24.99	74.00	43.70	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.3.4 Channel 2 @Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N20
: core1
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	39.74	-14.26	54.00	34.43	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N20
: core1
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	49.27	-24.73	74.00	43.96	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.3.5 Channel 10 @Ant 1




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11N20
              : core0
              : CH10
```

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2485.00	41.75	-12.25	54.00	35.98	31.86	6.91	33.00	Average



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N20
: core0
: CH10

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2486.08	58.86	-15.14	74.00	53.09	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.3.6 Channel 11 @Ant 1




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 11N20 2.4G WIFI core0
              : CH11
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
          MHz dBuV/m     dB dBuV/m   dBuV   dB/m     dB     dB
1 pp  2483.52  42.01 -11.99  54.00  36.24  31.86   6.91  33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N20 2.4G WIFI core0
: CH11

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.60	58.03	-15.97	74.00	52.26	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

Copyright © Huawei Technologies Co., Ltd.

2, Margin=Limit - Level

1.3.3.7 Channel 10@Ant 2




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11N20
              : core1
              : CH10
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
        _______ _____ _____ _______ _____ _____ _____ _____ _________
            MHz dBuV/m    dB dBuV/m  dBuV  dB/m    dB    dB

1 pp  2483.52  41.54 -12.46  54.00 35.77 31.86  6.91 33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.




```
Site          : 03CH01-SZ
Condition     : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:3000.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11N20
              : core1
              : CH10
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
          MHz dBuV/m     dB dBuV/m   dBuV   dB/m     dB     dB
1 pp  2484.36  54.65 -19.35  74.00  48.88  31.86   6.91  33.00 Peak
```

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.3.8 Channel 11@Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N20 2.4G WIFI core1
: CH11

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.36	40.63	-13.37	54.00	34.86	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N20 2.4G WIFI core1
: CH11

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2490.00	52.62	-21.38	74.00	46.78	31.93	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.4 Test Mode: 11N40



Copyright © Huawei Technologies Co., Ltd.

1.3.4.1 Channel 3 @Ant 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core0
: CH3

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	41.45	-12.55	54.00	36.14	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core0
: CH3

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	54.29	-19.71	74.00	48.98	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

Channel 4 @Ant 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: core0
: CH4

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	47.92	-6.08	54.00	42.61	31.50	6.81	33.00	Peak

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: core0
: CH4

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	61.59	-12.41	74.00	56.28	31.50	6.81	33.00	Peak

Copyright © Huawei Technologies Co., Ltd.

1.3.4.2 Channel 3 @Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core1
: CH3

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	39.45	-14.55	54.00	34.14	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core1
: CH3

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	49.81	-24.19	74.00	44.50	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.4.3 Channel 4 @Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: core1
: CH4

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	42.94	-11.06	54.00	37.63	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: core1
: CH4

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	55.20	-18.80	74.00	49.89	31.50	6.81	33.00	Peak

Copyright © Huawei Technologies Co., Ltd.

1.3.4.4 Channel 8 @Ant 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.56	44.61	-9.39	54.00	38.84	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 VERTICAL
: RBW:1000.000KHz VBW:3000.000KHz

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2499.84	52.23	-21.77	74.00	46.39	31.93	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.4.5 Channel 9 @Ant 1




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 11N40 2.4G WIFI core0
              : CH9
                        Over  Limit   ReadAntenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
          MHz dBuV/m     dB dBuV/m   dBuV   dB/m     dB     dB
1 pp  2483.60  42.08 -11.92  54.00  36.31  31.86   6.91  33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core0
: CH9

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2485.20	55.80	-18.20	74.00	50.03	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.4.6 Channel 8 @Ant 2




```
Site          : 03CH01-SZ
Condition     : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
              : RBW:1000.000KHz VBW:1.000KHz
              : ELLE-L04
              : 2.4G WIFI
              : 11N40
              : core1
              : CH9
                        Over  Limit   Read Antenna  Cable Preamp
          Freq  Level  Limit   Line  Level Factor   Loss Factor Remark
           MHz dBuV/m     dB dBuV/m  dBuV   dB/m     dB     dB
1 pp  2483.64  48.12  -5.88  54.00  42.35  31.86   6.91  33.00 Average
```


Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: core1
: CH9

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.04	61.76	-12.24	74.00	55.99	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.4.7 Channel 9@Ant 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core1
: CH9

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.72	41.10	-12.90	54.00	35.33	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core1
: CH9

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2492.76	52.53	-21.47	74.00	46.69	31.93	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.5 Test Mode: 11g-CDD



Copyright © Huawei Technologies Co., Ltd.

1.3.5.1 Channel 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11G 2.4G WIFI MIMO
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1	pp	2389.80	41.87	-12.13	54.00	36.56	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11G 2.4G WIFI MIMO
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	53.23	-20.77	74.00	47.92	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.5.2 Channel 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11G
: MIMO
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	41.66	-12.34	54.00	36.35	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11G
: MIMO
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1	pp	2389.91	52.60	-21.40	74.00	47.29	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.5.3 Channel 10

Data: 218




```
Site            : 03CH01-SZ
Condition       : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
                : RBW:1000.000KHz VBW:1.000KHz
                : ELLE-L04
                : 2.4G WIFI
                : 11G
                : MIMO
                : CH10
```

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.72	43.30	-10.70	54.00	37.53	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11G
: MIMO
: CH10

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.48	59.20	-14.80	74.00	53.43	31.86	6.91	33.00	Peak

Copyright © Huawei Technologies Co., Ltd.

1.3.5.4 Channel 11



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11G 2.4G WIFI MIMO
: CH11

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.68	44.82	-9.18	54.00	39.05	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11G 2.4G WIFI MIMO
: CH11

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.76	64.85	-9.15	74.00	59.08	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.6 Test Mode: 11N-20M-MIMO

1.3.6.1 Channel 1



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N20 2.4G WIFI MIMO
: CH1

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	42.22	-11.78	54.00	36.91	31.50	6.81	33.00	Peak

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N20 2.4G WIFI MIMO
: CH1

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.28	55.85	-18.15	74.00	50.54	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.6.2 Channel 2



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N20
: MIMO
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.70	40.96	-13.04	54.00	35.65	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N20
: MIMO
: CH2

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1	pp	2389.91	52.86	-21.14	74.00	47.55	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.6.3 Channel 10



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N20
: MIMO
: CH10

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.96	41.49	-12.51	54.00	35.72	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N20
: MIMO
: CH10

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2486.64	57.60	-16.40	74.00	51.83	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.6.4 Channel 11



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N20 2.4G WIFI MIMO
: CH11

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.56	43.69	-10.31	54.00	37.92	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N20 2.4G WIFI MIMO
: CH11

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2487.36	61.27	-12.73	74.00	55.50	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.7 Test Mode: 11N-40M-MIMO



Copyright © Huawei Technologies Co., Ltd.

1.3.7.1 Channel 3



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core1
: CH3

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	39.45	-14.55	54.00	34.14	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N40 2.4G WIFI core1
: CH3

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.80	49.81	-24.19	74.00	44.50	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.7.2 Channel 4



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: MIMO
: CH4

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.91	45.65	-8.35	54.00	40.34	31.50	6.81	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: MIMO
: CH4

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2389.70	58.64	-15.36	74.00	53.33	31.50	6.81	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit – Level

Copyright © Huawei Technologies Co., Ltd.

1.3.7.3 Channel 8



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: MIMO
: CH8

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.12	48.22	-5.78	54.00	42.45	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 2.4G WIFI
: 11N40
: MIMO
: CH8

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2483.52	63.76	-10.24	74.00	57.99	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.3.7.4 Channel 9



Site : 03CH01-SZ
Condition : AVG_BE_54 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:1.000KHz
: ELLE-L04
: 11N40 2.4G WIFI MIMO
: CH9

	Freq	Level	Over Limit	Limit Line	ReadAntenna Level	Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2485.80	46.52	-7.48	54.00	40.75	31.86	6.91	33.00	Average

Copyright © Huawei Technologies Co., Ltd.



Site : 03CH01-SZ
Condition : PEAK_BE_74 3m HF_ANT(3117)_119436 HORIZONTAL
: RBW:1000.000KHz VBW:3000.000KHz
: ELLE-L04
: 11N40 2.4G WIFI MIMO
: CH9

	Freq	Level	Over Limit	Limit Line	Read Level	Antenna Factor	Cable Loss	Preamp Factor	Remark
	MHz	dBuV/m	dB	dBuV/m	dBuV	dB/m	dB	dB	
1 pp	2484.88	61.37	-12.63	74.00	55.60	31.86	6.91	33.00	Peak

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

Copyright © Huawei Technologies Co., Ltd.

1.4 Part 4: Testing Range of "3 GHz to 18 GHz"

Note 1: The test results and plot for testing range of "3 GHz to 18 GHz" showed as below is the WORST case for all Test Modes and Channels. This range will not be presented for each Test Mode and each Channel.

Note 2: The testing range of "3 GHz to 18 GHz" is for checking radiated emissions located in restricted bands faraway from the EUT operating bands.

Note 3: Two limits are required in the testing range above 1 GHz, that is Peak limit (74 dBµV/m) and Average Limit (54 dBµV/m).



Copyright © Huawei Technologies Co., Ltd.

1.5 Part 5: Testing Range of “18 GHz to 26.5 GHz”



Copyright © Huawei Technologies Co., Ltd.

Appendix I: Conducted Emission at Power Port

Note: RBW =9 kHz, VBW = 30 kHz



MEASUREMENT RESULT: AV Detector

Frequency (MHz)	Level (dB μ V)	Limit (dB μ V)	Transd. (dB)	Margin (dB)	Line	PE
0.312854	26.78	49.89	9.7	23.12	L1	FLO
0.811527	24.18	46.00	9.7	21.82	L1	FLO
1.894110	22.53	46.00	9.7	23.47	L1	FLO
3.906351	31.68	46.00	9.7	14.32	L1	FLO
6.237600	30.32	50.00	9.7	19.68	L1	FLO
10.466240	31.24	50.00	9.7	18.76	L1	FLO

MEASUREMENT RESULT: PK Detector

Frequency (MHz)	Level (dB μ V)	Limit (dB μ V)	Transd. (dB)	Margin (dB)	Line	PE

Copyright © Huawei Technologies Co., Ltd.

0.347501	37.62	59.02	9.7	21.40	L1	FLO
0.782442	38.84	56.00	9.7	17.16	L1	FLO
1.522807	37.41	56.16	9.7	18.59	N	FLO
3.164994	45.05	56.00	9.7	10.95	L1	FLO
9.941758	39.17	60.00	9.7	20.83	N	FLO
12.964472	35.59	60.00	9.7	24.41	L1	FLO

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

END

Copyright © Huawei Technologies Co., Ltd.