



# USB Training Headset

## AC-304TR Dongle

### Lights

Red – Microphone muted  
Green – Microphone unmuted

Green – Agent AC-304TR headset microphone active  
Blue – Supervisor HS-1500BT headset microphone active

Blue flashing – Bluetooth Pairing  
Blue solid – Bluetooth Connected  
No light – Disconnected / Idle



First time pairing with the supervisor HS-1500BT headset.

- Turn on the supervisor HS-1500BT headset.

- Hold and continue to hold the Bluetooth button  and plug the USB connection in to the PC or laptop until Bluetooth light is flashing slowly.

If you have a question about your Cyber Acoustics AC-304TR, contact your local reseller, Cyber Acoustics sales representative or contact us at [www.cyberacoustics.com/support/contact](http://www.cyberacoustics.com/support/contact).

### Controls



Press once to mute the mic input;  
Press again to unmute.



Press once to increase the volume.  
Press & hold to increase the volume continuously until maximum level.



Press once to decrease the volume.  
Press & hold to decrease the volume continuously until minimum level.



Press & hold for 1 second to  
reconnect / disconnect.



Press & hold to switch between agent  
and supervisor headset.

# Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Unique Identifier: (AC-304TR)  
Responsible Party - Cyber Acoustics, Inc.  
3109 NE 109th Ave., Vancouver, WA 98682  
cyberacoustics.com



## Compliance Information Statement:

### FCC Part 15

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiving device
- Connect the equipment into an outlet on different circuit from the receiving device
- Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### RF exposure statement

This equipment complies with the FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux rayonnements de la FCC et de l'ISED établies pour un environnement non contrôlé. Cet émetteur ne doit pas être co-localisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

### IC WARNING

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
  - (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.