



NVNT	n40	5755	Ant1	5725	-36.66	2.33	-	-34.33	Peak	27	Pass
NVNT	n40	5755	Ant1	5725	-47.44	2.33	0.12	-44.99	Average	27	Pass
NVNT	n40	5795	Ant1	5850	-50.47	2.33	-	-48.14	Peak	27	Pass
NVNT	n40	5795	Ant1	5850	-58.12	2.33	0.12	-55.67	Average	27	Pass
NVNT	n40	5795	Ant1	5855	-50.92	2.33	-	-48.59	Peak	15.6	Pass
NVNT	n40	5795	Ant1	5855	-58.3	2.33	0.12	-55.85	Average	15.6	Pass
NVNT	n40	5795	Ant1	5875	-50.94	2.33	-	-48.61	Peak	10	Pass
NVNT	n40	5795	Ant1	5875	-58.44	2.33	0.12	-55.99	Average	10	Pass
NVNT	n40	5795	Ant1	5925	-50.1	2.33	-	-47.77	Peak	-27	Pass
NVNT	n40	5795	Ant1	5925	-57.96	2.33	0.12	-55.51	Average	-27	Pass
NVNT	ac20	5745	Ant1	5650	-48.81	2.33	-	-46.48	Peak	-27	Pass
NVNT	ac20	5745	Ant1	5650	-57.63	2.33	0.28	-55.02	Average	-27	Pass
NVNT	ac20	5745	Ant1	5700	-47.89	2.33	-	-45.56	Peak	10	Pass
NVNT	ac20	5745	Ant1	5700	-56.95	2.33	0.28	-54.34	Average	10	Pass
NVNT	ac20	5745	Ant1	5720	-42.05	2.33	-	-39.72	Peak	15.6	Pass
NVNT	ac20	5745	Ant1	5720	-53.93	2.33	0.28	-51.32	Average	15.6	Pass
NVNT	ac20	5745	Ant1	5725	-35.11	2.33	-	-32.78	Peak	27	Pass
NVNT	ac20	5745	Ant1	5725	-48.02	2.33	0.28	-45.41	Average	27	Pass
NVNT	ac20	5825	Ant1	5850	-39.24	2.33	-	-36.91	Peak	27	Pass
NVNT	ac20	5825	Ant1	5850	-54.08	2.33	0.28	-51.47	Average	27	Pass
NVNT	ac20	5825	Ant1	5855	-44.08	2.33	-	-41.75	Peak	15.6	Pass
NVNT	ac20	5825	Ant1	5855	-57.53	2.33	0.28	-54.92	Average	15.6	Pass
NVNT	ac20	5825	Ant1	5875	-50.04	2.33	-	-47.71	Peak	10	Pass
NVNT	ac20	5825	Ant1	5875	-58.74	2.33	0.28	-56.13	Average	10	Pass
NVNT	ac20	5825	Ant1	5925	-50.53	2.33	-	-48.20	Peak	-27	Pass
NVNT	ac20	5825	Ant1	5925	-58.12	2.33	0.28	-55.51	Average	-27	Pass
NVNT	ac40	5755	Ant1	5650	-48.98	2.33	-	-46.65	Peak	-27	Pass
NVNT	ac40	5755	Ant1	5650	-58.01	2.33	0.12	-55.56	Average	-27	Pass
NVNT	ac40	5755	Ant1	5700	-49.1	2.33	-	-46.77	Peak	10	Pass
NVNT	ac40	5755	Ant1	5700	-57.29	2.33	0.12	-54.84	Average	10	Pass
NVNT	ac40	5755	Ant1	5720	-36.92	2.33	-	-34.59	Peak	15.6	Pass
NVNT	ac40	5755	Ant1	5720	-51.04	2.33	0.12	-48.59	Average	15.6	Pass
NVNT	ac40	5755	Ant1	5725	-34.77	2.33	-	-32.44	Peak	27	Pass
NVNT	ac40	5755	Ant1	5725	-47.41	2.33	0.12	-44.96	Average	27	Pass
NVNT	ac40	5795	Ant1	5850	-50.4	2.33	-	-48.07	Peak	27	Pass
NVNT	ac40	5795	Ant1	5850	-58.43	2.33	0.12	-55.98	Average	27	Pass
NVNT	ac40	5795	Ant1	5855	-49.73	2.33	-	-47.40	Peak	15.6	Pass
NVNT	ac40	5795	Ant1	5855	-58.43	2.33	0.12	-55.98	Average	15.6	Pass
NVNT	ac40	5795	Ant1	5875	-49.97	2.33	-	-47.64	Peak	10	Pass
NVNT	ac40	5795	Ant1	5875	-58.58	2.33	0.12	-56.13	Average	10	Pass
NVNT	ac40	5795	Ant1	5925	-49.57	2.33	-	-47.24	Peak	-27	Pass





NVNT	ac40	5795	Ant1	5925	-58.56	2.33	0.12	-56.11	Average	-27	Pass
NVNT	ac80	5775	Ant1	5850	-50.29	2.33	-	-47.96	Peak	27	Pass
NVNT	ac80	5775	Ant1	5850	-57.94	2.33	0.25	-55.36	Average	27	Pass
NVNT	ac80	5775	Ant1	5855	-50.06	2.33	-	-47.73	Peak	15.6	Pass
NVNT	ac80	5775	Ant1	5855	-58.25	2.33	0.25	-55.67	Average	15.6	Pass
NVNT	ac80	5775	Ant1	5875	-50.38	2.33	-	-48.05	Peak	10	Pass
NVNT	ac80	5775	Ant1	5875	-57.68	2.33	0.25	-55.10	Average	10	Pass
NVNT	ac80	5775	Ant1	5925	-49.72	2.33	-	-47.39	Peak	-27	Pass
NVNT	ac80	5775	Ant1	5925	-57.66	2.33	0.25	-55.08	Average	-27	Pass
NVNT	ac80	5775	Ant1	5650	-50.44	2.33	-	-48.11	Peak	-27	Pass
NVNT	ac80	5775	Ant1	5650	-58.12	2.33	0.25	-55.54	Average	-27	Pass
NVNT	ac80	5775	Ant1	5700	-49.66	2.33	-	-47.33	Peak	10	Pass
NVNT	ac80	5775	Ant1	5700	-57.72	2.33	0.25	-55.14	Average	10	Pass
NVNT	ac80	5775	Ant1	5720	-42.54	2.33	-	-40.21	Peak	15.6	Pass
NVNT	ac80	5775	Ant1	5720	-53.2	2.33	0.25	-50.62	Average	15.6	Pass
NVNT	ac80	5775	Ant1	5725	-36.13	2.33	-	-33.80	Peak	27	Pass
NVNT	ac80	5775	Ant1	5725	-51.7	2.33	0.25	-49.12	Average	27	Pass
NVNT	ax20	5745	Ant1	5650	-50.73	2.33	-	-48.40	Peak	-27	Pass
NVNT	ax20	5745	Ant1	5650	-58.88	2.33	0.28	-56.27	Average	-27	Pass
NVNT	ax20	5745	Ant1	5700	-49.24	2.33	-	-46.91	Peak	10	Pass
NVNT	ax20	5745	Ant1	5700	-58.24	2.33	0.28	-55.63	Average	10	Pass
NVNT	ax20	5745	Ant1	5720	-39.77	2.33	-	-37.44	Peak	15.6	Pass
NVNT	ax20	5745	Ant1	5720	-54.63	2.33	0.28	-52.02	Average	15.6	Pass
NVNT	ax20	5745	Ant1	5725	-35.27	2.33	-	-32.94	Peak	27	Pass
NVNT	ax20	5745	Ant1	5725	-50.42	2.33	0.28	-47.81	Average	27	Pass
NVNT	ax20	5825	Ant1	5850	-43.21	2.33	-	-40.88	Peak	27	Pass
NVNT	ax20	5825	Ant1	5850	-55.2	2.33	0.28	-52.59	Average	27	Pass
NVNT	ax20	5825	Ant1	5855	-46.45	2.33	-	-44.12	Peak	15.6	Pass
NVNT	ax20	5825	Ant1	5855	-57.8	2.33	0.28	-55.19	Average	15.6	Pass
NVNT	ax20	5825	Ant1	5875	-49.95	2.33	-	-47.62	Peak	10	Pass
NVNT	ax20	5825	Ant1	5875	-59.73	2.33	0.28	-57.12	Average	10	Pass
NVNT	ax20	5825	Ant1	5925	-49.75	2.33	-	-47.42	Peak	-27	Pass
NVNT	ax20	5825	Ant1	5925	-57.65	2.33	0.28	-55.04	Average	-27	Pass
NVNT	ax40	5755	Ant1	5650	-49.87	2.33	-	-47.54	Peak	-27	Pass
NVNT	ax40	5755	Ant1	5650	-57.47	2.33	0.12	-55.02	Average	-27	Pass
NVNT	ax40	5755	Ant1	5700	-50.27	2.33	-	-47.94	Peak	10	Pass
NVNT	ax40	5755	Ant1	5700	-57.41	2.33	0.12	-54.96	Average	10	Pass
NVNT	ax40	5755	Ant1	5720	-43.07	2.33	-	-40.74	Peak	15.6	Pass
NVNT	ax40	5755	Ant1	5720	-52.93	2.33	0.12	-50.48	Average	15.6	Pass
NVNT	ax40	5755	Ant1	5725	-36.8	2.33	-	-34.47	Peak	27	Pass
NVNT	ax40	5755	Ant1	5725	-50.57	2.33	0.12	-48.12	Average	27	Pass





NVNT	ax40	5795	Ant1	5850	-50.26	2.33	-	-47.93	Peak	27	Pass
NVNT	ax40	5795	Ant1	5850	-58.81	2.33	0.12	-56.36	Average	27	Pass
NVNT	ax40	5795	Ant1	5855	-50.2	2.33	-	-47.87	Peak	15.6	Pass
NVNT	ax40	5795	Ant1	5855	-58.29	2.33	0.12	-55.84	Average	15.6	Pass
NVNT	ax40	5795	Ant1	5875	-50.73	2.33	-	-48.40	Peak	10	Pass
NVNT	ax40	5795	Ant1	5875	-58.09	2.33	0.12	-55.64	Average	10	Pass
NVNT	ax40	5795	Ant1	5925	-47.84	2.33	-	-45.51	Peak	-27	Pass
NVNT	ax40	5795	Ant1	5925	-57.71	2.33	0.12	-55.26	Average	-27	Pass
NVNT	ax80	5775	Ant1	5850	-49.45	2.33	-	-47.12	Peak	27	Pass
NVNT	ax80	5775	Ant1	5850	-58.32	2.33	0.25	-55.74	Average	27	Pass
NVNT	ax80	5775	Ant1	5855	-49.63	2.33	-	-47.30	Peak	15.6	Pass
NVNT	ax80	5775	Ant1	5855	-58.19	2.33	0.25	-55.61	Average	15.6	Pass
NVNT	ax80	5775	Ant1	5875	-48.98	2.33	-	-46.65	Peak	10	Pass
NVNT	ax80	5775	Ant1	5875	-58.33	2.33	0.25	-55.75	Average	10	Pass
NVNT	ax80	5775	Ant1	5925	-50.31	2.33	-	-47.98	Peak	-27	Pass
NVNT	ax80	5775	Ant1	5925	-57.82	2.33	0.25	-55.24	Average	-27	Pass
NVNT	ax80	5775	Ant1	5650	-49.29	2.33	-	-46.96	Peak	-27	Pass
NVNT	ax80	5775	Ant1	5650	-58.4	2.33	0.25	-55.82	Average	-27	Pass
NVNT	ax80	5775	Ant1	5700	-50.26	2.33	-	-47.93	Peak	10	Pass
NVNT	ax80	5775	Ant1	5700	-57.52	2.33	0.25	-54.94	Average	10	Pass
NVNT	ax80	5775	Ant1	5720	-43.97	2.33	-	-41.64	Peak	15.6	Pass
NVNT	ax80	5775	Ant1	5720	-53.26	2.33	0.25	-50.68	Average	15.6	Pass
NVNT	ax80	5775	Ant1	5725	-36.05	2.33	-	-33.72	Peak	27	Pass
NVNT	ax80	5775	Ant1	5725	-51.74	2.33	0.25	-49.16	Average	27	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street,
Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Restrict Band NVNT a 5745MHz Ant1 Peak




Restrict Band NVNT a 5745MHz Ant1 Average




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street,
Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity



Restrict Band NVNT a 5825MHz Ant1 Peak




Restrict Band NVNT a 5825MHz Ant1 Average






Restrict Band NVNT n20 5745MHz Ant1 Peak




Restrict Band NVNT n20 5745MHz Ant1 Average






Restrict Band NVNT n20 5825MHz Ant1 Peak




Restrict Band NVNT n20 5825MHz Ant1 Average






Restrict Band NVNT n40 5755MHz Ant1 Peak




Restrict Band NVNT n40 5755MHz Ant1 Average






Restrict Band NVNT n40 5795MHz Ant1 Peak




Restrict Band NVNT n40 5795MHz Ant1 Average






Restrict Band NVNT ac20 5745MHz Ant1 Peak




Restrict Band NVNT ac20 5745MHz Ant1 Average






Restrict Band NVNT ac20 5825MHz Ant1 Peak




Restrict Band NVNT ac20 5825MHz Ant1 Average






Restrict Band NVNT ac40 5755MHz Ant1 Peak




Restrict Band NVNT ac40 5755MHz Ant1 Average






Restrict Band NVNT ac40 5795MHz Ant1 Peak




Restrict Band NVNT ac40 5795MHz Ant1 Average






Restrict Band NVNT ac80 5775MHz Ant1 Peak




Restrict Band NVNT ac80 5775MHz Ant1 Average






Restrict Band NVNT ac80 5775MHz Ant1 Peak




Restrict Band NVNT ac80 5775MHz Ant1 Average






Restrict Band NVNT ax20 5745MHz Ant1 Peak




Restrict Band NVNT ax20 5745MHz Ant1 Average






Restrict Band NVNT ax20 5825MHz Ant1 Peak




Restrict Band NVNT ax20 5825MHz Ant1 Average






Restrict Band NVNT ax40 5755MHz Ant1 Peak




Restrict Band NVNT ax40 5755MHz Ant1 Average






Restrict Band NVNT ax40 5795MHz Ant1 Peak




Restrict Band NVNT ax40 5795MHz Ant1 Average






Restrict Band NVNT ax80 5775MHz Ant1 Peak




Restrict Band NVNT ax80 5775MHz Ant1 Average






Restrict Band NVNT ax80 5775MHz Ant1 Peak



Restrict Band NVNT ax80 5775MHz Ant1 Average





E.5 Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5745	Ant0	5744.98	-20000	-3.48	25	Pass
NVNT	a	5785	Ant0	5784.98	-20000	-3.46	25	Pass
NVNT	a	5825	Ant0	5824.98	-20000	-3.43	25	Pass
NVNT	n20	5745	Ant0	5744.98	-20000	-3.48	25	Pass
NVNT	n20	5785	Ant0	5784.98	-20000	-3.46	25	Pass
NVNT	n20	5825	Ant0	5824.98	-20000	-3.43	25	Pass
NVNT	n40	5755	Ant0	5754.96	-40000	-6.95	25	Pass
NVNT	n40	5795	Ant0	5795	0	0	25	Pass
NVNT	ac20	5745	Ant0	5745	0	0	25	Pass
NVNT	ac20	5785	Ant0	5784.96	-40000	-6.91	25	Pass
NVNT	ac20	5825	Ant0	5824.96	-40000	-6.87	25	Pass
NVNT	ac40	5755	Ant0	5754.96	-40000	-6.95	25	Pass
NVNT	ac40	5795	Ant0	5795	0	0	25	Pass
NVNT	ac80	5775	Ant0	5775	0	0	25	Pass
NVNT	ax20	5745	Ant0	5744.98	-20000	-3.48	25	Pass
NVNT	ax20	5785	Ant0	5784.98	-20000	-3.46	25	Pass
NVNT	ax20	5825	Ant0	5825	0	0	25	Pass
NVNT	ax40	5755	Ant0	5755	0	0	25	Pass
NVNT	ax40	5795	Ant0	5795	0	0	25	Pass
NVNT	ax80	5775	Ant0	5775	0	0	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street,
Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Freq. Stability NVNT a 5745MHz Ant0




Freq. Stability NVNT a 5785MHz Ant0






Freq. Stability NVNT a 5825MHz Ant0




Freq. Stability NVNT n20 5745MHz Ant0






Freq. Stability NVNT n20 5785MHz Ant0




Freq. Stability NVNT n20 5825MHz Ant0






Freq. Stability NVNT n40 5755MHz Ant0




Freq. Stability NVNT n40 5795MHz Ant0






Freq. Stability NVNT ac20 5745MHz Ant0




Freq. Stability NVNT ac20 5785MHz Ant0






Freq. Stability NVNT ac20 5825MHz Ant0




Freq. Stability NVNT ac40 5755MHz Ant0






Freq. Stability NVNT ac40 5795MHz Ant0




Freq. Stability NVNT ac80 5775MHz Ant0






Freq. Stability NVNT ax20 5745MHz Ant0




Freq. Stability NVNT ax20 5785MHz Ant0






Freq. Stability NVNT ax20 5825MHz Ant0




Freq. Stability NVNT ax40 5755MHz Ant0






Freq. Stability NVNT ax40 5795MHz Ant0



Freq. Stability NVNT ax80 5775MHz Ant0





Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5745	Ant1	5745	0	0	25	Pass
NVNT	a	5785	Ant1	5785	0	0	25	Pass
NVNT	a	5825	Ant1	5825	0	0	25	Pass
NVNT	n20	5745	Ant1	5745	0	0	25	Pass
NVNT	n20	5785	Ant1	5785	0	0	25	Pass
NVNT	n20	5825	Ant1	5824.98	-20000	-3.43	25	Pass
NVNT	n40	5755	Ant1	5754.96	-40000	-6.95	25	Pass
NVNT	n40	5795	Ant1	5794.96	-40000	-6.9	25	Pass
NVNT	ac20	5745	Ant1	5745	0	0	25	Pass
NVNT	ac20	5785	Ant1	5784.98	-20000	-3.46	25	Pass
NVNT	ac20	5825	Ant1	5825	0	0	25	Pass
NVNT	ac40	5755	Ant1	5754.96	-40000	-6.95	25	Pass
NVNT	ac40	5795	Ant1	5794.96	-40000	-6.9	25	Pass
NVNT	ac80	5775	Ant1	5775	0	0	25	Pass
NVNT	ax20	5745	Ant1	5745	0	0	25	Pass
NVNT	ax20	5785	Ant1	5784.98	-20000	-3.46	25	Pass
NVNT	ax20	5825	Ant1	5824.98	-20000	-3.43	25	Pass
NVNT	ax40	5755	Ant1	5755	0	0	25	Pass
NVNT	ax40	5795	Ant1	5795	0	0	25	Pass
NVNT	ax80	5775	Ant1	5775	0	0	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street,
Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Freq. Stability NVNT a 5745MHz Ant1




Freq. Stability NVNT a 5785MHz Ant1






Freq. Stability NVNT a 5825MHz Ant1




Freq. Stability NVNT n20 5745MHz Ant1






Freq. Stability NVNT n20 5785MHz Ant1




Freq. Stability NVNT n20 5825MHz Ant1






Freq. Stability NVNT n40 5755MHz Ant1




Freq. Stability NVNT n40 5795MHz Ant1






Freq. Stability NVNT ac20 5745MHz Ant1




Freq. Stability NVNT ac20 5785MHz Ant1






Freq. Stability NVNT ac20 5825MHz Ant1




Freq. Stability NVNT ac40 5755MHz Ant1






Freq. Stability NVNT ac40 5795MHz Ant1




Freq. Stability NVNT ac80 5775MHz Ant1






Freq. Stability NVNT ax20 5745MHz Ant1




Freq. Stability NVNT ax20 5785MHz Ant1






Freq. Stability NVNT ax20 5825MHz Ant1




Freq. Stability NVNT ax40 5755MHz Ant1






Freq. Stability NVNT ax40 5795MHz Ant1



Freq. Stability NVNT ax80 5775MHz Ant1





E.6 Duty Cycle

Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant0	94.65	0.24	0.91
NVNT	a	5785	Ant0	94.56	0.24	0.91
NVNT	a	5825	Ant0	94.65	0.24	0.91
NVNT	n20	5745	Ant0	93.77	0.28	1.07
NVNT	n20	5785	Ant0	93.77	0.28	1.07
NVNT	n20	5825	Ant0	93.77	0.28	1.07
NVNT	n40	5755	Ant0	97.23	0.12	0.46
NVNT	n40	5795	Ant0	97.18	0.12	0.46
NVNT	ac20	5745	Ant0	93.72	0.28	1.06
NVNT	ac20	5785	Ant0	93.72	0.28	1.06
NVNT	ac20	5825	Ant0	93.72	0.28	1.06
NVNT	ac40	5755	Ant0	97.19	0.12	0.46
NVNT	ac40	5795	Ant0	97.19	0.12	0.46
NVNT	ac80	5775	Ant0	94.32	0.25	0.97
NVNT	ax20	5745	Ant0	93.82	0.28	1.06
NVNT	ax20	5785	Ant0	93.82	0.28	1.06
NVNT	ax20	5825	Ant0	93.72	0.28	1.06
NVNT	ax40	5755	Ant0	97.19	0.12	0.46
NVNT	ax40	5795	Ant0	97.19	0.12	0.46
NVNT	ax80	5775	Ant0	94.41	0.25	0.97




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street,
Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5745MHz Ant0




Duty Cycle NVNT a 5785MHz Ant0






Duty Cycle NVNT a 5825MHz Ant0




Duty Cycle NVNT n20 5745MHz Ant0








Duty Cycle NVNT n20 5785MHz Ant0




Duty Cycle NVNT n20 5825MHz Ant0








Duty Cycle NVNT ac20 5745MHz Ant0




Duty Cycle NVNT ac20 5785MHz Ant0






Duty Cycle NVNT ac20 5825MHz Ant0




Duty Cycle NVNT ac40 5755MHz Ant0






Duty Cycle NVNT ac40 5795MHz Ant0




Duty Cycle NVNT ac80 5775MHz Ant0






Duty Cycle NVNT ax20 5745MHz Ant0




Duty Cycle NVNT ax20 5785MHz Ant0






Duty Cycle NVNT ax20 5825MHz Ant0




Duty Cycle NVNT ax40 5755MHz Ant0






Duty Cycle NVNT ax40 5795MHz Ant0



Duty Cycle NVNT ax80 5775MHz Ant0





Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant1	94.65	0.24	0.91
NVNT	a	5785	Ant1	94.65	0.24	0.91
NVNT	a	5825	Ant1	94.56	0.24	0.91
NVNT	n20	5745	Ant1	93.77	0.28	1.07
NVNT	n20	5785	Ant1	93.77	0.28	1.07
NVNT	n20	5825	Ant1	93.67	0.28	1.07
NVNT	n40	5755	Ant1	97.18	0.12	0.46
NVNT	n40	5795	Ant1	97.23	0.12	0.46
NVNT	ac20	5745	Ant1	93.72	0.28	1.06
NVNT	ac20	5785	Ant1	93.72	0.28	1.06
NVNT	ac20	5825	Ant1	93.72	0.28	1.06
NVNT	ac40	5755	Ant1	97.24	0.12	0.46
NVNT	ac40	5795	Ant1	97.19	0.12	0.46
NVNT	ac80	5775	Ant1	94.41	0.25	0.97
NVNT	ax20	5745	Ant1	93.82	0.28	1.06
NVNT	ax20	5785	Ant1	93.72	0.28	1.06
NVNT	ax20	5825	Ant1	93.82	0.28	1.06
NVNT	ax40	5755	Ant1	97.24	0.12	0.46
NVNT	ax40	5795	Ant1	97.19	0.12	0.46
NVNT	ax80	5775	Ant1	94.32	0.25	0.97




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street,
Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5745MHz Ant1




Duty Cycle NVNT a 5785MHz Ant1






Duty Cycle NVNT a 5825MHz Ant1




Duty Cycle NVNT n20 5745MHz Ant1






Duty Cycle NVNT n20 5785MHz Ant1




Duty Cycle NVNT n20 5825MHz Ant1






Duty Cycle NVNT n40 5755MHz Ant1




Duty Cycle NVNT n40 5795MHz Ant1






Duty Cycle NVNT ac20 5745MHz Ant1




Duty Cycle NVNT ac20 5785MHz Ant1






Duty Cycle NVNT ac20 5825MHz Ant1




Duty Cycle NVNT ac40 5755MHz Ant1






Duty Cycle NVNT ac40 5795MHz Ant1




Duty Cycle NVNT ac80 5775MHz Ant1






Duty Cycle NVNT ax20 5745MHz Ant1




Duty Cycle NVNT ax20 5785MHz Ant1






Duty Cycle NVNT ax20 5825MHz Ant1




Duty Cycle NVNT ax40 5755MHz Ant1





Duty Cycle NVNT ax40 5795MHz Ant1



Duty Cycle NVNT ax80 5775MHz Ant1

